

**BG96**

# AT Commands Manual

**LTE Module Series**

Rev. BG96\_AT\_Commands\_Manual\_V2.0

Date: 2017-08-11



**Our aim is to provide customers with timely and comprehensive service. For any assistance, please contact our company headquarters:**

**Quectel Wireless Solutions Co., Ltd.**

7<sup>th</sup> Floor, Hongye Building, No.1801 Hongmei Road, Xuhui District, Shanghai 200233, China

Tel: +86 21 5108 6236

Email: [info@quectel.com](mailto:info@quectel.com)

**Or our local office. For more information, please visit:**

<http://quectel.com/support/sales.htm>

**For technical support, or to report documentation errors, please visit:**

<http://quectel.com/support/technical.htm>

Or email to: [support@quectel.com](mailto:support@quectel.com)

**GENERAL NOTES**

QUECTEL OFFERS THE INFORMATION AS A SERVICE TO ITS CUSTOMERS. THE INFORMATION PROVIDED IS BASED UPON CUSTOMERS' REQUIREMENTS. QUECTEL MAKES EVERY EFFORT TO ENSURE THE QUALITY OF THE INFORMATION IT MAKES AVAILABLE. QUECTEL DOES NOT MAKE ANY WARRANTY AS TO THE INFORMATION CONTAINED HEREIN, AND DOES NOT ACCEPT ANY LIABILITY FOR ANY INJURY, LOSS OR DAMAGE OF ANY KIND INCURRED BY USE OF OR RELIANCE UPON THE INFORMATION. ALL INFORMATION SUPPLIED HEREIN IS SUBJECT TO CHANGE WITHOUT PRIOR NOTICE.

**COPYRIGHT**

THE INFORMATION CONTAINED HERE IS PROPRIETARY TECHNICAL INFORMATION OF QUECTEL CO., LTD. TRANSMITTING, REPRODUCTION, DISSEMINATION AND EDITING OF THIS DOCUMENT AS WELL AS UTILIZATION OF THE CONTENT ARE FORBIDDEN WITHOUT PERMISSION. OFFENDERS WILL BE HELD LIABLE FOR PAYMENT OF DAMAGES. ALL RIGHTS ARE RESERVED IN THE EVENT OF A PATENT GRANT OR REGISTRATION OF A UTILITY MODEL OR DESIGN.

***Copyright © Quectel Wireless Solutions Co., Ltd. 2017. All rights reserved.***

# About the Document

## History

Revision	Date	Author	Description
1.0	2017-04-01	Hyman DING	Initial
2.0	2017-08-11	Walker HAN/ Elvis SUN/ Sherlock ZHAO/ Hyman DING	Numerous changes were made to this document. It should be read in its entirety.

Quectel  
Confidential

## Contents

<b>About the Document</b> .....	<b>2</b>
<b>Contents</b> .....	<b>3</b>
<b>Table Index</b> .....	<b>7</b>
<b>1 Introduction</b> .....	<b>8</b>
1.1. Scope of the Document .....	8
1.2. AT Command Syntax.....	8
1.3. Supported Character Sets .....	9
1.4. AT Command Interface.....	9
1.5. Unsolicited Result Code .....	9
1.6. Turn off Procedure .....	10
1.7. Commands Under Development.....	10
<b>2 General Commands</b> .....	<b>11</b>
2.1. ATI Display Product Identification .....	11
2.2. AT+GMI Request Manufacturer Identification .....	12
2.3. AT+GMM Request TA Model Identification .....	12
2.4. AT+GMR Request TA Revision Identification of Software Release .....	13
2.5. AT+CGMI Request Manufacturer Identification.....	13
2.6. AT+CGMM Request Model Identification .....	14
2.7. AT+CGMR Request TA Revision Identification of Software Release.....	14
2.8. AT+GSN Request International Mobile Equipment Identity (IMEI) .....	15
2.9. AT+CGSN Request Product Serial Number Identification .....	16
2.10. AT&F Set All Current Parameters to Manufacturer Defaults .....	16
2.11. AT&V Display Current Configuration .....	17
2.12. AT&W Store Current Parameters to User Defined Profile.....	18
2.13. ATZ Set All Current Parameters to User Defined Profile.....	18
2.14. ATQ Set Result Code Presentation Mode .....	19
2.15. ATV TA Response Format .....	19
2.16. ATE Set Command Echo Mode.....	21
2.17. A/ Repeat Previous Command Line .....	21
2.18. ATS3 Set Command Line Termination Character.....	22
2.19. ATS4 Set Response Formatting Character .....	23
2.20. ATS5 Set Command Line Editing Character .....	23
2.21. ATX Set CONNECT Result Code Format and Monitor Call Progress .....	24
2.22. AT+CFUN Set Phone Functionality .....	25
2.23. AT+CMEE Error Message Format.....	26
2.24. AT+CSCS Select TE Character Set.....	27
2.25. AT+QURCCFG Configure URC Indication Option .....	28
<b>3 Serial Interface Control Commands</b> .....	<b>30</b>
3.1. AT&C Set DCD Function Mode .....	30
3.2. AT&D Set DTR Function Mode.....	30

3.3.	AT+IFC	Set TE-TA Local Data Flow Control.....	31
3.4.	AT+ICF	Set TE-TA Control Character Framing .....	32
3.5.	AT+IPR	Set TE-TA Fixed Local Rate .....	33
3.6.	AT+QRIR*	Restore RI Behavior to Inactive .....	34
<b>4</b>	<b>Status Control Commands</b>	.....	<b>35</b>
4.1.	AT+CPAS	Mobile Equipment Activity Status.....	35
4.2.	AT+CEER*	Extended Error Report.....	36
4.3.	AT+QCFG	Extended Configuration Settings .....	37
4.3.1.	AT+QCFG="gprsattach"	GPRS Attach Mode Configuration.....	38
4.3.2.	AT+QCFG="nwscanseq"	Network Searching Sequence Configuration.....	39
4.3.3.	AT+QCFG="nwscanmode"	Network Search Mode Configuration.....	39
4.3.4.	AT+QCFG="iotopmode"	LTE Network Search Mode Configuration.....	40
4.3.5.	AT+QCFG="roamservice"	Roam Service Configuration .....	41
4.3.6.	AT+QCFG="band"	Band Configuration .....	42
4.3.7.	AT+QCFG="servicedomain"	Service Domain Configuration.....	44
4.3.8.	AT+QCFG="sgsn"	UE SGSN Release Version Configuration .....	44
4.3.9.	AT+QCFG="msc"	UE MSC Release Version Configuration.....	45
4.3.10.	AT+QCFG="PDP/DuplicateChk"	Establish Multi PDNs with the Same APN .....	46
4.3.11.	AT+QCFG="urc/ri/ring"	RI Behavior When RING URC is Presented.....	46
4.3.12.	AT+QCFG="urc/ri/smsincoming"	RI Behavior When Incoming SMS URCS are Presented.....	48
4.3.13.	AT+QCFG="urc/ri/other"	RI Behavior When Other URCS are Presented .....	49
4.3.14.	AT+QCFG="risignaltype"	RI Signal Output Carrier .....	50
4.3.15.	AT+QCFG="urc/delay"	Delay URC Indication .....	51
4.4.	AT+QINDCFG	URC Indication Configuration.....	51
<b>5</b>	<b>(U)SIM Related Commands</b>	.....	<b>53</b>
5.1.	AT+CIMI	Request International Mobile Subscriber Identity (IMSI).....	53
5.2.	AT+CLCK	Facility Lock .....	54
5.3.	AT+CPIN	Enter PIN .....	56
5.4.	AT+CPWD	Change Password .....	58
5.5.	AT+CSIM*	Generic (U)SIM Access.....	59
5.6.	AT+CRSM	Restricted (U)SIM Access.....	60
5.7.	AT+QCCID	Show ICCID .....	61
5.8.	AT+QPINC*	Display PIN Remainder Counter .....	62
5.9.	AT+QINISTAT*	Query Initialization Status of (U)SIM Card.....	62
5.10.	AT+QSIMDET*	(U)SIM Card Detection .....	63
5.11.	AT+QSIMSTAT*	(U)SIM Card Insertion Status Report .....	64
<b>6</b>	<b>Network Service Commands</b>	.....	<b>66</b>
6.1.	AT+CREG	Network Registration Status .....	66
6.2.	AT+COPS	Operator Selection .....	67
6.3.	AT+CSQ	Signal Quality Report.....	69
6.4.	AT+CPOL	Preferred Operator List.....	70
6.5.	AT+COPN	Read Operator Names.....	72

6.6.	AT+CTZU	Automatic Time Zone Update .....	72
6.7.	AT+CPSMS	Power Saving Mode Setting .....	73
6.8.	AT+CEDRXS	e-I-DRX Setting .....	76
6.9.	AT+CEDRXRDP	Read Dynamic Parameters.....	79
6.10.	AT+CTZR	Time Zone Reporting .....	81
6.11.	AT+QLTS	Obtain the Latest Time Synchronized Through Network .....	83
6.12.	AT+QNWINFO	Query Network Information.....	85
6.13.	AT+QSPN*	Display the Name of Registered Network .....	86
<b>7</b>	<b>Call Related Commands</b> .....		<b>87</b>
7.1.	ATA	Answer an Incoming Call.....	87
7.2.	ATD	Mobile Originated Call to Dial a Number .....	88
7.3.	ATH	Disconnect Existing Connection .....	90
7.4.	AT+CVHU*	Voice Hang up Control.....	90
7.5.	AT+CHUP*	Hang up the Call.....	91
7.6.	+++	Switch from Data Mode to Command Mode .....	91
7.7.	ATO	Switch from Command Mode to Data Mode .....	92
7.8.	ATS0	Set Number of Rings before Automatically Answering Call.....	93
7.9.	ATS6	Set Pause before Blind Dialing .....	94
7.10.	ATS7	Set the Time to Wait for Connection Completion.....	94
7.11.	ATS8	Set the Time to Wait for Comma Dial Modifier.....	95
7.12.	ATS10	Set Disconnection Delay after Indicating the Absence of Data Carrier .....	95
7.13.	AT+CSTA*	Select Type of Address.....	96
7.14.	AT+CLCC*	List Current Calls of ME .....	97
7.15.	AT+CR*	Service Reporting Control .....	98
7.16.	AT+CRC	Set Cellular Result Codes for Incoming Call Indication .....	99
7.17.	AT+CRLP*	Select Radio Link Protocol Parameter .....	100
7.18.	AT+QECCNUM	Configure Emergency Call Numbers.....	102
7.19.	AT+QHUP*	Hang up Call with a Specific Release Cause.....	103
<b>8</b>	<b>Phonebook Commands*</b> .....		<b>106</b>
8.1.	AT+CNUM	Subscriber Number.....	106
8.2.	AT+CPBF	Find Phonebook Entries .....	107
8.3.	AT+CPBR	Read Phonebook Entries .....	108
8.4.	AT+CPBS	Select Phonebook Memory Storage.....	109
8.5.	AT+CPBW	Write Phonebook Entry.....	110
<b>9</b>	<b>Short Message Service Commands</b> .....		<b>112</b>
9.1.	AT+CSMS	Select Message Service .....	112
9.2.	AT+CMGF	Message Format.....	113
9.3.	AT+CSCA	Service Center Address.....	114
9.4.	AT+CPMS	Preferred Message Storage.....	115
9.5.	AT+CMGD	Delete Messages.....	117
9.6.	AT+CMGL	List Messages .....	118
9.7.	AT+CMGR	Read Messages .....	121
9.8.	AT+CMGS	Send Messages.....	125

9.9.	AT+CMMS	More Messages to Send .....	126
9.10.	AT+CMGW	Write Messages to Memory .....	127
9.11.	AT+CMSS	Send Messages from Storage .....	129
9.12.	AT+CNMA	New Message Acknowledgement to UE/TE .....	131
9.13.	AT+CNMI	SMS Event Reporting Configuration .....	132
9.14.	AT+CSCB*	Select Cell Broadcast Message Types .....	135
9.15.	AT+CSDH	Show SMS Text Mode Parameters .....	136
9.16.	AT+CSMP	Set SMS Text Mode Parameters .....	137
9.17.	AT+QCMGS*	Send Concatenated Messages .....	138
9.18.	AT+QCMGR*	Read Concatenated Messages .....	139
9.19.	AT+QSMSR*	Read Messages .....	141
9.20.	AT+QSMSL*	List Messages .....	145
<b>10</b>	<b>Packet Domain Commands</b> .....		<b>149</b>
10.1.	AT+CGATT	Attachment or Detachment of PS .....	149
10.2.	AT+CGDCONT	Define PDP Context .....	150
10.3.	AT+CGQREQ*	Quality of Service Profile (Requested) .....	151
10.4.	AT+CGQMIN*	Quality of Service Profile (Minimum Acceptable) .....	154
10.5.	AT+CGACT	Activate or Deactivate PDP Contexts .....	157
10.6.	AT+CGDATA*	Enter Data Mode .....	158
10.7.	AT+CGPADDR	Show PDP Address .....	159
10.8.	AT+CGCLASS*	GPRS Mobile Station Class .....	160
10.9.	AT+CGREG	Network Registration Status .....	160
10.10.	AT+CGEREP*	Packet Domain Event Report .....	162
10.11.	AT+CGSMS	Select Service for MO SMS Messages .....	164
10.12.	AT+CEREG	EPS Network Registration Status .....	165
10.13.	AT+QGDCNT	Packet Data Counter .....	167
10.14.	AT+QAUGDCNT	Auto Save Packet Data Counter .....	168
<b>11</b>	<b>Supplementary Service Commands*</b> .....		<b>170</b>
11.1.	AT+CCFC	Call Forwarding Number and Conditions Control .....	170
11.2.	AT+CCWA	Call Waiting Control .....	172
11.3.	AT+CHLD	Call Related Supplementary Services .....	174
11.4.	AT+CLIP	Calling Line Identification Presentation .....	176
11.5.	AT+CLIR	Calling Line Identification Restriction .....	177
11.6.	AT+COLP	Connected Line Identification Presentation .....	179
11.7.	AT+CSSN	Supplementary Service Notifications .....	180
11.8.	AT+CUSD	Unstructured Supplementary Service Data .....	182
<b>12</b>	<b>Audio Commands*</b> .....		<b>184</b>
12.1.	AT+CLVL	Loudspeaker Volume Level Selection .....	184
12.2.	AT+CMUT	Mute Control .....	185
12.3.	AT+QAUDLOOP	Enable Audio Loop Test .....	185
12.4.	AT+VTS	DTMF and Tone Generation .....	186
12.5.	AT+VTD	Set Tone Duration .....	187
12.6.	AT+QAUDMOD	Set Audio Mode .....	188

12.7.	AT+QDAI	Digital Audio Interface Configuration .....	189
12.8.	AT+QEEC	Set Echo Cancellation Parameters.....	191
12.9.	AT+QSIDET	Set the Side Tone Gain in Current Mode.....	192
12.10.	AT+QMIC	Set Uplink Gains of MIC.....	192
12.11.	AT+QRXGAIN	Set Downlink Gains of RX .....	193
12.12.	AT+QIIC	IIC Read and Write .....	194
<b>13</b>	<b>Hardware Related Commands</b> .....		<b>196</b>
13.1.	AT+QPOWD	Power down.....	196
13.2.	AT+CCLK	Clock .....	196
13.3.	AT+CBC*	Battery Charge .....	197
13.4.	AT+QADC*	Read ADC Value.....	198
13.5.	AT+QSCLK*	Configure Whether or Not to Enter into Sleep Mode.....	199
<b>14</b>	<b>Appendix</b> .....		<b>200</b>
14.1.	References .....		200
14.2.	Factory Default Settings Restorable with AT&F .....		201
14.3.	AT Command Settings Storable with AT&W .....		203
14.4.	AT Command Settings Storable with ATZ .....		204
14.5.	Summary of CME ERROR Codes.....		205
14.6.	Summary of CMS ERROR Codes.....		206
14.7.	Summary of URC.....		208
14.8.	SMS Character Sets Conversions.....		210
14.9.	Release Cause Text List of AT+CEER .....		216

## Table Index

TABLE 1: TYPES OF AT COMMANDS AND RESPONSES .....	9
TABLE 2: AT&V RESPONSE.....	17
TABLE 3: ATV0&ATV1 RESULT CODES NUMERIC EQUIVALENTS AND BRIEF DESCRIPTION .....	20
TABLE 4: DELAY CLASS .....	154
TABLE 5: RELATED DOCUMENTS .....	200
TABLE 6: TERMS AND ABBREVIATIONS .....	200
TABLE 7: FACTORY DEFAULT SETTINGS RESTORABLE WITH AT&F .....	201
TABLE 8: AT COMMAND SETTINGS STORABLE WITH AT&W .....	203
TABLE 9: AT COMMAND SETTINGS STORABLE WITH ATZ .....	204
TABLE 10: DIFFERENT CODING SCHEMES OF +CME ERROR: <ERR>.....	205
TABLE 11: DIFFERENT CODING SCHEMES OF +CMS ERROR: <ERR> .....	207
TABLE 12: SUMMARY OF URC .....	208
TABLE 13: THE WAY OF SMS TEXT INPUT OR OUTPUT.....	210
TABLE 14: THE INPUT CONVERSIONS TABLE (DCS=GSM 7 BIT AND AT+CSCS="GSM") .....	211
TABLE 15: THE OUTPUT CONVERSIONS TABLE (DCS=GSM 7 BIT AND AT+CSCS="GSM") .....	212
TABLE 16: GSM EXTENDED CHARACTERS.....	212
TABLE 17: THE INPUT CONVERSIONS TABLE (DCS=GSM 7 BIT AND AT+CSCS="IRA") .....	213
TABLE 18: IRA EXTENDED CHARACTERS .....	214
TABLE 19: THE OUTPUT CONVERSIONS TABLE (DCS=GSM 7 BIT AND AT+CSCS="IRA") .....	215
TABLE 20: GSM EXTENDED CHARACTERS.....	215
TABLE 21: RELEASE CAUSE TEXT LIST OF AT+CEER .....	216

# 1 Introduction

## 1.1. Scope of the Document

This document presents the AT Commands Set for Quectel cellular engine BG96.

## 1.2. AT Command Syntax

The “AT” or “at” prefix must be set at the beginning of each command line. To terminate a command line enter `<CR>`. Commands are usually followed by a response that includes “`<CR><LF><response><CR><LF>`”. Throughout this document, only the responses are presented, “`<CR><LF>`” are omitted intentionally.

The AT Commands Set implemented by BG96 is a combination of *3GPP TS 27.007*, *3GPP TS 27.005* and *ITU-T recommendation V.25ter* as well as the AT Commands developed by Quectel.

All these AT commands can be split into three categories syntactically: “**basic**”, “**S parameter**”, and “**extended**”. They are listed as follows:

- **Basic syntax**

These AT commands have the format of “`AT<x><n>`”, or “`AT&<x><n>`”, where “`<x>`” is the command, and “`<n>`” is/are the argument(s) for that command. An example of this is “`ATE<n>`”, which tells the DCE whether received characters should be echoed back to the DTE according to the value of “`<n>`”. “`<n>`” is optional and a default will be used if it is missing.

- **S parameter syntax**

These AT commands have the format of “`ATS<n>=<m>`”, where “`<n>`” is the index of the **S** register to set, and “`<m>`” is the value to assign to it.

- **Extended syntax**

These commands can be operated in several modes, as following table:

**Table 1: Types of AT Commands and Responses**

<b>Test Command</b>	<b>AT+&lt;x&gt;=?</b>	This command returns the list of parameters and value ranges set by the corresponding Write Command or internal processes.
<b>Read Command</b>	<b>AT+&lt;x&gt;?</b>	This command returns the currently set value of the parameter or parameters.
<b>Write Command</b>	<b>AT+&lt;x&gt;=&lt;...&gt;</b>	This command sets the user-definable parameter values.
<b>Execution Command</b>	<b>AT+&lt;x&gt;</b>	This command reads non-variable parameters affected by internal processes in the UE.

### 1.3. Supported Character Sets

BG96 AT command interface defaults to the GSM character set. BG96 module supports the following character sets:

- GSM format
- UCS2
- IRA

The character set can be configured and interrogated by using the **AT+CSCS** command (3GPP TS 27.007) and it is defined in 3GPP TS 27.005. The character set affects transmission and reception of SMS and SMS Cell Broadcast Messages, as well as the entry and display of phone book entries text field.

### 1.4. AT Command Interface

BG96 AT command interface includes two USB ports (USB MODEM port and USB AT port) and one main UART port. The main UART port and two USB ports support AT command communication and data transfer.

### 1.5. Unsolicited Result Code

As an Unsolicited Result Code and a report message, URC is not issued as part of the response related to an executed AT command. URC is issued by BG96 without being requested by the TE and it is issued automatically when a certain event occurs. Typical events leading to URCs are incoming calls (**RING**), received short messages, high/low voltage alarm, high/low temperature alarm, etc.

## 1.6. Turn off Procedure

It is recommended to execute **AT+QPOWD** command to turn off the module, as it is the safest and best way. This procedure is realized by letting the module log off from the network and allowing the software to enter into a secure and safe data state before disconnecting the power supply.

After sending **AT+QPOWD**, do not enter any other AT commands. The module outputs **POWERED DOWN** and sets the STATUS pin as low to enter into the shutdown state. In order to avoid data loss, it is suggested to wait for 1s to switch off the VBAT after the STATUS pin is set as low and the URC **POWERED DOWN** is outputted. If **POWERED DOWN** cannot be received within 65s, the VBAT shall be switched off compulsorily.

## 1.7. Commands Under Development

The AT commands marked with “\*” in this document are still under development.

Quectel  
Confidential

## 2 General Commands

### 2.1. ATI Display Product Identification Information

The command delivers a product information text.

#### ATI Display Product Identification Information

Execution Command  
**ATI**

Response  
TA issues product information text.  
**Quectel**  
**BG96**  
**Revision: <revision>**  
  
**OK**

Maximum Response Time

300ms

Reference  
V.25ter

#### Parameter

**<revision>** Identification text of product software version

#### Example

```
ATI
Quectel
BG96
Revision: BG96MAR01A01M1G
OK
```

## 2.2. AT+GMI Request Manufacturer Identification

The command returns a manufacturer identification text. See also **AT+CGMI**.

### AT+GMI Request Manufacturer Identification

Test Command <b>AT+GMI=?</b>	Response <b>OK</b>
Execution Command <b>AT+GMI</b>	Response TA reports one or more lines of information text which permits the user to identify the manufacturer. <b>Quectel</b>  <b>OK</b>
Maximum Response Time	300ms
Reference V.25ter	

## 2.3. AT+GMM Request TA Model Identification

The command returns a product model identification text. It is identical with **AT+CGMM**.

### AT+GMM Request TA Model Identification

Test Command <b>AT+GMM=?</b>	Response <b>OK</b>
Execution Command <b>AT+GMM</b>	Response TA returns a product model identification text. <b>BG96</b>  <b>OK</b>
Maximum Response Time	300ms
Reference V.25ter	

## 2.4. AT+GMR Request TA Revision Identification of Software Release

The command delivers a product firmware version identification text. It is identical with **AT+CGMR**.

### AT+GMR Request TA Revision Identification of Software Release

Test Command <b>AT+GMR=?</b>	Response <b>OK</b>
Execution Command <b>AT+GMR</b>	Response TA reports one or more lines of information text which permits the user to identify the revision of software release. <b>&lt;revision&gt;</b>  <b>OK</b>
Maximum Response Time	300ms
Reference V.25ter	

#### Parameter

**<revision>** Identification text of product software version

#### Example

```
AT+GMR
BG96MAR01A01M1G

OK
```

## 2.5. AT+CGMI Request Manufacturer Identification

The command returns a manufacturer identification text. See also **AT+GMI**.

### AT+CGMI Request Manufacturer Identification

Test Command <b>AT+CGMI=?</b>	Response <b>OK</b>
Execution Command <b>AT+CGMI</b>	Response TA returns manufacturer identification text. <b>Quectel</b>

	OK
Maximum Response Time	300ms
Reference 3GPP TS 27.007	

## 2.6. AT+CGMM Request Model Identification

The command returns a product model identification text. It is identical with **AT+GMM**.

<b>AT+CGMM Request Model Identification</b>	
Test Command <b>AT+CGMM=?</b>	Response <b>OK</b>
Execution Command <b>AT+CGMM</b>	Response TA returns product model identification text. <b>BG96</b>  <b>OK</b>
Maximum Response Time	300ms
Reference 3GPP TS 27.007	

## 2.7. AT+CGMR Request TA Revision Identification of Software Release

The command delivers a product firmware version identification text. It is identical with **AT+GMR**.

<b>AT+CGMR Request TA Revision Identification of Software Release</b>	
Test Command <b>AT+CGMR=?</b>	Response <b>OK</b>
Execution Command <b>AT+CGMR</b>	Response TA returns identification text of product software version. <b>&lt;revision&gt;</b>  <b>OK</b>
Maximum Response Time	300ms
Reference 3GPP TS 27.007	

**Parameter**

**<revision>** Identification text of product software version

## 2.8. AT+GSN Request International Mobile Equipment Identity (IMEI)

The command returns the International Mobile Equipment Identity (IMEI). It is identical with **AT+CGSN**.

### AT+GSN Request International Mobile Equipment Identity (IMEI)

Test Command <b>AT+GSN=?</b>	Response <b>OK</b>
Execution Command <b>AT+GSN</b>	Response TA reports the IMEI (International Mobile Equipment Identity) number in information text which permits the user to identify the individual ME device. <b>&lt;IMEI&gt;</b> <b>OK</b>
Maximum Response Time	300ms
Reference V.25ter	

**Parameter**

**<IMEI>** IMEI of the ME

**NOTE**

The serial number (IMEI) varies with the individual ME device.

## 2.9. AT+CGSN Request Product Serial Number Identification

The command returns International Mobile Equipment Identity (IMEI). It is identical with **AT+GSN**.

### AT+CGSN Request Product Serial Number Identification

Test Command <b>AT+CGSN=?</b>	Response <b>OK</b>
Execution Command <b>AT+CGSN</b>	Response <b>&lt;IMEI&gt;</b>  <b>OK</b>
Maximum Response Time	300ms
Reference 3GPP TS 27.007	

#### Parameter

**<IMEI>** IMEI of the ME

#### NOTE

The serial number (IMEI) varies with the individual ME device.

## 2.10. AT&F Set All Current Parameters to Manufacturer Defaults

The command resets AT command settings to their factory default values.

### AT&F Set All Current Parameters to Manufacturer Defaults

Execution Command <b>AT&amp;F[&lt;value&gt;]</b>	Response TA sets all current parameters to the manufacturer defined profile. See <b>Table 8</b> . <b>OK</b>
Maximum Response Time	300ms
Reference V.25ter	

**Parameter**

<value>      0      Set all TA parameters to manufacturer defaults

**2.11. AT&V    Display Current Configuration**

The command displays the current settings of several AT command parameters, including the single-letter AT command parameters which are not readable otherwise.

**AT&V    Display Current Configuration**

Execution Command <b>AT&amp;V</b>	Response TA returns the current parameter settings. See <b>Table 2</b> . <b>OK</b>
Maximum Response Time	300ms
Reference V.25ter	

**Table 2: AT&V Response**

AT&V
&C: 1
&D: 2
&F: 0
&W: 0
E: 1
Q: 0
V: 1
X: 1
Z: 0
S0: 0
S3: 13
S4: 10
S5: 8
S6: 2
S7: 0
S8: 2
S10: 15
OK

## 2.12. AT&W Store Current Parameters to User Defined Profile

The command stores the current AT command settings to a user defined profile in non-volatile memory.

### AT&W Store Current Parameters to User Defined Profile

Execution Command <b>AT&amp;W[&lt;n&gt;]</b>	Response TA stores the current parameter settings in the user defined profile. See <b>Table 9</b> . <b>OK</b>
Maximum Response Time	300ms
Reference V.25ter	

#### Parameter

<n>	<u>0</u>	Profile number to store current parameters
-----	----------	--

## 2.13. ATZ Set All Current Parameters to User Defined Profile

The command restores the current AT command settings to the user defined profile in non-volatile memory, if they were stored with **AT&W** before. Any additional AT command on the same command line may be ignored.

### ATZ Set All Current Parameters to User Defined Profile

Execution Command <b>ATZ[&lt;value&gt;]</b>	Response TA sets all current parameters to the user defined profile. See <b>Table 10</b> . <b>OK</b>
Maximum Response Time	300ms
Reference V.25ter	

#### Parameter

<value>	<u>0</u>	Reset to profile number 0
---------	----------	---------------------------

## 2.14. ATQ Set Result Code Presentation Mode

The command controls whether the result code is transmitted to the TE. Other information text transmitted as response is not affected.

### ATQ Set Result Code Presentation Mode

Execution Command <b>ATQ&lt;n&gt;</b>	Response This parameter setting determines whether or not the TA transmits any result code to the TE. Information text transmitted in response is not affected by this setting. If <n>=0: <b>OK</b> If <n>=1: (none)
Maximum Response Time	300ms
Reference V.25ter	

#### Parameter

<n>	<u>0</u>	TA transmits result code
	1	Result codes are suppressed and not transmitted

## 2.15. ATV TA Response Format

The command determines the contents of header and trailer transmitted with AT command result codes and information responses.

The result codes, their numeric equivalents and brief descriptions of the use of each are listed in the following table.

### ATV TA Response Format

Execution Command <b>ATV&lt;value&gt;</b>	Response This parameter setting determines the contents of the header and trailer transmitted with result codes and information responses. When <value>=0 <b>0</b> When <value>=1 <b>OK</b>
--	--

Maximum Response Time	300ms
Reference V.25ter	

### Parameter

<value>	0	Information response: <text><CR><LF> Short result code format: <numeric code><CR>
	1	Information response: <CR><LF><text><CR><LF> Long result code format: <CR><LF><verbose code><CR><LF>

### Example

```

ATV1 //Set <value>=1
OK
AT+CSQ
+CSQ: 30,99

OK //When <value>=1, the result code is OK.
ATV0 //Set <value>=0
0
AT+CSQ
+CSQ: 30,99
0 //When <value>=0, the result code is 0.

```

**Table 3: ATV0&ATV1 Result Codes Numeric Equivalents and Brief Description**

ATV1	ATV0	Description
OK	0	Acknowledges execution of a command.
CONNECT	1	A connection has been established. The DCE is moving from command mode to data mode.
RING	2	The DCE has detected an incoming call signal from network.
NO CARRIER	3	The connection has been terminated or the attempt to establish a connection failed.
ERROR	4	Command not recognized, command line maximum length exceeded, parameter value invalid, or other problem with processing the command line.
NO DIALTONE	6	No dial tone detected.

BUSY	7	Engaged (busy) signal detected.
NO ANSWER	8	“@” (Wait for Quiet Answer) dial modifier was used, but remote ringing followed by five seconds of silence was not detected before expiration of the connection timer (S7).

## 2.16. ATE Set Command Echo Mode

The command controls whether or not the module echoes characters received from TE during AT command mode.

ATE Set Command Echo Mode	
Execution Command <b>ATE&lt;value&gt;</b>	Response This setting determines whether or not the TA echoes characters received from TE during command mode. <b>OK</b>
Maximum Response Time	300ms
Reference V.25ter	

### Parameter

<b>&lt;value&gt;</b>	0	Echo mode OFF
	1	Echo mode ON

## 2.17. A/ Repeat Previous Command Line

The command repeats previous AT command line, and “/” acts as the line terminating character.

A/ Repeat Previous Command Line	
Execution Command <b>A/</b>	Response Repeat the previous command
Reference V.25ter	

## Example

```

ATI
Quectel
BG96
Revision: BG96MAR01A01M1G

OK
A/ //Repeat the previous command.
Quectel
BG96
Revision: BG96MAR01A01M1G

OK
    
```

## 2.18. ATS3 Set Command Line Termination Character

The command determines the character recognized by the module to terminate an incoming command line. It is also generated for result codes and information text, along with character value set via **ATS4**.

### ATS3 Set Command Line Termination Character

Read Command <b>ATS3?</b>	Response <n>  <b>OK</b>
Write Command <b>ATS3=&lt;n&gt;</b>	Response This parameter setting determines the character recognized by TA to terminate an incoming command line. The TA also returns this character in output. <b>OK</b>
Maximum Response Time	300ms
Reference V.25ter	

### Parameter

<n>	0-13-127	Command line termination character (Default 13=<CR>)
-----	----------	--

## 2.19. ATS4 Set Response Formatting Character

The command determines the character generated by the module for result code and information text, along with the command line termination character set via **ATS3**.

### ATS4 Set Response Formatting Character

Read Command <b>ATS4?</b>	Response <n>  <b>OK</b>
Write Command <b>ATS4=&lt;n&gt;</b>	Response This parameter setting determines the character generated by the TA for result code and information text. <b>OK</b>
Maximum Response Time	300ms
Reference V.25ter	

#### Parameter

<n>	0-10-127	Response formatting character (Default 10=<LF>)
-----	----------	---

## 2.20. ATS5 Set Command Line Editing Character

The command determines the character value used by the module to delete the immediately preceding character from the AT command line (i.e. equates to backspace key).

### ATS5 Set Command Line Editing Character

Read Command <b>ATS5?</b>	Response <n>  <b>OK</b>
Write Command <b>ATS5=&lt;n&gt;</b>	Response This parameter setting determines the character recognized by TA as a request to delete the immediately preceding character from the command line. <b>OK</b>
Maximum Response Time	300ms

Reference  
V.25ter

### Parameter

<n>      0-8-127      Command line editing character (Default 8=<Backspace>)

## 2.21. ATX Set CONNECT Result Code Format and Monitor Call Progress

The command determines whether or not the module transmits particular result codes to the TE. It also controls whether or not the module verifies the presence of a dial tone when it begins dialing, and whether or not engaged tone (busy signal) detection is enabled.

### ATX Set CONNECT Result Code Format and Monitor Call Progress

Execution Command <b>ATX&lt;value&gt;</b>	Response This parameter setting determines whether or not the TA detected the presence of dial tone and busy signal and whether or not TA transmits particular result codes. <b>OK</b>
Maximum Response Time	300ms
Reference V.25ter	

### Parameter

<value>	0	<b>CONNECT</b> result code returned only. Dial tone and busy detection are both disabled.
	1	<b>CONNECT&lt;text&gt;</b> result code returned only. Dial tone and busy detection are both disabled.
	2	<b>CONNECT&lt;text&gt;</b> result code returned. Dial tone detection is enabled, while busy detection is disabled.
	3	<b>CONNECT&lt;text&gt;</b> result code returned. Dial tone detection is disabled, while busy detection is enabled.
	4	<b>CONNECT&lt;text&gt;</b> result code returned. Dial tone and busy detection are both enabled.

## 2.22. AT+CFUN Set Phone Functionality

The command controls the functionality level. It can also be used to reset the ME.

### AT+CFUN Set Phone Functionality

Test Command <b>AT+CFUN=?</b>	Response <b>+CFUN:</b> (list of supported <b>&lt;fun&gt;</b> s),(list of supported <b>&lt;rst&gt;</b> s)  <b>OK</b>
Read Command <b>AT+CFUN?</b>	Response <b>+CFUN:</b> <b>&lt;fun&gt;</b>  <b>OK</b>
Write Command <b>AT+CFUN=&lt;fun&gt;[,&lt;rst&gt;]</b>	Response <b>OK</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	15s, determined by network.
Reference 3GPP TS 27.007	

### Parameter

<b>&lt;fun&gt;</b>	0	Minimum functionality
	<u>1</u>	Full functionality (Default)
	4	Disable the ME from both transmitting and receiving RF signals
<b>&lt;rst&gt;</b>	<u>0</u>	Do not reset the ME before setting it to <b>&lt;fun&gt;</b> functionality level. This is the default setting when <b>&lt;rst&gt;</b> is not given.
	1	Reset the ME. The device is fully functional after the reset. This value is available only for <b>&lt;fun&gt;</b> =1.

### Example

```

AT+CFUN=0 //Switch the ME to minimum functionality
OK
AT+COPS?
+COPS: 0 //No operator is registered

OK
AT+CPIN?
    
```

```

+CME ERROR: 13 // (U)SIM failure
AT+CFUN=1 // Switch the ME to full functionality
OK

+CPIN: SIM PIN
AT+CPIN=1234
OK

+CPIN: READY

+QUSIM: 1

+QIND: SMS DONE
AT+CPIN?
+CPIN: READY

OK
AT+COPS?
+COPS: 0,0,"CHINA MOBILE CMCC",7 // Operator is registered

OK
    
```

## 2.23. AT+CMEE Error Message Format

The command controls the format of error result codes: **ERROR**, error numbers or verbose messages as **+CME ERROR: <err>** and **+CMS ERROR: <err>**.

### AT+CMEE Error Message Format

Test Command <b>AT+CMEE=?</b>	Response <b>+CMEE:</b> (list of supported <n>s)  <b>OK</b>
Read Command <b>AT+CMEE?</b>	Response <b>+CMEE:</b> <n>  <b>OK</b>
Write Command <b>AT+CMEE=&lt;n&gt;</b>	Response TA disables or enables the use of result code <b>+CME ERROR: &lt;err&gt;</b> as an indication of an error related to the functionality of the ME.  <b>OK</b>

Maximum Response Time	300ms
Reference	
3GPP TS 27.007	

### Parameter

<n>	0	Disable result code
	1	Enable result code and use numeric values
	2	Enable result code and use verbose values

### Example

```

AT+CMEE=0 //Disable result code
OK
AT+CPIN?
ERROR //Only ERROR will be displayed
AT+CMEE=1 //Enable error result code with numeric values
OK
AT+CPIN?
+CME ERROR: 10
AT+CMEE=2 //Enable error result code with verbose (string) values
OK
AT+CPIN?
+CME ERROR: SIM not inserted
    
```

## 2.24. AT+CSCS Select TE Character Set

The Write Command informs the module which character set is used by the TE. This enables the UE to convert character strings correctly between TE and UE character sets.

AT+CSCS Select TE Character Set	
Test Command AT+CSCS=?	Response +CSCS: (list of supported <chset>s)  OK
Read Command AT+CSCS?	Response +CSCS: <chset>  OK

Write Command <b>AT+CSCS=&lt;chset&gt;</b>	Response Set character set <b>&lt;chset&gt;</b> which is used by the TE. The TA can then convert character strings correctly between the TE and ME character sets. <b>OK</b>
Maximum Response Time	300ms
Reference 3GPP TS 27.007	

### Parameter

<b>&lt;chset&gt;</b>	"GSM"	GSM default alphabet
	"IRA"	International reference alphabet
	"UCS2"	UCS2 alphabet

### Example

```

AT+CSCS? //Query the current character set
+CSCS: "GSM"

OK
AT+CSCS="UCS2" //Set the character set to "UCS2"
OK
AT+CSCS?
+CSCS: "UCS2"

OK

```

## 2.25. AT+QURCCFG Configure URC Indication Option

The command is used to configure the output port of URC.

### AT+QURCCFG Configure URC Indication Option

Test Command <b>AT+QURCCFG=?</b>	Response <b>+QURCCFG: "urcport",("usbat","usbmodem","uart1")</b>  <b>OK</b>
Write Command <b>AT+QURCCFG="urcport"[,&lt;urcportvalue&gt;]</b>	If the configuration parameter <b>&lt;urcportvalue&gt;</b> is omitted, return the current configuration: <b>+QURCCFG: "urcport",&lt;urcportvalue&gt;</b>

	<p><b>OK</b></p> <p>If the configuration parameter <b>&lt;urcportvalue&gt;</b> is not omitted, set the URC output port:</p> <p><b>OK</b> <b>ERROR</b></p>
Maximum Response Time	300ms

### Parameter

<b>&lt;urcportvalue&gt;</b>	Set URC output port	
	"usbat"	USB AT port
	"usbmodem"	USB modem port
	"uart1"	Main UART

### NOTES

1. Configuration of URC output port will be saved to NV immediately by default.
2. After URC output port is set successfully, it will take effect immediately.

### Example

```

AT+QURCCFG=?
+QURCCFG: "urcport",("usbat","usbmodem","uart1")

OK
AT+QURCCFG="urcport","usbmodem"
OK
AT+QURCCFG="urcport"
+QURCCFG: "urcport","usbmodem"

OK
    
```

# 3 Serial Interface Control Commands

## 3.1. AT&C Set DCD Function Mode

The command controls the behavior of the UE's DCD line.

### AT&C Set DCD Function Mode

Execution Command <b>AT&amp;C[&lt;value&gt;]</b>	Response This parameter determines how the state of circuit 109 (DCD) relates to the detection of received line signal from the distant end. <b>OK</b>
Maximum Response Time	300ms
Reference V.25ter	

### Parameter

<b>&lt;value&gt;</b>	0	DCD (data carrier detection) function is always ON
	1	DCD (data carrier detection) function is ON only in the presence of data carrier

## 3.2. AT&D Set DTR Function Mode

The command determines how the UE responds if DTR line is changed from low to high level during data mode.

### AT&D Set DTR Function Mode

Execution Command <b>AT&amp;D[&lt;value&gt;]</b>	Response This parameter determines how the TA responds when circuit 108/2 (DTR) is changed from low to high level during data mode. <b>OK</b>
Maximum Response Time	300ms

Reference  
V.25ter

### Parameter

<b>&lt;value&gt;</b>	0	TA ignores status on DTR.
	1	Low→High on DTR: Change to command mode while remaining the connected call.
	2	Low→High on DTR: Disconnect data call, and change to command mode. When DTR is in high level, auto-answer function is disabled.

## 3.3. AT+IFC Set TE-TA Local Data Flow Control

The command determines the flow control behavior of the serial port.

### AT+IFC Set TE-TA Local Data Flow Control

Test Command <b>AT+IFC=?</b>	Response <b>+IFC:</b> (list of supported <b>&lt;dce_by_dte&gt;</b> s),(list of supported <b>&lt;dte_by_dce&gt;</b> s)  <b>OK</b>
Read Command <b>AT+IFC?</b>	Response <b>+IFC:</b> <b>&lt;dce_by_dte&gt;</b> , <b>&lt;dte_by_dce&gt;</b>  <b>OK</b>
Write Command <b>AT+IFC=&lt;dce_by_dte&gt;,&lt;dte_by_dce&gt;</b>	Response This parameter setting determines the data flow control on the serial interface for data mode. <b>OK</b>
Maximum Response Time	300ms
Reference V.25ter	

### Parameter

<b>&lt;dce_by_dte&gt;</b>	Specifies the method that will be used by TE when receiving data from TA
0	None
2	RTS flow control
<b>&lt;dte_by_dce&gt;</b>	Specifies the method that will be used by TA when receiving data from TE
0	None
2	CTS flow control

**NOTE**

Flow control is only applicable for data mode.

**Example**

```
AT+IFC=2,2 //Open the hardware flow control
OK
AT+IFC?
+IFC: 2,2
OK
```

**3.4. AT+ICF Set TE-TA Control Character Framing**

The command determines the serial interface character framing format and parity received by TA from TE.

**AT+ICF Set TE-TA Control Character Framing**

Test Command <b>AT+ICF=?</b>	Response <b>+ICF:</b> (list of supported <b>&lt;format&gt;s</b> ),(list of supported <b>&lt;parity&gt;s</b> )  <b>OK</b>
Read Command <b>AT+ICF?</b>	Response <b>+ICF:</b> <b>&lt;format&gt;</b> , <b>&lt;parity&gt;</b>  <b>OK</b>
Write Command <b>AT+ICF=[&lt;format&gt;,&lt;parity&gt;]</b>	Response This parameter setting determines the serial interface character framing format and parity received by TA from TE. <b>OK</b>
Maximum Response Time	300ms
Reference V.25ter	

**Parameter**

<b>&lt;format&gt;</b>	<u>3</u>	8 data 0 parity 1 stop
<b>&lt;parity&gt;</b>	0	Odd
	1	Even

2	Mark (1)
3	Space (0)

#### NOTES

1. The command is applied for command mode.
2. The **<parity>** field is ignored if the **<format>** field specifies no parity.

### 3.5. AT+IPR Set TE-TA Fixed Local Rate

The command is used to query and set the baud rate of the UART. The default baud rate value (**<rate>**) is 115200bps. The setting of **<rate>** will not be restored with **AT&F**.

#### AT+IPR Set TE-TA Fixed Local Rate

Test Command <b>AT+IPR=?</b>	Response <b>+IPR:</b> (list of supported auto detectable <b>&lt;rate&gt;</b> s),(list of supported fixed-only <b>&lt;rate&gt;</b> s)  <b>OK</b>
Read Command <b>AT+IPR?</b>	Response <b>+IPR: &lt;rate&gt;</b>  <b>OK</b>
Write Command <b>AT+IPR=&lt;rate&gt;</b>	Response This parameter setting determines the data rate of the TA on the serial interface. After the delivery of any result code associated with the current command line, the rate of command takes effect.  <b>OK</b>
Maximum Response Time	300ms
Reference V.25ter	

#### Parameter

<b>&lt;rate&gt;</b>	Baud rate per second 9600 19200 38400 57600
---------------------	---

115200  
230400  
460800  
921600

#### NOTES

1. If a fixed baud rate is set, make sure that both TE (DTE, usually external processor) and TA (DCE, Quectel module) are configured to the same rate.
2. The value of **AT+IPR** cannot be restored with **AT&F** and **ATZ**, but it is still storable with **AT&W**.
3. In multiplex mode, the baud rate cannot be changed by the Write Command **AT+IPR=<rate>**, and the setting is invalid and cannot be stored even if **AT&W** is executed after the Write Command.
4. A selected baud rate takes effect after the Write Command is executed and acknowledged by "OK".

#### Example

```

AT+IPR=115200           //Set fixed baud rate to 115200bps.
OK
AT&W                   //Store current setting, that is, the serial communication speed is
                        115200bps after restarting module.
OK
AT+IPR?
+IPR: 115200
OK
AT+IPR=115200;&W       //Set fixed baud rate to 115200bps and store the current setting.
OK
    
```

### 3.6. AT+QRIR\* Restore RI Behavior to Inactive

If the RI (ring indicator) behavior is "always", it can be restored to inactive by the Execution Command. The RI behavior is controlled by **AT+QCFG\***. Please refer to **AT+QCFG="urc/ri/ring"**, **AT+QCFG="urc/ri/smsincoming"**, and **AT+QCFG="urc/ri/other"** for more details.

#### AT+QRIR\* Restore RI Behavior to Inactive

Test Command	Response
<b>AT+QRIR=?</b>	<b>OK</b>
Execution Command	Response
<b>AT+QRIR</b>	<b>OK</b> <b>ERROR</b>
Maximum Response Time	300ms

# 4 Status Control Commands

## 4.1. AT+CPAS Mobile Equipment Activity Status

The Execution Command queries the module's activity status.

AT+CPAS Mobile Equipment Activity Status	
Test Command AT+CPAS=?	Response +CPAS: (list of supported <pas>s)  OK
Execution Command AT+CPAS	Response TA returns the activity status of ME: +CPAS: <pas>  OK ERROR  If there is an error related to ME functionality: +CME ERROR: <err>
Maximum Response Time	300ms
Reference 3GPP TS 27.007	

### Parameter

<pas>	0	Ready
	3	Ringing
	4	Call in progress or call hold

### Example

```
AT+CPAS
+CPAS: 0 //The module is idle.
OK
```

```

RING
AT+CLCC
+CLCC: 1,1,4,0,0,"15695519173",161

OK
AT+CPAS
+CPAS: 3 //The module is ringing.

OK
AT+CLCC
+CLCC: 1,0,0,0,0,"10010",129

OK
AT+CPAS
+CPAS: 4 //Call in progress.

OK
    
```

## 4.2. AT+CEER\* Extended Error Report

The command is used to query an extended error and report the cause of the last failed operation, such as:

- the failure to release a call
- the failure to set up a call (both mobile originated or terminated)
- the failure to modify a call by using supplementary services
- the failure to activate, register, query, deactivate or deregister a supplementary service
- the failure to attach GPRS or the failure to activate a PDP context
- the failure to detach GPRS or the failure to deactivate a PDP context

The parameter **<text>** is a text to describe the cause information given by the network.

### AT+CEER\* Extended Error Report

Test command <b>AT+CEER=?</b>	Response <b>OK</b>
Execution command <b>AT+CEER</b>	Response <b>+CEER: &lt;text&gt;</b>

**OK**  
**ERROR**

If there is an error related to ME functionality:

	<b>+CME ERROR: &lt;errcode&gt;</b>
Maximum Response Time	300ms

### Parameter

<b>&lt;text&gt;</b>	Release cause text. Reason for the last call failure to setup or release (listed in <b>Chapter 14.9</b> ). Both CS and PS domain call types are reported. Cause data is captured from Call Manager events and cached locally to later use by this command.
---------------------	--

## 4.3. AT+QCFG Extended Configuration Settings

The command is used to query and configure various settings of UE.

### AT+QCFG Extended Configuration Settings

Test Command	Response
AT+QCFG=?	<p><b>+QCFG: "gprsattach",</b> (list of supported &lt;attachmode&gt;s)</p> <p><b>+QCFG: "nwscanmode",</b> (list of supported &lt;scanmode&gt;s), (list of supported &lt;effect&gt;s)</p> <p><b>+QCFG: "nwscanseq",</b> (list of supported &lt;scanseq&gt;s), (list of supported &lt;effect&gt;s)</p> <p><b>+QCFG: "roamservice",</b> (list of supported &lt;roammode&gt;s), (list of supported &lt;effect&gt;s)</p> <p><b>+QCFG: "servicedomain",</b> (list of supported &lt;service&gt;s), (list of supported &lt;effect&gt;s)</p> <p><b>+QCFG: "rrc",</b> (list of supported &lt;rrcr&gt;s)</p> <p><b>+QCFG: "sgsn",</b> (list of supported &lt;sgsnr&gt;s)</p> <p><b>+QCFG: "msc",</b>(list of supported &lt;mscr&gt;s)</p> <p><b>+QCFG: "pdp/duplicatechk",</b>(list of supported &lt;enable&gt;s)</p> <p><b>+QCFG: "urc/ri/ring",</b> (list of supported &lt;typeri&gt;s), (list of supported &lt;pulseduration&gt;s), (list of supported &lt;activeduration&gt;s), (list of supported &lt;inactiveduration&gt;s),</p>

	(list of supported <ringnodisturbing>s) <b>+QCFG: "urc/ri/smsincoming",</b> (list of supported <typeri>s), (list of supported <pulseduration>s) <b>+QCFG: "urc/ri/other",</b> (list of supported <typeri>s), (list of supported <pulseduration>s) <b>+QCFG: "risignatype",</b> (list of supported <risignatype>s) <b>OK</b>
Maximum Response Time	300ms

### 4.3.1. AT+QCFG="gprsattach" GPRS Attach Mode Configuration

The command specifies the mode to attach GPRS when UE is powered on. This configuration is valid only after the module is restarted.

<b>AT+QCFG="gprsattach" GPRS Attach Mode Configuration</b>	
Write Command <b>AT+QCFG="gprsattach" [&lt;attachmode&gt;]</b>	Response If <attachmode> is omitted, return the current configuration: <b>+QCFG: "gprsattach", &lt;attachmode&gt;</b>  <b>OK</b>  If the configuration parameter <attachmode> is not omitted, configure the GPRS attach mode: <b>OK</b> <b>ERROR</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms

#### Parameter

<attachmode>	Number format. The mode to attach GRPS when UE is powered on.
0	Manual attach
1	Auto attach

### 4.3.2. AT+QCFG="nwscanseq" Network Searching Sequence Configuration

The command specifies the sequence of searching network. If **<effect>** is omitted, the configuration will take effect immediately.

#### AT+QCFG="nwscanseq" Network Searching Sequence Configuration

Write Command <b>AT+QCFG="nwscanseq"[,&lt;scanseq&gt;[, effect]]</b>	Response If <b>&lt;scanseq&gt;</b> and <b>&lt;effect&gt;</b> are both omitted, return the current configuration: <b>+QCFG: "nwscanseq",&lt;scanseq&gt;</b>  <b>OK</b>  If <b>&lt;scanseq&gt;</b> and <b>&lt;effect&gt;</b> are not omitted, configure the network searching sequence : <b>OK</b> <b>ERROR</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms

#### Parameter

<b>&lt;scanseq&gt;</b>	Number format. Network search sequence. (e.g.: 020301 stands for LTE Cat.M1 → LTE Cat.NB1 → GSM) <u>00</u> Automatic (LTE Cat.M1 → LTE Cat.NB1 → GSM) 01 GSM 02 LTE Cat.M1 03 LTE Cat.NB1
<b>&lt;effect&gt;</b>	Number format. When to take effect. 0 Take effect after UE reboots 1 Take effect immediately

### 4.3.3. AT+QCFG="nwscanmode" Network Search Mode Configuration

The command specifies the network mode to be searched. If **<effect>** is omitted, the configuration will take effect immediately.

#### AT+QCFG="nwscanmode" Network Search Mode Configuration

Write Command <b>AT+QCFG="nwscanmode"[,&lt;scanmod</b>	Response If <b>&lt;scanmode&gt;</b> and <b>&lt;effect&gt;</b> are both omitted, return the
---	---

<b>e&gt;[,&lt;effect&gt;]]</b>	<p>current configuration: <b>+QCFG: "nwscanmode",&lt;scanmode&gt;</b></p> <p><b>OK</b></p> <p>If <b>&lt;scanmode&gt;</b> and <b>&lt;effect&gt;</b> are not omitted, set the network mode to be searched:</p> <p><b>OK</b> <b>ERROR</b></p> <p>If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p>
Maximum Response Time	300ms

### Parameter

<b>&lt;scanmode&gt;</b>	<p>Number format. Network mode to be searched.</p> <p><u>0</u> Automatic 1 GSM only 3 LTE only</p>
<b>&lt;effect&gt;</b>	<p>Number format. When to take effect.</p> <p>0 Take effect after UE reboots <u>1</u> Take effect immediately</p>

#### 4.3.4. AT+QCFG="iotopmode" LTE Network Search Mode Configuration

The command specifies the network category to be searched under LTE network mode. If **<effect>** is omitted, the configuration will take effect immediately.

#### AT+QCFG="iotopmode" LTE Network Search Mode Configuration

<p>Write Command</p> <p><b>AT+QCFG="iotopmode"[,&lt;mode&gt;,&lt;effect&gt;]]</b></p>	<p>Response</p> <p>If <b>&lt;mode&gt;</b> and <b>&lt;effect&gt;</b> are both omitted, return the current configuration: <b>+QCFG: "iotopmode",&lt;mode&gt;</b></p> <p><b>OK</b></p> <p>If <b>&lt;mode&gt;</b> and <b>&lt;effect&gt;</b> are not omitted, configure the network category to be searched under LTE network mode: <b>OK</b> <b>ERROR</b></p>
---	---

	If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms

### Parameter

<b>&lt;mode&gt;</b>	Number format. Network category to be searched under LTE network mode. 0 LTE Cat.M1 1 LTE Cat.NB1 <u>2</u> LTE Cat.M1 and Cat.NB1
<b>&lt;effect&gt;</b>	Number format. When to take effect. 0 Take effect after UE reboots <u>1</u> Take effect immediately

### 4.3.5. AT+QCFG="roamservice" Roam Service Configuration

The command is used to enable or disable the roam service. If **<effect>** is omitted, the configuration will take effect immediately.

<b>AT+QCFG="roamservice" Roam Service Configuration</b>	
Write Command <b>AT+QCFG="roamservice",&lt;roammode&gt;[,&lt;effect&gt;]</b>	Response If <b>&lt;roammode&gt;</b> and <b>&lt;effect&gt;</b> are both omitted, return the current configuration: <b>+QCFG: "roamservice",&lt;roammode&gt;</b>  <b>OK</b>  If <b>&lt;roammode&gt;</b> and <b>&lt;effect&gt;</b> are not omitted, configure the mode of roam service: <b>OK</b> <b>ERROR</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms

### Parameter

<b>&lt;roammode&gt;</b>	Number format. The mode of roam service. 1 Disable roam service
-------------------------	--

	2	Enable roam service
	<u>255</u>	AUTO
<b>&lt;effect&gt;</b>		Number format. When to take effect.
	0	Take effect after UE reboots
	1	Take effect immediately

#### 4.3.6. AT+QCFG="band" Band Configuration

The command specified the preferred frequency bands to be searched of UE. If **<effect>** is omitted, the configuration will take effect immediately.

#### AT+QCFG="band" Band Configuration

<p>Write Command</p> <p><b>AT+QCFG="band" [&lt;gsmbandval&gt;,&lt;catm1bandval&gt;,&lt;catnb1bandval&gt;,&lt;effect&gt;]</b></p>	<p>Response</p> <p>If configuration parameters and <b>&lt;effect&gt;</b> are omitted (that is, only execute <b>AT+QCFG="band"</b>), return the current configuration:</p> <p><b>+QCFG:</b> "band",&lt;gsmbandval&gt;,&lt;catm1bandval&gt;,&lt;catnb1bandval&gt; &gt;</p> <p><b>OK</b></p> <p>If configuration parameters are all entered, configure the preferred frequency bands to be searched:</p> <p><b>OK</b> <b>ERROR</b></p> <p>If error is related to ME functionality:</p> <p><b>+CME ERROR: &lt;err&gt;</b></p>
<p>Maximum Response Time</p>	<p>300ms</p>

#### Parameter

<b>&lt;gsmbandval&gt;</b>	A hexadecimal value that specifies the GSM frequency band. If it is set to 0, it means not to change GSM frequency band. (eg.: a=2(GSM1800)+ 8(GSM1900))
00000000	No change
00000001	GSM 900MHz
00000002	GSM 1800MHz
00000004	GSM 850MHz
00000008	GSM 1900MHz
<u>0000000F</u>	Any frequency band
<b>&lt;catm1bandval&gt;</b>	A hexadecimal value that specifies the LTE Cat.M1 frequency band. If it is set to 0 or 0x40000000, it means not to change the frequency band. (eg.: 0x15=0x1(LTE

	B1)+0x4(LTE B3)+0x10(LTE B5))	
	0x1 (CM_BAND_PREF_LTE_EUTRAN_BAND1)	LTE B1
	0x2 (CM_BAND_PREF_LTE_EUTRAN_BAND2)	LTE B2
	0x4 (CM_BAND_PREF_LTE_EUTRAN_BAND3)	LTE B3
	0x8 (CM_BAND_PREF_LTE_EUTRAN_BAND4)	LTE B4
	0x10 (CM_BAND_PREF_LTE_EUTRAN_BAND5)	LTE B5
	0x80 (CM_BAND_PREF_LTE_EUTRAN_BAND8)	LTE B8
	0x800(CM_BAND_PREF_LTE_EUTRAN_BAND12)	LTE B12
	0x1000 (CM_BAND_PREF_LTE_EUTRAN_BAND13)	LTE B13
	0x20000 (CM_BAND_PREF_LTE_EUTRAN_BAND18)	LTE B18
	0x40000(CM_BAND_PREF_LTE_EUTRAN_BAND19)	LTE B19
	0x80000 (CM_BAND_PREF_LTE_EUTRAN_BAND20)	LTE B20
	0x2000000 (CM_BAND_PREF_LTE_EUTRAN_BAND26)	LTE B26
	0x8000000(CM_BAND_PREF_LTE_EUTRAN_BAND28)	LTE B28
	0x400000000(CM_BAND_PREF_LTE_EUTRAN_BAND39)	LTE B39
	0x40000000	No change
	<u>0x400A0E189F (CM_BAND_PREF_ANY)</u>	Any frequency band
<b>&lt;catnb1bandval&gt;</b>	A hexadecimal value that specifies the LTE Cat.NB1 frequency band. If it is set to 0 or 0x40000000, it means not to change the frequency band.	
	0x1 (CM_BAND_PREF_LTE_EUTRAN_BAND1)	LTE B1
	0x2 (CM_BAND_PREF_LTE_EUTRAN_BAND2)	LTE B2
	0x4 (CM_BAND_PREF_LTE_EUTRAN_BAND3)	LTE B3
	0x8 (CM_BAND_PREF_LTE_EUTRAN_BAND4)	LTE B4
	0x10 (CM_BAND_PREF_LTE_EUTRAN_BAND5)	LTE B5
	0x80 (CM_BAND_PREF_LTE_EUTRAN_BAND8)	LTE B8
	0x800(CM_BAND_PREF_LTE_EUTRAN_BAND12)	LTE B12
	0x1000 (CM_BAND_PREF_LTE_EUTRAN_BAND13)	LTE B13
	0x20000 (CM_BAND_PREF_LTE_EUTRAN_BAND18)	LTE B18
	0x40000(CM_BAND_PREF_LTE_EUTRAN_BAND19)	LTE B19
	0x80000 (CM_BAND_PREF_LTE_EUTRAN_BAND20)	LTE B20
	0x2000000 (CM_BAND_PREF_LTE_EUTRAN_BAND26)	LTE B26
	0x8000000(CM_BAND_PREF_LTE_EUTRAN_BAND28)	LTE B28
	0x40000000	No change
	<u>0xA0E189F (CM_BAND_PREF_ANY)</u>	Any frequency band
<b>&lt;effect&gt;</b>	When to take effect	
	0	Take effect after UE reboots
	1	Take effect immediately

### 4.3.7. AT+QCFG="servicedomain" Service Domain Configuration

The command specifies the registered service domain. If **<effect>** is omitted, the configuration will take effect immediately.

#### AT+QCFG="servicedomain" Service Domain Configuration

Write Command <b>AT+QCFG="servicedomain"[,&lt;service&gt;,&lt;effect&gt;]</b>	Response If <b>&lt;service&gt;</b> and <b>&lt;effect&gt;</b> are both omitted, return the current configuration: <b>+QCFG: "servicedomain",&lt;service&gt;</b>  <b>OK</b>  If <b>&lt;service&gt;</b> and <b>&lt;effect&gt;</b> are not omitted, configure the service domain of UE: <b>OK</b> <b>ERROR</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms

#### Parameter

<b>&lt;service&gt;</b>	Service domain of UE 0 CS only 1 PS only <u>2</u> CS & PS
<b>&lt;effect&gt;</b>	Number format. When to take effect. 0 Take effect after UE reboots <u>1</u> Take effect immediately

### 4.3.8. AT+QCFG="sgsn" UE SGSN Release Version Configuration

The command specifies the UE SGSN release version. This configuration is valid only after the module is restarted.

#### AT+QCFG="sgsn" UE SGSN Release Version Configuration

Write Command <b>AT+QCFG="sgsn"[,&lt;sgsnr&gt;]</b>	Response If <b>&lt;sgsnr&gt;</b> is omitted, return the current configuration: <b>+QCFG: "sgsn",&lt;sgsnr&gt;</b>
--	---

	<p>OK</p> <p>If <b>&lt;sgsnr&gt;</b> is not omitted, configure the SGSN release version :</p> <p>OK</p> <p>ERROR</p> <p>If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p>
Maximum Response Time	300ms

### Parameter

<b>&lt;sgsnr&gt;</b>	SGSN release version
	0 R97
	1 R99
	2 Dynamic

### 4.3.9. AT+QCFG="msc" UE MSC Release Version Configuration

The command specifies the UE MSC release version. This configuration is valid only after the module is restarted.

#### AT+QCFG="msc" UE MSC Release Version Configuration

<p>Write Command</p> <p><b>AT+QCFG="msc"[,&lt;mscr&gt;]</b></p>	<p>Response</p> <p>If <b>&lt;mscr&gt;</b> is omitted, return the current configuration: <b>+QCFG: "msc",&lt;mscr&gt;</b></p> <p>OK</p> <p>If <b>&lt;mscr&gt;</b> is not omitted, configure the MSC release version: OK ERROR</p> <p>If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p>
Maximum Response Time	300ms

### Parameter

<b>&lt;mscr&gt;</b>	MSC release version
---------------------	---------------------

0	R97
1	R99
<u>2</u>	Dynamic

#### 4.3.10. AT+QCFG="PDP/DuplicateChk" Establish Multi PDNs with the Same APN

The command allows/refuses establishing multiple PDNs with the same APN profile. The configuration will take effect immediately.

#### AT+QCFG="PDP/DuplicateChk" Establish Multi PDNs with the Same APN

Write Command

**AT+QCFG="PDP/DuplicateChk"[,<enable>]**

Response

If <enable> is omitted, return the current configuration:  
**+QCFG: "PDP/DuplicateChk",<enable>**

**OK**

If <enable> is not omitted, allow/refuse establishing multiple PDNs with the same APN profile:

**OK**

**ERROR**

If there is an error related to ME functionality:

**+CME ERROR: <err>**

Maximum Response Time

300ms

#### Parameter

<enable>	0	Refused to establish multi PDNs with the same APN profile
	1	Allowed to establish multi PDNs with the same APN profile

#### 4.3.11. AT+QCFG="urc/ri/ring" RI Behavior When RING URC is Presented

**AT+QCFG="urc/ri/ring"**, **AT+QCFG="urc/ri/smsincoming"** and **AT+QCFG="urc/ri/other"** are used to control the RI (ring indicator) behavior when URC is reported. These configurations will be stored into NV automatically. The ring indicator is active low. **AT+QCFG="urc/ri/ring"** specifies the RI behavior when URC **RING** is presented to indicate an incoming call.

The sum of parameters <activeduration> and <inactiveduration> determines the interval time of **RING** indications when a call is coming.

**AT+QCFG="urc/ri/ring" RI Behavior When RING URC is Presented**

<p>Write Command</p> <p><b>AT+QCFG="urc/ri/ring" [,&lt;typeri&gt; [,&lt;pulseduration&gt; [,&lt;activeduration&gt; [,&lt;inactiveduration&gt; [,&lt;ringnodisturbing&gt; ]]]]]]</b></p>	<p>Response</p> <p>If &lt;typeri&gt;, &lt;pulseduration&gt;, &lt;activeduration&gt;, &lt;inactiveduration&gt; and &lt;ringnodisturbing&gt; are omitted, return the current configuration:</p> <p><b>+QCFG:</b> "urc/ri/ring",&lt;typeri&gt;,&lt;pulseduration&gt;,&lt;activeduration&gt;,&lt;inactiveduration&gt;,&lt;ringnodisturbing&gt;,&lt;pulsecount&gt;</p> <p><b>OK</b></p> <p>If all configuration parameters are entered, set the RI behavior when <b>RING</b> URC is presented:</p> <p><b>OK</b> <b>ERROR</b></p> <p>If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p>
<p>Maximum Response Time</p>	<p>300ms</p>

**Parameter**

<b>&lt;typeri&gt;</b>	<p>RI behavior when URCs are presented</p> <p>"off" No change. Ring indicator keeps inactive.</p> <p>"pulse" Pulse. Pulse width determined by &lt;pulseduration&gt;.</p> <p>"always" Change to active. RI behavior can be restored to inactive by <b>AT+QRIR</b>.</p> <p>"auto" When <b>RING</b> is presented to indicate an incoming call, the ring indicator changes to and keeps active. When ring of the incoming call ends, either answering or hanging up the incoming call, the ring indicator will change to inactive.</p> <p>"wave" When <b>RING</b> is presented to indicate an incoming call, the ring indicator outputs a square wave. Both &lt;activeduration&gt; and &lt;inactiveduration&gt; are used to set parameters of the square wave. When the ring of incoming call ends, either answering or hanging up the incoming call, the ring indicator will change to inactive.</p>
<b>&lt;pulseduration&gt;</b>	<p>The width of pulse. The value ranges from 1 to 2000ms and the default is 120ms. This parameter is only meaningful when &lt;typeri&gt; is "pulse". If this parameter is not needed, it can be set as null.</p>
<b>&lt;activeduration&gt;</b>	<p>The active duration of square wave. The value ranges from 1 to 10000ms, and the default is 1000ms. This parameter is only meaningful when</p>

<b>&lt;inactiveduration&gt;</b>	<b>&lt;typeri&gt;</b> is "wave". The inactive duration of square wave. The value ranges from 1 to 10000ms, and the default is 5000ms. This parameter is only meaningful when <b>&lt;typeri&gt;</b> is "wave".
<b>&lt;ringnodisturbing&gt;</b>	Set whether the ring indicator behavior could be disturbed. This parameter is only meaningful when <b>&lt;typeri&gt;</b> is configured to "auto" or "wave". For example, when <b>&lt;typeri&gt;</b> is configured to "wave", if the square wave needs not to be disturbed by other URCs (including SMS related URCs), then <b>&lt;ringnodisturbing&gt;</b> should be set to "on". <b>"off"</b> RI behavior can be disturbed by other URCs when the behavior is caused by an incoming call ringing. <b>"on"</b> RI behavior cannot be disturbed by other URCs when the behavior is caused by an incoming call ringing.
<b>&lt;pulsecount&gt;</b>	The count of pulse. This parameter is only meaningful when <b>&lt;typeri&gt;</b> is "pulse". The value ranges from 1 to 5 and the default is 1. The interval time between two pulses is equal to <b>&lt;pulseduration&gt;</b> .

#### 4.3.12. AT+QCFG="urc/ri/smsincoming" RI Behavior When Incoming SMS URCs are Presented

The command specifies the RI (ring indicator) behavior when related incoming message URCs are presented. Incoming message URCs include **+CMTI**, **+CMT**, **+CDS**, and **+CBM**.

<b>AT+QCFG="urc/ri/smsincoming" RI Behavior When Incoming SMS URCs are Presented</b>	
Write Command <b>AT+QCFG="urc/ri/smsincoming" [&lt;typeri&gt;,&lt;pulseduration&gt;]</b>	Response If <b>&lt;typeri&gt;</b> and <b>&lt;pulseduration&gt;</b> are omitted, return the current configuration: <b>+QCFG:</b> <b>"urc/ri/smsincoming",&lt;typeri&gt;,&lt;pulseduration&gt;,&lt;pulsecount&gt;</b>  <b>OK</b>  If <b>&lt;typeri&gt;</b> and <b>&lt;pulseduration&gt;</b> are not omitted, set the RI behavior when incoming SMS URCs are presented: <b>OK</b> <b>ERROR</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms

## Parameter

<b>&lt;typeri&gt;</b>	RI behavior when URCs are presented "off" No change. Ring indicator keeps inactive. "pulse" Pulse. Pulse width determined by <b>&lt;pulseduration&gt;</b> . "always" Change to active. RI behavior can be restored to inactive by <b>AT+QRIR</b> .
<b>&lt;pulseduration&gt;</b>	The width of pulse. The value ranges from 1 to 2000ms and the default is 120ms. This parameter is only meaningful when <b>&lt;typeri&gt;</b> is "pulse".
<b>&lt;pulsecount&gt;</b>	The count of pulse. This parameter is only meaningful when <b>&lt;typeri&gt;</b> is "pulse". The value ranges from 1 to 5 and the default is 1. The interval time between two pulses is equal to <b>&lt;pulseduration&gt;</b> .

### 4.3.13. AT+QCFG="urc/ri/other" RI Behavior When Other URCs are Presented

The command specifies the RI (ring indicator) behavior when other URCs are presented.

#### AT+QCFG="urc/ri/other" RI Behavior When Other URCs are Presented

Write Command <b>AT+QCFG="urc/ri/other" [&lt;typeri&gt; [&lt;pulseduration&gt;]]</b>	Response If <b>&lt;typeri&gt;</b> and <b>&lt;pulseduration&gt;</b> are omitted, return the current configuration: <b>+QCFG:</b> <b>"urc/ri/other", &lt;typeri&gt;, &lt;pulseduration&gt;, &lt;pulsecount&gt;</b>  <b>OK</b>  If <b>&lt;typeri&gt;</b> and <b>&lt;pulseduration&gt;</b> are not omitted, set the RI behavior when other URCs are presented: <b>OK</b> <b>ERROR</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms

## Parameter

<b>&lt;typeri&gt;</b>	RI behavior when URCs are presented "off" No change. Ring indicator keeps inactive. "pulse" Pulse. Pulse width determined by <b>&lt;pulseduration&gt;</b> .
<b>&lt;pulseduration&gt;</b>	The width of pulse. The value ranges from 1 to 2000ms and the default is 120ms. This parameter is only meaningful when <b>&lt;typeri&gt;</b> is "pulse".

**<pulsecount>** The count of pulse. This parameter is only meaningful when **<typeri>** is "pulse". The value ranges from 1 to 5 and the default is 1. The interval time between two pulses is equal to **<pulseduration>**.

#### 4.3.14. AT+QCFG="risignaltyp" RI Signal Output Carrier

The command specifies the RI (ring indicator) signal output carrier.

##### AT+QCFG="risignaltyp" RI Signal Output Carrier

Write Command <b>AT+QCFG="risignaltyp",[&lt;risignaltyp e&gt;]</b>	Response If <b>&lt;risignaltyp&gt;</b> is omitted, return the current configuration: <b>+QCFG: "risignaltyp",&lt;risignaltyp&gt;</b>  <b>OK</b>  If <b>&lt;risignaltyp&gt;</b> is not omitted, configure the RI signal output carrier: <b>OK</b> <b>ERROR</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms

##### Parameter

<b>&lt;risignaltyp&gt;</b>	RI signal output carrier. <u>"respective"</u>  "physical"	The ring indicator behaves on the port where URC is presented. For example, if URC is presented on UART port, it is physical ring indicator. If URC is presented on USB port, it is virtual ring indicator. If URC is presented on USB AT port, and the port does not support ring indicator, then there will be no ring indicator. <b>AT+QURCCFG="urcport"</b> can get the port on which URC is presented.  No matter on which port URC is presented, URC only causes the behavior of physical ring indicator.
----------------------------	--	--

### 4.3.15. AT+QCFG="urc/delay" Delay URC Indication

The command can delay the output of URC indication until ring indicator pulse ends.

#### AT+QCFG="urc/delay" Delay URC Indication

Write Command

**AT+QCFG="urc/delay" [<enable>]**

Response

If <enable> is omitted, return the current configuration:

**+QCFG: "urc/delay",<enable>**

**OK**

If <enable> is not omitted, set when the URC indication will be outputted:

**OK**

**ERROR**

If there is an error related to ME functionality:

**+CME ERROR: <err>**

Reference

#### Parameter

<b>&lt;enable&gt;</b>	0	URC indication will be outputted when ring indicator pulse starts.
	1	URC indication will be outputted when ring indicator pulse ends (only effective when the type of ring indicator is "pulse". Please refer to <b>AT+QCFG="urc/ri/ring"</b> , <b>AT+QCFG="urc/ri/smsincoming"</b> and <b>AT+QCFG="urc/ri/other"</b> for more details).

### 4.4. AT+QINDCFG URC Indication Configuration

The command is used to control URC indication.

#### AT+QINDCFG URC Indication Configuration

Test command

**AT+QINDCFG=?**

Response

**+QINDCFG: "all",(0,1),(0,1)**

**+QINDCFG: "csq",(0,1),(0,1)**

**+QINDCFG: "smsfull",(0,1),(0,1)**

**+QINDCFG: "ring",(0,1),(0,1)**

**+QINDCFG: "smsincoming",(0,1),(0,1)**

	<b>OK</b>
Write command <b>AT+QINDCFG=&lt;urctype&gt;[,&lt;enable&gt;[,&lt;savetonvram&gt;]]</b>	<p>Response</p> <p>If <b>&lt;enable&gt;</b> and <b>&lt;savetonvram&gt;</b> are omitted, the current configuration will be returned: <b>+QINDCFG: &lt;urctype&gt;,&lt;enable&gt;</b></p> <p><b>OK</b></p> <p>If <b>&lt;enable&gt;</b> and <b>&lt;savetonvram&gt;</b> are not omitted, set the URC indication configurations: <b>OK</b> <b>ERROR</b></p> <p>If there is an error related to ME functionality: <b>+CME ERROR: &lt;errcode&gt;</b></p>
Maximum Response Time	300ms

## Parameter

<b>&lt;urctype&gt;</b>	<p>URC type</p> <p>"all" Main switch of all URCs. Default is ON.</p> <p>"csq" Indication of signal strength and channel bit error rate change (similar to <b>AT+CSQ</b>). Default is OFF. If this configuration is ON, present: <b>+QIND: "csq",&lt;rsssi&gt;,&lt;ber&gt;</b></p> <p>"smsfull" SMS storage full indication. Default is OFF. If this configuration is ON, present: <b>+QIND: "smsfull",&lt;storage&gt;</b></p> <p>"ring" <b>RING</b> indication. Default is ON.</p> <p>"smsincoming" Incoming message indication. Default is ON. Related URCs list: <b>+CMTI, +CMT, +CDS</b></p>
<b>&lt;enable&gt;</b>	<p>URC indication is ON or OFF</p> <p>0 OFF</p> <p>1 ON</p>
<b>&lt;savetonvram&gt;</b>	<p>Whether to save configuration into NV. Not saved by default.</p> <p>0 Not save</p> <p>1 Save</p>

# 5 (U)SIM Related Commands

## 5.1. AT+CIMI Request International Mobile Subscriber Identity (IMSI)

The command requests the International Mobile Subscriber Identity (IMSI) which is intended to permit the TE to identify the individual SIM card or active application in the UICC (GSM or USIM) that is attached to the MT.

<b>AT+CIMI Request International Mobile Subscriber Identity (IMSI)</b>	
Test Command <b>AT+CIMI=?</b>	Response <b>OK</b>
Execution Command <b>AT+CIMI</b>	Response TA returns <b>&lt;IMSI&gt;</b> for identifying the individual (U)SIM which is attached to ME. <b>&lt;IMSI&gt;</b>  <b>OK</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms
Reference	3GPP TS 27.007

### Parameter

**<IMSI>** International Mobile Subscriber Identity (string without double quotes)

### Example

```
AT+CIMI
460023210226023 //Query IMSI number of (U)SIM which is attached to ME

OK
```

## 5.2. AT+CLCK Facility Lock

The command is used to lock, unlock or interrogate a MT or a network facility **<fac>**. It can be aborted when network facilities are being set or interrogated. The factory default password of PF, PN, PU, PP and PC lock is "12341234".

AT+CLCK Facility Lock	
Test Command <b>AT+CLCK=?</b>	Response <b>+CLCK:</b> (list of supported <b>&lt;fac&gt;</b> s)  <b>OK</b>
Write Command <b>AT+CLCK=&lt;fac&gt;,&lt;mode&gt;[,&lt;passwd&gt;[,&lt;class&gt;]]</b>	Response This command is used to lock, unlock or interrogate the ME or network facility <b>&lt;fac&gt;</b> . Password is normally needed to do such actions. When querying the status of network service ( <b>&lt;mode&gt;</b> =2) the response line for 'not active' case ( <b>&lt;status&gt;</b> =0) should be returned only if service is not active for any <b>&lt;class&gt;</b> .  If <b>&lt;mode&gt;</b> is not equal to 2 and the command is executed successfully: <b>OK</b>  If <b>&lt;mode&gt;</b> =2 and the command is executed successfully: <b>+CLCK: &lt;status&gt;[,&lt;class&gt;]</b> <b>[+CLCK: &lt;status&gt;[,&lt;class&gt;]]</b> <b>[...]</b>  <b>OK</b>
Maximum Response Time	5s
Reference	3GPP TS 27.007

### Parameter

<b>&lt;fac&gt;</b>	"SC"	(U)SIM (lock SIM/UICC card installed in the currently selected card slot) (SIM/UICC asks password in MT power-up and when this lock command issued).
	"AO"	BAOC (Bar All Outgoing Calls) (refer to 3GPP TS 22.088 clause 1).
	"OI"	BOIC (Bar Outgoing International Calls) (refer to 3GPP TS 22.088 clause 1).
	"OX"	BOIC-exHC (Bar Outgoing International Calls except to Home Country) (refer to 3GPP TS 22.088 clause 1).
	"AI"	BAIC (Bar All Incoming Calls) (refer to 3GPP TS 22.088 clause 2).

"IR"	BIC-Roam (Bar Incoming Calls when Roaming outside the home country) (refer to 3GPP TS 22.088 clause 2).
"AB"	All Barring services (refer to 3GPP TS 22.030) (applicable only for <mode>=0).
"AG"	All outgoing barring services (refer to 3GPP TS 22.030) (applicable only for <mode>=0).
"AC"	All incoming barring services (refer to 3GPP TS 22.030) (applicable only for <mode>=0).
"FD"	SIM card or active application in the UICC (GSM or USIM) fixed dialing memory feature (if PIN2 authentication has not been done during the current session, PIN2 is required as <passwd>).
"PF"	Lock Phone to the very first inserted SIM/UICC card (also referred in the present document as PH-FSIM) (MT asks password when other SIM/UICC cards are inserted).
"PN"	Network Personalization (refer to 3GPP TS 22.022)
"PU"	Network Subset Personalization (refer to 3GPP TS 22.022)
"PP"	Service Provider Personalization (refer to 3GPP TS 22.022)
"PC"	Corporate Personalization (refer to 3GPP TS 22.022)
<mode>	0 Unlock
	1 Lock
	2 Query status
<passwd>	Password
<class>	1 Voice
	2 Data
	4 FAX
	7 All telephony except SMS (Default)
	8 Short message service
	16 Data circuit synchronization
	32 Data circuit asynchronization
<status>	0 OFF
	1 ON

### Example

```

AT+CLCK="SC",2 //Query the status of (U)SIM card
+CLCK: 0 //The (U)SIM card is unlocked (OFF)

OK
AT+CLCK="SC",1,"1234" //Lock (U)SIM card, and the password is 1234
OK
AT+CLCK="SC",2 //Query the status of (U)SIM card
+CLCK: 1 //The (U)SIM card is locked (ON)

OK
AT+CLCK="SC",0,"1234" //Unlock (U)SIM card

```

OK

### 5.3. AT+CPIN Enter PIN

The command is used to enter a password or query whether or not the module requires a password which is necessary before it can be operated. The password may be (U)SIM PIN, (U)SIM PUK, PH-SIM PIN, etc.

#### AT+CPIN Enter PIN

Test Command <b>AT+CPIN=?</b>	Response <b>OK</b>
Read Command <b>AT+CPIN?</b>	Response TA returns an alphanumeric string indicating whether or not some password is required. <b>+CPIN: &lt;code&gt;</b>  <b>OK</b>
Write Command <b>AT+CPIN=&lt;pin&gt;[,&lt;new pin&gt;]</b>	Response TA stores a password, such as (U)SIM PIN, (U)SIM PUK, etc., which is necessary before it can be operated. If the PIN is to be entered twice, the TA shall automatically repeat the PIN. If no PIN request is pending, no action is taken and an error message, <b>+CME ERROR</b> , is returned to TE.  If the PIN required is (U)SIM PUK or (U)SIM PUK2, the second pin is required. This second pin, <b>&lt;new pin&gt;</b> , is used to replace the old pin in the (U)SIM.  <b>OK</b>
Maximum Response Time	5s
Reference 3GPP TS 27.007	

#### Parameter

<b>&lt;code&gt;</b>	READY	MT is not pending for any password
	SIM PIN	MT is waiting for (U)SIM PIN to be given
	SIM PUK	MT is waiting for (U)SIM PUK to be given
	SIM PIN2	MT is waiting for (U)SIM PIN2 to be given
	SIM PUK2	MT is waiting for (U)SIM PUK2 to be given
	PH-NET PIN	MT is waiting for network personalization password to be given
	PH-NET PUK	MT is waiting for network personalization unblocking password

		to be given
	PH-NETSUB PIN	MT is waiting for network subset personalization password to be given
	PH-NETSUB PUK	MT is waiting for network subset personalization unblocking password to be given
	PH-SP PIN	MT is waiting for service provider personalization password to be given
	PH-SP PUK	MT is waiting for service provider personalization unblocking password to be given
	PH-CORP PIN	MT is waiting for corporate personalization password to be given
	PH-CORP PUK	MT is waiting for corporate personalization unblocking password to be given
<b>&lt;pin&gt;</b>	String type. Password. If the requested password was a PUK, such as (U)SIM PUK1, PH-FSIM PUK or another password, then <b>&lt;pin&gt;</b> must be followed by <b>&lt;new pin&gt;</b> .	
<b>&lt;new pin&gt;</b>	String type. New password required if the requested code was a PUK.	

### Example

```
//Enter PIN
AT+CPIN?
+CPIN: SIM PIN //Queried PIN code is locked

OK
AT+CPIN=1234 //Enter PIN
OK

+CPIN: READY
AT+CPIN? //PIN has already been entered
+CPIN: READY

OK

//Enter PUK and PIN
AT+CPIN?
+CPIN: SIM PUK //Queried PUK code is locked

OK
AT+CPIN="26601934","1234" //Enter PUK and new PIN password
OK

+CPIN: READY
AT+CPIN?
+CPIN: READY //PUK has already been entered
```

OK

## 5.4. AT+CPWD Change Password

The command sets a new password for the facility lock function defined by command facility lock **AT+CLCK**.

### AT+CPWD Change Password

Test Command <b>AT+CPWD=?</b>	Response TA returns a list of pairs which present the available facilities and the maximum length of their password. <b>+CPWD:</b> (list of supported <b>&lt;fac&gt;s</b> ),( <b>&lt;pwdlength&gt;s</b> )  <b>OK</b>
Write Command <b>AT+CPWD=&lt;fac&gt;,&lt;oldpwd&gt;,&lt;newpwd&gt;</b> >	Response TA sets a new password for the facility lock function.  <b>OK</b>
Maximum Response Time	5s
Reference	3GPP TS 27.007

### Parameter

<b>&lt;fac&gt;</b>	<p>“SC” (U)SIM (lock SIM/UICC card) (SIM/UICC asks password in MT power-up and when this lock command is issued)</p> <p>“AO” BAO (Bar All Outgoing Calls, refer to <i>3GPP TS 22.088 clause 1</i>)</p> <p>“OI” BOIC (Bar Outgoing International Calls, refer to <i>3GPP TS 22.088 clause 1</i>)</p> <p>“OX” BOIC-exHC (Bar Outgoing International Calls except to Home Country, refer to <i>3GPP TS 22.088 clause 1</i>)</p> <p>“AI” BAIC (Bar All Incoming Calls, refer to <i>3GPP TS 22.088 clause 2</i>)</p> <p>“IR” BIC-Roam (Bar Incoming Calls when Roaming outside the home country, refer to <i>3GPP TS 22.088 clause 2</i>)</p> <p>“AB” All barring services (refer to <i>3GPP TS 22.030</i>, applicable only for <b>&lt;mode&gt;=0</b>)</p> <p>“AG” All outgoing barring services (refer to <i>3GPP TS 22.030</i>, applicable only for <b>&lt;mode&gt;=0</b>)</p> <p>“AC” All incoming barring services (refer to <i>3GPP TS 22.030</i>, applicable only for <b>&lt;mode&gt;=0</b>)</p> <p>“P2” (U)SIM PIN2</p>
<b>&lt;pwdlength&gt;</b>	Integer type. Maximum length of password.

<oldpwd>	Password specified for the facility from the user interface or with command.
<newpwd>	New password

### Example

```

AT+CPIN?
+CPIN: READY

OK
AT+CPWD="SC","1234","4321"           //Change (U)SIM card password to "4321"
OK

//Restart module or re-activate the (U)SIM card

AT+CPIN?                               //Queried PIN code is locked
+CPIN: SIM PIN

OK
AT+CPIN="4321"                         //PIN must be entered to define a new password "4321"
OK

+CPIN: READY
    
```

## 5.5. AT+CSIM\* Generic (U)SIM Access

The command allows a direct control of the (U)SIM that is installed in the currently selected card slot by a distant application on the TE. The TE shall then keep the processing of (U)SIM information within the frame specified by GSM/UMTS.

### AT+CSIM\* Generic (U)SIM Access

Test Command <b>AT+CSIM=?</b>	Response <b>OK</b>
Write Command <b>AT+CSIM=&lt;length&gt;,&lt;command&gt;</b>	Response <b>+CSIM: &lt;length&gt;,&lt;response&gt;</b>  <b>OK</b> <b>ERROR</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms
Reference	

3GPP TS 27.007

**Parameter**

<b>&lt;length&gt;</b>	Integer type. Length of <b>&lt;command&gt;</b> or <b>&lt;response&gt;</b> string.
<b>&lt;command&gt;</b>	Command transferred by the MT to the (U)SIM in the format as described in 3GPP TS 51.011.
<b>&lt;response&gt;</b>	Response to the command transferred by the (U)SIM to the MT in the format as described in 3GPP TS 51.011.

### 5.6. AT+CRSM Restricted (U)SIM Access

The command offers easy and limited access to the (U)SIM database. It transmits the (U)SIM command number (**<command>**) and its required parameters to the MT.

#### AT+CRSM Restricted (U)SIM Access

Test Command <b>AT+CRSM=?</b>	Response <b>OK</b>
Write Command <b>AT+CRSM=&lt;command&gt;[,&lt;fileId&gt;[,&lt;P1&gt;,&lt;P2&gt;,&lt;P3&gt;[,&lt;data&gt;][,&lt;pathId&gt;]]]</b>	Response <b>+CRSM: &lt;sw1&gt;,&lt;sw2&gt;[,&lt;response&gt;]</b>  <b>OK</b> <b>ERROR</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms
Reference 3GPP TS 27.007	

**Parameter**

<b>&lt;command&gt;</b>	(U)SIM command number
	176 READ BINARY
	178 READ RECORD
	192 GET RESPONSE
	214 UPDATE BINARY
	220 UPDATE RECORD
	242 STATUS

<b>&lt;fileId&gt;</b>	Integer type. Identifier for an elementary data file on (U)SIM, if used by <b>&lt;command&gt;</b> .
<b>&lt;P1&gt;, &lt;P2&gt;, &lt;P3&gt;</b>	Integer type. Parameters transferred by the MT to the (U)SIM. These parameters are mandatory for every command, except GET RESPONSE and STATUS. The values are described in <i>3GPP TS 51.011</i> .
<b>&lt;data&gt;</b>	Information which shall be written to the (U)SIM (hexadecimal character format; refer to <b>AT+CSCS</b> ).
<b>&lt;pathId&gt;</b>	The directory path of an elementary file on a UICC in hexadecimal format.
<b>&lt;sw1&gt;, &lt;sw2&gt;</b>	Integer type. Information from the (U)SIM about the execution of the actual command. These parameters are delivered to the TE in both cases, on successful or failed execution of the command.
<b>&lt;response&gt;</b>	Response of a successful completion of the command previously issued (hexadecimal character format; refer to <b>AT+CSCS</b> ). STATUS and GET RESPONSE return data, which gives information about the current elementary data field. The information includes the type of file and its size (refer to <i>3GPP TS 51.011</i> ). After READ BINARY, READ RECORD or RETRIEVE DATA command, the requested data will be returned. <b>&lt;response&gt;</b> is not returned after a successful UPDATE BINARY, UPDATE RECORD or SET DATA command.

## 5.7. AT+QCCID Show ICCID

The command returns the ICCID (Integrated Circuit Card Identifier) number of the (U)SIM card.

<b>AT+QCCID Show ICCID</b>	
Test Command <b>AT+QCCID=?</b>	Response <b>OK</b>
Execution Command <b>AT+QCCID</b>	Response <b>+QCCID: &lt;iccid&gt;</b>  <b>OK</b> <b>ERROR</b>
Maximum Response Time	300ms

### Example

```

AT+QCCID //Query ICCID of the (U)SIM card
+QCCID: 89860025128306012474

OK

```

## 5.8. AT+QPINC\* Display PIN Remainder Counter

The command can query the number of attempts left to enter the password of (U)SIM PIN/PUK.

<b>AT+ QPINC* Display PIN Remainder Counter</b>	
Test Command <b>AT+QPINC=?</b>	Response <b>+QPINC: ("SC", "P2")</b>  <b>OK</b>
Read Command <b>AT+QPINC?</b>	Response <b>+QPINC: "SC", &lt;pincounter&gt;, &lt;pukcounter&gt;</b> <b>+QPINC: "P2", &lt;pincounter&gt;, &lt;pukcounter&gt;</b>  <b>OK</b>
Write Command <b>AT+QPINC=&lt;facility&gt;</b>	Response <b>+QPINC: &lt;facility&gt;, &lt;pincounter&gt;, &lt;pukcounter&gt;</b>  <b>OK</b> <b>ERROR</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms

### Parameter

<b>&lt;facility&gt;</b>	"SC" (U)SIM PIN "P2" (U)SIM PIN2
<b>&lt;pincounter&gt;</b>	Number of attempts left to enter the password of PIN
<b>&lt;pukcounter&gt;</b>	Number of attempts left to enter the password of PUK

## 5.9. AT+QINISTAT\* Query Initialization Status of (U)SIM Card

The command is used to query the initialization status of (U)SIM card.

<b>AT+QINISTAT* Query Initialization Status of (U)SIM Card</b>	
Test Command <b>AT+QINISTAT=?</b>	Response <b>+QINISTAT: (0-7)</b>  <b>OK</b>

Execution Command <b>AT+QINISTAT</b>	Response <b>+QINISTAT: &lt;status&gt;</b>  <b>OK</b>
Maximum Response Time	300ms

### Parameter

<b>&lt;status&gt;</b>	Initialization status of (U)SIM card. Actual value is the sum of several of the following four kinds (e.g. 7=1+2+4 means CPIN READY & SMS DONE & PB DONE).
0	Initial state
1	CPIN READY. Operation like lock/unlock PIN is allowed
2	SMS initialization completed
4	Phonebook initialization completed

## 5.10. AT+QSIMDET\* (U)SIM Card Detection

The command enables (U)SIM card hot-swap function. (U)SIM card is detected by GPIO interrupt. The level of (U)SIM card detection pin should also be set when the (U)SIM card is inserted. This command can be saved by **AT&W**.

### AT+ QSIMDET\* (U)SIM Card Detection

Test Command <b>AT+QSIMDET=?</b>	Response <b>+QSIMDET: (0,1),(0,1)</b>  <b>OK</b>
Read Command <b>AT+QSIMDET?</b>	Response <b>+QSIMDET: &lt;enable&gt;,&lt;insertlevel&gt;</b>  <b>OK</b>
Write Command <b>AT+QSIMDET=&lt;enable&gt;,&lt;insertlevel&gt;</b>	Response <b>OK</b> <b>ERROR</b>
Maximum Response Time	300ms

### Parameter

<b>&lt;enable&gt;</b>	Enable or disable (U)SIM card detection
<u>0</u>	Disable

	1	Enable
<b>&lt;insertlevel&gt;</b>	The level of (U)SIM card detection pin when a (U)SIM card is inserted	
	0	Low level
	1	High level

### NOTES

- Hot-swap function is invalid if the configured value of **<insertlevel>** is inconsistent with hardware design.
- Hot-swap function takes effect after the module is restarted.

### Example

```

AT+QSIMDET=1,0           //Set (U)SIM card detection pin level as low when (U)SIM card is inserted
OK

<Remove (U)SIM card>

+CPIN: NOT READY

<Insert (U)SIM card>

+CPIN: READY             //If PIN1 of the (U)SIM card is unlocked
    
```

## 5.11. AT+QSIMSTAT\* (U)SIM Card Insertion Status Report

The command queries (U)SIM card insertion status and determines whether (U)SIM card insertion status report is enabled. The configuration of this command can be saved by **AT&W**.

### AT+ QSIMSTAT\* (U)SIM Card Insertion Status Report

Test Command <b>AT+QSIMSTAT=?</b>	Response <b>+QSIMSTAT: (0,1)</b>  <b>OK</b>
Read Command <b>AT+QSIMSTAT?</b>	Response <b>+QSIMSTAT: &lt;enable&gt;,&lt;insertedstatus&gt;</b>  <b>OK</b>
Write Command <b>AT+QSIMSTAT=&lt;enable&gt;</b>	Response <b>OK</b> <b>ERROR</b>
Maximum Response Time	300ms

## Parameter

<b>&lt;enable&gt;</b>	Enable or disable (U)SIM card insertion status report. If it is enabled, when (U)SIM card is removed or inserted, the URC <b>+QSIMSTAT: &lt;enable&gt;,&lt;insertedstatus&gt;</b> will be reported. <u>0</u> Disable 1    Enable
<b>&lt;insertedstatus&gt;</b>	(U)SIM card is inserted or removed. This argument is not allowed to be set. 0    Removed 1    Inserted 2    Unknown, before (U)SIM initialization

## Example

```

AT+QSIMSTAT? //Query (U)SIM card insertion status.
+QSIMSTAT: 0,1

OK
AT+QSIMDET=1,0
OK
AT+QSIMSTAT=1 //Enable (U)SIM card insertion status report.
OK
AT+QSIMSTAT?
+QSIMSTAT: 1,1

OK
<Remove (U)SIM card>
+QSIMSTAT : 1,0 //Report of (U)SIM card insertion status: removed.

+CPIN: NOT READY
AT+QSIMSTAT?
+QSIMSTAT: 1,0

OK
<Insert (U)SIM card>
+QSIMSTAT : 1,1 //Report of (U)SIM card insertion status: inserted

+CPIN: READY
    
```

# 6 Network Service Commands

## 6.1. AT+CREG Network Registration Status

The Write Command controls the presentation of the unsolicited result code **+CREG: <stat>** when **<n>=1** and there is a change in the MT's circuit mode network registration status in GERAN/E-UTRAN, or unsolicited result code **+CREG: <stat>[,<lac>],[<ci>],[<Act>]]** when **<n>=2** and there is a change of the network cell in GERAN/E-UTRAN.

AT+CREG Network Registration Status	
Test Command <b>AT+CREG=?</b>	Response <b>+CREG:</b> (list of supported <b>&lt;n&gt;s</b> )  <b>OK</b>
Read Command <b>AT+CREG?</b>	Response <b>+CREG: &lt;n&gt;,&lt;stat&gt;[,&lt;lac&gt;,&lt;ci&gt;[,&lt;Act&gt;]]</b>  <b>OK</b>
Write Command <b>AT+CREG[=&lt;n&gt;]</b>	Response <b>OK</b> <b>ERROR</b>
Maximum Response Time	300ms
Reference	3GPP TS 27.007

### Parameter

<b>&lt;n&gt;</b>	0	Disable network registration unsolicited result code
	1	Enable network registration unsolicited result code: <b>+CREG:&lt;stat&gt;</b>
	2	Enable network registration and location information unsolicited result code: <b>+CREG: &lt;stat&gt;[,&lt;lac&gt;,&lt;ci&gt;[,&lt;Act&gt;]]</b>
<b>&lt;stat&gt;</b>	0	Not registered. MT is not currently searching an operator to register to.
	1	Registered, home network.
	2	Not registered, but MT is currently trying to attach or searching an operator to register to.
	3	Registration denied

	4	Unknown
	5	Registered, roaming
<b>&lt;lac&gt;</b>	String type. Two-byte location area code in hexadecimal format.	
<b>&lt;ci&gt;</b>	String type. Four-byte GERAN/E-UTRAN cell ID in hexadecimal format.	
<b>&lt;Act&gt;</b>	Access technology selected	
	0	GSM
	8	LTE Cat.M1
	9	LTE Cat.NB1

## 6.2. AT+COPS Operator Selection

The command returns the current operators and their status, and allows setting automatic or manual network selection.

### AT+COPS Operator Selection

<p>Test Command <b>AT+COPS=?</b></p>	<p>Response</p> <p>TA returns a set of five parameters, each representing an operator presenting in the network. Any of the formats may be unavailable and should then be an empty field. The list of operators shall be in the order of: home network, networks referenced in (U)SIM and other networks.</p> <p><b>+COPS:</b> (list of supported&lt;stat&gt;, long alphanumeric &lt;oper&gt;, short alphanumeric &lt;oper&gt;, numeric &lt;oper&gt;s)[,&lt; Act&gt;]s] [,,(list of supported &lt;mode&gt;s),(list of supported &lt;format&gt;s )]</p> <p><b>OK</b></p> <p>If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p>
<p>Read Command <b>AT+COPS?</b></p>	<p>Response</p> <p>TA returns the current mode and the currently selected operator. If no operator is selected, &lt;format&gt;, &lt;oper&gt; and &lt;Act&gt; are omitted.</p> <p><b>+COPS: &lt;mode&gt;[,&lt;format&gt;[,&lt;oper&gt;][,&lt;Act&gt;]]</b></p> <p><b>OK</b></p> <p>If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p>
<p>Write Command <b>AT+COPS=&lt;mode&gt;[,&lt;format&gt;[,&lt;oper&gt;][,&lt;Act&gt;]]</b></p>	<p>Response</p> <p>TA forces an attempt to select and register the GSM/UMTS network operator. If the selected operator is not available, no</p>

	<p>other operator shall be selected (except <b>&lt;mode&gt;=4</b>). The format of selected operator name shall apply to further Read Command (<b>AT+COPS?</b>).</p> <p><b>OK</b></p> <p>If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p>
Maximum Response Time	180s, determined by network.
Reference	3GPP TS 27.007

### Parameter

<b>&lt;stat&gt;</b>	0	Unknown
	1	Operator available
	2	Current operator
	3	Operator forbidden
<b>&lt;oper&gt;</b>	Operator in format as per <b>&lt;mode&gt;</b>	
<b>&lt;mode&gt;</b>	0	Automatic mode. <b>&lt;oper&gt;</b> field is ignored.
	1	Manual operator selection. <b>&lt;oper&gt;</b> field shall be presented and <b>&lt;Act&gt;</b> optionally.
	2	Manual deregister from network.
	3	Set only <b>&lt;format&gt;</b> (for <b>AT+COPS?</b> Read Command), and do not attempt to register/deregister ( <b>&lt;oper&gt;</b> and <b>&lt;Act&gt;</b> fields are ignored). This value is invalid in the response of the Read Command.
	4	Manual/automatic selection. <b>&lt;oper&gt;</b> field shall be presented. If manual selection fails, automatic mode ( <b>&lt;mode&gt;=0</b> ) is entered.
<b>&lt;format&gt;</b>	0	Long format alphanumeric <b>&lt;oper&gt;</b> which can be up to 16 characters long
	1	Short format alphanumeric <b>&lt;oper&gt;</b>
	2	Numeric <b>&lt;oper&gt;</b> . GSM location area identification number.
<b>&lt;Act&gt;</b>	Access technology selected. Values 3, 4, 5 and 6 occur only in the response of the Read Command while MS is in data service state and is not intended for <b>AT+COPS</b> Write Command.	
	0	GSM
	8	LTE Cat.M1
	9	LTE Cat.NB1

### Example

```

AT+COPS=? //List all current network operators
+COPS: +COPS: (3,"CHN-UNICOM","UNICOM","46001",0),(3,"CHINA
MOBILE","CMCC","46000",0),(1,"CHN-CT","CT","46011",9),(0,1,2,3,4),(0,1,2)

```

```
OK
AT+COPS? //Query the currently selected network operator
+COPS: 0,0,"CHN-UNICOM",0
OK
```

### 6.3. AT+CSQ Signal Quality Report

The command indicates the received signal strength **<rss>** and the channel bit error rate **<ber>**.

#### AT+CSQ Signal Quality Report

Test Command <b>AT+CSQ=?</b>	Response The Test Command returns values supported by the TA. <b>+CSQ:</b> (list of supported <b>&lt;rss&gt;</b> s),(list of supported <b>&lt;ber&gt;</b> s)  <b>OK</b>
Execution Command <b>AT+CSQ</b>	Response The Execution Command returns received signal strength indication <b>&lt;rss&gt;</b> and channel bit error rate <b>&lt;ber&gt;</b> from the ME. <b>+CSQ: &lt;rss&gt;,&lt;ber&gt;</b>  <b>OK</b> <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms
Reference 3GPP TS 27.007	

#### Parameter

<b>&lt;rss&gt;</b>		
0		-113dBm or less
1		-111dBm
2...30		-109... -53dBm
31		-51dBm or greater
99		Not known or not detectable
100		-116dBm or less
101		-115dBm
102...190		-114...-26dBm
191		-25dBm or greater
199		Not known or not detectable

<b>&lt;ber&gt;</b>	Channel bit error rate (in percent)
0...7	As RXQUAL values in the table in 3GPP TS 45.008 subclause 8.2.4
99	Not known or not detectable

### Example

```

AT+CSQ=?
+CSQ: (0-31,99),(0-7,99)

OK
AT+CSQ
+CSQ: 28,99 //The current signal strength indication is 28 and channel bit
error rate is 99.

OK
    
```

#### NOTE

After using network related commands such as **AT+CCWA** and **AT+CCFC**, it is recommended to wait for 3s before entering **AT+CSQ** so as to ensure that any network access required by the preceding command has been finished.

## 6.4. AT+CPOL Preferred Operator List

The command edits and queries the list of preferred operators.

### AT+CPOL Preferred Operator List

Test Command <b>AT+CPOL=?</b>	Response <b>+CPOL:</b> (list of supported <b>&lt;index&gt;</b> s),(list of supported <b>&lt;format&gt;</b> s)  <b>OK</b>
Read Command <b>AT+CPOL?</b>	Response Query the list of preferred operators: <b>+CPOL:</b> <b>&lt;index&gt;</b> , <b>&lt;format&gt;</b> , <b>&lt;oper&gt;</b> [, <b>&lt;GSM&gt;</b> ], <b>&lt;GSM_compact&gt;</b> , <b>&lt;UTRAN&gt;</b> , <b>&lt;E-UTRAN&gt;</b> <b>&lt;index&gt;</b> , <b>&lt;format&gt;</b> , <b>&lt;oper&gt;</b> [, <b>&lt;GSM&gt;</b> ], <b>&lt;GSM_compact&gt;</b> , <b>&lt;UTRAN&gt;</b> , <b>&lt;E-UTRAN&gt;</b> [...]

	<b>OK</b>
Write Command <b>AT+CPOLE=&lt;index&gt;[,&lt;format&gt;[,&lt;oper&gt; [&lt;GSM&gt;,&lt;GSM_compact&gt;,&lt;UTRAN&gt;, &lt;E-UTRAN&gt;]]]</b>	Response Edit the list of preferred operators:  <b>OK</b> <b>ERROR</b>  If the <b>&lt;index&gt;</b> is given but the <b>&lt;operator&gt;</b> is left out, the entry is deleted.
Maximum Response Time	300ms
Reference	3GPP TS 27.007

### Parameter

<b>&lt;index&gt;</b>	Integer type. The order number of operator in the (U)SIM preferred operator list
<b>&lt;format&gt;</b>	0 Long format alphanumeric <b>&lt;oper&gt;</b> 1 Short format alphanumeric <b>&lt;oper&gt;</b> 2 Numeric <b>&lt;oper&gt;</b>
<b>&lt;oper&gt;</b>	String type. <b>&lt;format&gt;</b> indicates the format is alphanumeric or numeric (see <b>AT+COPS</b> )
<b>&lt;GSM&gt;</b>	GSM access technology 0 Access technology is not selected 1 Access technology is selected
<b>&lt;GSM_compact&gt;</b>	GSM compact access technology 0 Access technology is not selected 1 Access technology is selected
<b>&lt;UTRAN&gt;</b>	UTRAN access technology 0 Access technology is not selected 1 Access technology is selected
<b>&lt;E-UTRAN&gt;</b>	E-UTRAN access technology 0 Access technology is not selected 1 Access technology is selected

### NOTES

1. The access technology selection parameters **<GSM>**, **<GSM\_compact>**, **<UTRAN>** and **<E-UTRAN>** are required for SIM cards or UICCs containing PLMN selector with access technology.
2. The parameter **<UTRAN>** is invalid in this command for BG96.

## 6.5. AT+COPN Read Operator Names

The command returns the list of operator names from the ME. Each operator code **<numeric>** that has an alphanumeric equivalent **<alphan>** in the ME memory is returned.

### AT+COPN Read Operator Names

Test Command <b>AT+COPN=?</b>	Response <b>OK</b>
Execution Command <b>AT+COPN</b>	Response <b>+COPN: &lt;numeric1&gt;,&lt;alpha1&gt;</b> <b>[+COPN: &lt;numeric2&gt;,&lt;alpha2&gt;</b> <b>[...]]</b>  <b>OK</b> <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	Depends on the number of operator names.
Reference 3GPP TS 27.007	

#### Parameter

<b>&lt;numeric&gt;</b>	String type. Operator in numeric format (see <b>AT+COPS</b> )
<b>&lt;alphan&gt;</b>	String type. Operator in long alphanumeric format (see <b>AT+COPS</b> )

## 6.6. AT+CTZU Automatic Time Zone Update

The Write Command enables and disables automatic time zone update via NITZ. The configuration is stored to NV automatically.

### AT+CTZU Automatic Time Zone Update

Test Command <b>AT+CTZU=?</b>	Response <b>+CTZU: (0,1)</b>  <b>OK</b>
Write Command <b>AT+CTZU=&lt;onoff&gt;</b>	Response <b>OK</b> <b>ERROR</b>
Read Command <b>AT+CTZU?</b>	Response <b>+CTZU: &lt;onoff&gt;</b>

	OK
Maximum Response Time	300ms
Reference	
3GPP TS 27.007	

### Parameter

<b>&lt;onoff&gt;</b>	Integer type. The mode of automatic time zone update.
0	Disable automatic time zone update via NITZ
1	Enable automatic time zone update via NITZ

### Example

```
AT+CTZU?
```

```
+CTZU: 0
```

```
OK
```

```
AT+CTZU=?
```

```
+CTZU: (0,1)
```

```
OK
```

```
AT+CTZU=1
```

```
OK
```

```
AT+CTZU?
```

```
+CTZU: 1
```

```
OK
```

## 6.7. AT+CPSMS Power Saving Mode Setting

The Write Command controls the setting of the UE's power saving mode (PSM) parameters.

### AT+CPSMS Power Saving Mode Setting

Test Command	Response
AT+CPSMS=?	+CPSMS: (list of supported <mode>s),(list of supported <Requested_Periodic-RAU>s),(list of supported <Requested_GPRS-READY-timer>s),(list of supported <Requested_Periodic-TAU>s),(list of supported <Requested_Active-Time>s)

	<b>OK</b>
Write Command <b>+CPSMS=[&lt;mode&gt;[,&lt;Requested_Periodic-RAU&gt;[,&lt;Requested_GPRS-READY-timer&gt;[,&lt;Requested_Periodic-TAU&gt;[,&lt;Requested_Active-Time&gt;]]]]]</b>	Response <b>OK</b> <b>ERROR</b>
Read Command <b>AT+CPSMS?</b>	Response <b>+CPSMS: &lt;mode&gt;[,&lt;Requested_Periodic-RAU&gt;[,&lt;Requested_GPRS-READY-timer&gt;[,&lt;Requested_Periodic-TAU&gt;[,&lt;Requested_Active-Time&gt;]]]</b>  <b>OK</b>
Maximum Response Time	300ms
Reference 3GPP TS 27.007	

## Parameter

<b>&lt;mode&gt;</b>	Integer type. Disable or enable the use of PSM in the UE. <ul style="list-style-type: none"> <li><u>0</u>    Disable the use of PSM</li> <li>1    Enable the use of PSM</li> <li>2    Disable the use of PSM and discard all parameters for PSM or, if available, reset to the manufacturer specific default values.</li> </ul>																
<b>&lt;Requested_Periodic-RAU&gt;</b>	String type. One byte in an 8 bit format. Requested extended periodic RAU value (T3312) to be allocated to the UE in GERAN. (e.g. "01000111" equals to 70 hours) Bits 5 to 1 represent the binary coded timer value Bits 6 to 8 define the timer value unit as follows: <table border="0" style="margin-left: 20px;"> <tr> <td>Bits</td> <td></td> </tr> <tr> <td>8 7 6</td> <td></td> </tr> <tr> <td>0 0 0</td> <td>value is incremented in multiples of 10 minutes</td> </tr> <tr> <td>0 0 1</td> <td>value is incremented in multiples of 1 hour</td> </tr> <tr> <td>0 1 0</td> <td>value is incremented in multiples of 10 hours</td> </tr> <tr> <td>0 1 1</td> <td>value is incremented in multiples of 2 seconds</td> </tr> <tr> <td>1 0 0</td> <td>value is incremented in multiples of 30 seconds</td> </tr> <tr> <td>1 0 1</td> <td>value is incremented in multiples of 1 minute</td> </tr> </table>	Bits		8 7 6		0 0 0	value is incremented in multiples of 10 minutes	0 0 1	value is incremented in multiples of 1 hour	0 1 0	value is incremented in multiples of 10 hours	0 1 1	value is incremented in multiples of 2 seconds	1 0 0	value is incremented in multiples of 30 seconds	1 0 1	value is incremented in multiples of 1 minute
Bits																	
8 7 6																	
0 0 0	value is incremented in multiples of 10 minutes																
0 0 1	value is incremented in multiples of 1 hour																
0 1 0	value is incremented in multiples of 10 hours																
0 1 1	value is incremented in multiples of 2 seconds																
1 0 0	value is incremented in multiples of 30 seconds																
1 0 1	value is incremented in multiples of 1 minute																
<b>&lt;Requested_GPRS-READY-timer&gt;</b>	String type. One byte in an 8 bit format. Requested GPRS READY timer value (T3314) to be allocated to the UE in GERAN. (e.g. "01001010" equals to 1 hours) Bits 5 to 1 represent the binary coded timer value Bits 6 to 8 define the timer value unit as follows: <table border="0" style="margin-left: 20px;"> <tr> <td>Bits</td> <td></td> </tr> <tr> <td>8 7 6</td> <td></td> </tr> </table>	Bits		8 7 6													
Bits																	
8 7 6																	

0 0 0 value is incremented in multiples of 2 seconds  
 0 0 1 value is incremented in multiples of 1 minute  
 0 1 0 value is incremented in multiples of decihours  
 1 1 1 value indicates that the timer is deactivated.

**<Requested\_Periodic-TAU>** String type. One byte in an 8 bit format. Requested extended periodic TAU value (T3412) to be allocated to the UE in E-UTRAN.  
 (e.g. "00001010" equals to 100 minutes)

Bits 5 to 1 represent the binary coded timer value.

Bits 6 to 8 define the timer value unit as follows:

Bits

8 7 6

0 0 0 value is incremented in multiples of 10 minutes

0 0 1 value is incremented in multiples of 1 hour

0 1 0 value is incremented in multiples of 10 hours

0 1 1 value is incremented in multiples of 2 seconds

1 0 0 value is incremented in multiples of 30 seconds

1 0 1 value is incremented in multiples of 1 minute

**<Requested\_Active-Time>** String type. One byte in an 8 bit format. Requested Active Time value (T3324) to be allocated to the UE.

(e.g. "00001111" equals to 1 minute)

Bits 5 to 1 represent the binary coded timer value.

Bits 6 to 8 define the timer value unit as follows:

Bits

8 7 6

0 0 0 value is incremented in multiples of 2 seconds

0 0 1 value is incremented in multiples of 1 minute

0 1 0 value is incremented in multiples of decihours

1 1 1 value indicates that the timer is deactivated.

### Example

```
AT+CPSMS=1,,"0000100","00001111" //Set the requested T3412 value to 40 minutes, and set the requested T3324 value to 30 seconds.
```

OK

## 6.8. AT+CEDRXS e-I-DRX Setting

The Write Command controls the setting of the UE's e-I-DRX (extended idle mode DRX) parameters.

AT+CEDRXS e-I-DRX Setting	
Test Command <b>AT+CEDRXS=?</b>	Response <b>+CEDRXS:</b> (list of supported <mode>s),(list of supported <AcT-type>s),(list of supported <Requested_eDRX_value>s)  <b>OK</b>
Write Command <b>AT+CEDRXS=[&lt;mode&gt;,[,&lt;AcT-type&gt;[,&lt;Requested_eDRX_value&gt;]]]</b>	Response <b>OK</b> <b>ERROR</b>
Read Command <b>AT+CEDRXS?</b>	Response <b>[+CEDRXS: &lt;AcT-type&gt;,&lt;Requested_eDRX_value&gt;</b> <b>[+CEDRXS: &lt;AcT-type&gt;,&lt;Requested_eDRX_value&gt;</b> <b>[...]]]</b>  <b>OK</b>
Maximum Response Time	300ms
Reference	3GPP TS 27.007

### Parameter

<b>&lt;mode&gt;</b>	Integer type. Disable or enable the use of e-I-DRX in the UE. 0 Disable the use of e-I-DRX 1 Enable the use of e-I-DRX 2 Enable the use of e-I-DRX and enable the unsolicited result code <b>+CEDRXP:</b> <b>&lt;AcT-type&gt;[,&lt;Requested_eDRX_value&gt;[,&lt;NW-provided_eDRX_value&gt;[,&lt;Paging_time_window&gt;]]]</b> 3 Disable the use of e-I-DRX and discard all parameters for e-I-DRX or, if available, reset to the manufacturer specific default values.
<b>&lt;AcT-type&gt;</b>	Integer type. The type of access technology. 0 Access technology is not using e-I-DRX. This parameter value is only used in the unsolicited result code. 1 LTE Cat.M1 2 GSM 3 UTRAN 4 LTE

5 LTE Cat.NB1

**<Requested\_eDRX\_value>**

String type. Half a byte in a 4 bit format.

bit

4	3	2	1	E-UTRAN e-I-DRX cycle length duration
0	0	0	0	5.12 seconds
0	0	0	1	10.24 seconds
0	0	1	0	20.48 seconds
0	0	1	1	40.96 seconds
0	1	0	0	61.44 seconds
0	1	0	1	81.92 seconds
0	1	1	0	102.4 seconds
0	1	1	1	122.88 seconds
1	0	0	0	143.36 seconds
1	0	0	1	163.84 seconds
1	0	1	0	327.68 seconds
1	0	1	1	655.36 seconds
1	1	0	0	1310.72 seconds
1	1	0	1	2621.44 seconds
1	1	1	0	5242.88 seconds
1	1	1	1	10485.76 seconds

**<NW-provided\_eDRX\_value>**

String type. Half a byte in a 4 bit format.

bit

4	3	2	1	E-UTRAN e-I-DRX cycle length duration
0	0	0	0	5.12 seconds
0	0	0	1	10.24 seconds
0	0	1	0	20.48 seconds
0	0	1	1	40.96 seconds
0	1	0	0	61.44 seconds
0	1	0	1	81.92 seconds
0	1	1	0	102.4 seconds
0	1	1	1	122.88 seconds
1	0	0	0	143.36 seconds
1	0	0	1	163.84 seconds
1	0	1	0	327.68 seconds
1	0	1	1	655.36 seconds
1	1	0	0	1310.72 seconds
1	1	0	1	2621.44 seconds
1	1	1	0	5242.88 seconds
1	1	1	1	10485.76 seconds

**<Paging\_time\_window>**

String type. Half a byte in a 4 bit format.

LTE Cat.M1 mode

bit

4	3	2	1	Paging Time Window length
0	0	0	0	1.28 seconds

---

0	0	0	1	2.56 seconds
0	0	1	0	3.84 seconds
0	0	1	1	5.12 seconds
0	1	0	0	6.4 seconds
0	1	0	1	7.68 seconds
0	1	1	0	8.96 seconds
0	1	1	1	10.24 seconds
1	0	0	0	11.52 seconds
1	0	0	1	12.8 seconds
1	0	1	0	14.08 seconds
1	0	1	1	15.36 seconds
1	1	0	0	16.64 seconds
1	1	0	1	17.92 seconds
1	1	1	0	19.20 seconds
1	1	1	1	20.48 seconds

LTE Cat.NB1 mode

bit

4	3	2	1	Paging Time Window length
0	0	0	0	2.56 seconds
0	0	0	1	5.12 seconds
0	0	1	0	7.68 seconds
0	0	1	1	10.24 seconds
0	1	0	0	12.8 seconds
0	1	0	1	15.36 seconds
0	1	1	0	17.92 seconds
0	1	1	1	20.48 seconds
1	0	0	0	23.04 seconds
1	0	0	1	25.6 seconds
1	0	1	0	28.16 seconds
1	0	1	1	30.72 seconds
1	1	0	0	33.28 seconds
1	1	0	1	35.84 seconds
1	1	1	0	38.4 seconds
1	1	1	1	40.96 seconds

---

**Example**

```
AT+CEDRX=1,5,"0000" //Set the requested e-I-DRX value to 5.12 seconds.
```

```
OK
```

**NOTE**

<AcT-type>=3 or 4 is invalid in this command for BG96.

## 6.9. AT+CEDRXRDP Read Dynamic Parameters

The Execution Command returns <AcT-type>, <Requested\_eDRX\_value>, <NW-provided\_eDRX\_value> and <Paging\_time\_window> if e-I-DRX is used for the cell that the MS is currently registered to.

### AT+CEDRXRDP Read Dynamic Parameters

Test Command <b>AT+CEDRXRDP=?</b>	Response  <b>OK</b>
Execution Command <b>AT+CEDRXRDP</b>	Response <b>+CEDRXRDP:</b> <AcT-type>[,<Requested_eDRX_value>[,<NW-provided_eDRX_value>[,<Paging_time_window>]]]
Maximum Response Time	300ms
Reference 3GPP TS 27.007	

### Parameter

<b>&lt;AcT-type&gt;</b>	Integer type. The type of access technology.			
0	Access technology is not using e-I-DRX. This parameter value is only used in the unsolicited result code.			
1	LTE Cat.M1			
2	GSM			
3	UTRAN			
4	LTE			
5	LTE Cat.NB1			
<b>&lt;Requested_eDRX_value&gt;</b>	String type. Half a byte in a 4 bit format.			
	bit			
4	3	2	1	E-UTRAN e-I-DRX cycle length duration
0	0	0	0	5.12 seconds
0	0	0	1	10.24 seconds
0	0	1	0	20.48 seconds

---

0	0	1	1	40.96 seconds
0	1	0	0	61.44 seconds
0	1	0	1	81.92 seconds
0	1	1	0	102.4 seconds
0	1	1	1	122.88 seconds
1	0	0	0	143.36 seconds
1	0	0	1	163.84 seconds
1	0	1	0	327.68 seconds
1	0	1	1	655.36 seconds
1	1	0	0	1310.72 seconds
1	1	0	1	2621.44 seconds
1	1	1	0	5242.88 seconds
1	1	1	1	10485.76 seconds

**<NW-provided\_eDRX\_value>** String type. Half a byte in a 4 bit format.

bit

4	3	2	1	E-UTRAN e-I-DRX cycle length duration
0	0	0	0	5.12 seconds
0	0	0	1	10.24 seconds
0	0	1	0	20.48 seconds
0	0	1	1	40.96 seconds
0	1	0	0	61.44 seconds
0	1	0	1	81.92 seconds
0	1	1	0	102.4 seconds
0	1	1	1	122.88 seconds
1	0	0	0	143.36 seconds
1	0	0	1	163.84 seconds
1	0	1	0	327.68 seconds
1	0	1	1	655.36 seconds
1	1	0	0	1310.72 seconds
1	1	0	1	2621.44 seconds
1	1	1	0	5242.88 seconds
1	1	1	1	10485.76 seconds

**<Paging\_time\_window>** String type. Half a byte in a 4 bit format.

LTE Cat.M1 mode

bit

4	3	2	1	Paging Time Window length
0	0	0	0	1.28 seconds
0	0	0	1	2.56 seconds
0	0	1	0	3.84 seconds
0	0	1	1	5.12 seconds
0	1	0	0	6.4 seconds
0	1	0	1	7.68 seconds
0	1	1	0	8.96 seconds
0	1	1	1	10.24 seconds

---

1	0	0	0	11.52 seconds
1	0	0	1	12.8 seconds
1	0	1	0	14.08 seconds
1	0	1	1	15.36 seconds
1	1	0	0	16.64 seconds
1	1	0	1	17.92 seconds
1	1	1	0	19.20 seconds
1	1	1	1	20.48 seconds
LTE Cat.NB1 mode				
bit				
4	3	2	1	Paging Time Window length
0	0	0	0	2.56 seconds
0	0	0	1	5.12 seconds
0	0	1	0	7.68 seconds
0	0	1	1	10.24 seconds
0	1	0	0	12.8 seconds
0	1	0	1	15.36 seconds
0	1	1	0	17.92 seconds
0	1	1	1	20.48 seconds
1	0	0	0	23.04 seconds
1	0	0	1	25.6 seconds
1	0	1	0	28.16 seconds
1	0	1	1	30.72 seconds
1	1	0	0	33.28 seconds
1	1	0	1	35.84 seconds
1	1	1	0	38.4 seconds
1	1	1	1	40.96 seconds

**NOTE**

<AcT-type>=3 or 4 is invalid in **AT+CEDRXS** command, so it will not be responded in this command for BG96.

### 6.10. AT+CTZR Time Zone Reporting

The command controls the time zone reporting of changed event. If reporting is enabled, the MT returns the unsolicited result code **+CTZV: <tz>** or **+CTZE: <tz>,<dst>,<time>** whenever the time zone is changed. The configuration is stored to NV automatically.

## AT+CTZR Time Zone Reporting

Test Command <b>AT+CTZR=?</b>	Response <b>+CTZR: (0-2)</b>  <b>OK</b>
Write Command <b>AT+CTZR=&lt;reporting&gt;</b>	Response <b>OK</b> <b>ERROR</b>
Read Command <b>AT+CTZR?</b>	Response <b>+CTZR: &lt;reporting&gt;</b>  <b>OK</b>
Maximum Response Time	300ms
Reference 3GPP TS 27.007	

### Parameter

<b>&lt;reporting&gt;</b>	Integer type. Indicates the mode of time zone reporting. <ul style="list-style-type: none"> <li>0 Disable time zone reporting of changed event</li> <li>1 Enable time zone reporting of changed event by unsolicited result code: <b>+CTZV: &lt;tz&gt;</b></li> <li>2 Enable extended time zone reporting of changed event by unsolicited result code: <b>+CTZE: &lt;tz&gt;,&lt;dst&gt;,&lt;time&gt;</b></li> </ul>
<b>&lt;tz&gt;</b>	String type. Represents the sum of the local time zone (difference between the local time and GMT is expressed in quarters of an hour) plus daylight saving time. The format is “±zz”, expressed as a fixed width, two digit integer within the range -48 ... +56. To maintain a fixed width, numbers in the range -9 ... +9 are expressed with a leading zero, e.g. “-09”, “+00” and “+09”.
<b>&lt;dst&gt;</b>	Integer type. Indicates whether <b>&lt;tz&gt;</b> includes daylight savings adjustment. <ul style="list-style-type: none"> <li>0 <b>&lt;tz&gt;</b> includes no adjustment for daylight saving time</li> <li>1 <b>&lt;tz&gt;</b> includes +1 hour (equals 4 quarters in <b>&lt;tz&gt;</b>) adjustment for daylight saving time</li> <li>2 <b>&lt;tz&gt;</b> includes +2 hours (equals 8 quarters in <b>&lt;tz&gt;</b>) adjustment for daylight saving time</li> </ul>
<b>&lt;time&gt;</b>	String type. Represents the local time. The format is “YYYY/MM/DD,hh:mm:ss”, expressed as integers representing year (YYYY), month (MM), date (DD), hour (hh), minute (mm) and second (ss). This parameter can be provided by the network when delivering time zone information and will be presented in the unsolicited result code of extended time zone reporting if provided by the network.

### Example

```

AT+CTZR=2
OK
AT+CTZR?
+CTZR: 2

OK

+CTZE: "+32",0,"2013/08/23,06:51:13" //<reporting> is 2
    
```

## 6.11. AT+QLTS Obtain the Latest Time Synchronized Through Network

The command is used to obtain the latest time synchronized through network.

### AT+QLTS Obtain the Latest Time Synchronized Through Network

Test Command <b>AT+QLTS=?</b>	Response <b>+QLTS:</b> list of supported <b>&lt;mode&gt;</b> s <b>OK</b>
Execution Command <b>AT+QLTS</b>	Response The Execution Command returns the latest time that has been synchronized through network: <b>+QLTS: &lt;time&gt;,&lt;ds&gt;</b>  <b>OK</b>
Write Command <b>AT+QLTS=&lt;mode&gt;</b>	Response <b>+QLTS: &lt;time&gt;,&lt;dst&gt;</b>  <b>OK</b> <b>ERROR</b>  If there is an error related to ME functionality <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms

### Parameter

<b>&lt;mode&gt;</b>	Query network time mode
0	Query the latest time that has been synchronized through network
1	Query the current GMT time calculated from the latest time that has been synchronized through network

	2	Query the current LOCAL time calculated from the latest time that has been synchronized through network
<time>		String type value. Format is "yy/MM/dd,hh:mm:ss±zz", where characters indicate year (last two digits), month, day, hour, minutes, seconds and time zone (indicates the difference, expressed in quarters of an hour, between the local time and GMT; range -48...+48). E.g. 6th of May 2004, 22:10:00 GMT+2 hours equals to "04/05/06,22:10:00+08"
<ds>		Daylight saving time.

**NOTE**

If the time has not been synchronized through network, the command will return a null time string: **+QLTS:**  
""

**Example**

```

AT+QLTS=?           //Query supported network time modes.
+QLTS: (0-2)

OK
AT+QLTS             //Query the latest time synchronized through network.
+QLTS: "2017/01/13,03:40:48+32,0"
OK
AT+QLTS=0           //Query the latest time synchronized through network. It offers the same
                    //function as Execution Command AT+QLTS.
+QLTS: "2017/01/13,03:40:48+32,0"

OK
AT+QLTS=1           //Query the current GMT time calculated from the latest time that has been
                    //synchronized through network.
+QLTS: "2017/01/13,03:41:22+32,0"

OK
AT+QLTS=2           //Query the current LOCAL time calculated from the latest time that has been
                    //synchronized through network
+QLTS: "2017/01/13,11:41:23+32,0"

OK

```

## 6.12. AT+QNWINFO Query Network Information

The command indicates network information such as the access technology selected, the operator, and the band selected.

### AT+QNWINFO Query Network Information

Test Command <b>AT+QNWINFO=?</b>	Response <b>OK</b>
Execution Command <b>AT+QNWINFO</b>	Response <b>+QNWINFO: &lt;Act&gt;,&lt;oper&gt;,&lt;band&gt;,&lt;channel&gt;</b>  <b>OK</b>
Maximum Response Time	300ms

#### Parameter

<b>&lt;Act&gt;</b>	String type. Access technology selected. "NONE" "GSM" "GPRS" "EDGE" "Cat-M1" "Cat-NB1"
<b>&lt;oper&gt;</b>	String type. Operator in numeric format.
<b>&lt;band&gt;</b>	String type. Band selected. "GSM 850" "GSM 900" "GSM 1800" "GSM 1900" "LTE BAND 1" – "LTE BAND 43"
<b>&lt;channel&gt;</b>	Integer type. Channel ID.

#### Example

```
AT+QNWINFO=?
OK
AT+QNWINFO
+QNWINFO: "EDGE","46001","GSM 1800",653
OK
```

### 6.13. AT+QSPN\* Display the Name of Registered Network

#### AT+QSPN\* Display the Name of Registered Network

Test Command <b>AT+QSPN=?</b>	Response  <b>OK</b>
Execution Command <b>AT+QSPN</b>	Response <b>+QSPN: &lt;FNN&gt;,&lt;SNN&gt;,&lt;SPN&gt;,&lt;alphabet&gt;,&lt;RPLMN&gt;</b>  <b>OK</b>
Reference	

#### Parameter

<b>&lt;SPN&gt;</b>	Service provider name
<b>&lt;alphabet&gt;</b>	Alphabet of full network name and short network name 0 GSM 7 bit default alphabet 1 UCS2
<b>&lt;RPLMN&gt;</b>	Registered PLMN
<b>&lt;FNN&gt;</b>	Full network name
<b>&lt;SNN&gt;</b>	Short network name

#### NOTES

1. If **<alphabet>** is 0, **<FNN>** and **<SNN>** will be shown in GSM 7 bit default alphabet string.
2. If **<alphabet>** is 1, **<FNN>** and **<SNN>** will be shown in UCS2 hexadecimal string.

#### Example

```
AT+QSPN //Query the EONS information of RPLMN
+QSPN: "CHN-UNICOM","UNICOM","",0,"46001"
OK
```

# 7 Call Related Commands

## 7.1. ATA Answer an Incoming Call

The command connects the module to an incoming voice or data call indicated by a **RING** URC.

### ATA Answer an Incoming Call

Execution Command <b>ATA</b>	<p>Response</p> <p>TA sends off-hook to the remote station.</p> <p>Response in case of data call, if successfully connected: <b>CONNECT&lt;text&gt;</b></p> <p>And TA switches to data mode.</p> <p>Note: <b>&lt;text&gt;</b> outputs only when <b>&lt;value&gt;</b> is greater than 0 in <b>ATX &lt;value&gt;</b> parameter setting.</p> <p>When TA returns to command mode after call release: <b>OK</b></p> <p>Response in case of voice call, if successfully connected: <b>OK</b></p> <p>Response if no connection: <b>NO CARRIER</b></p>
Maximum Response Time	90s, determined by network.
Reference V.25ter	

#### NOTES

1. Any additional commands on the same command line are ignored.
2. This command may be aborted generally by receiving a character during execution. The aborting is not possible during some states of connection establishment such as handshaking.
3. See also **ATX**.

## Example

```

RING //A voice call is ringing
AT+CLCC
+CLCC: 1,0,0,1,0,"",128 //PS call in LTE mode
+CLCC: 2,1,4,0,0,"02154450290",129 //Incoming call

OK
ATA //Accept the voice call with ATA
OK
    
```

## 7.2. ATD Mobile Originated Call to Dial a Number

The command can be used to set up outgoing voice and data calls. Supplementary services can also be controlled with this command.

### ATD Mobile Originated Call to Dial a Number

Execution Command  
ATD<n>[<mgsms>][:]

#### Response

This command can be used to set up outgoing voice, data or FAX calls. It also serves to control supplementary services.

If no dial tone and (parameter setting **ATX2** or **ATX4**):

**NO DIALTONE**

If busy and (parameter setting **ATX3** or **ATX4**):

**BUSY**

If a connection cannot be established:

**NO CARRIER**

If connection is successful and non-voice call:

**CONNECT<text>**

And TA switches to data mode.

<text> outputs only when <value> is greater than 0 in **ATX<value>** parameter setting.

When TA returns to command mode after call release:

**OK**

If connection is successful and voice call:

**OK**

Maximum Response Time

5s, determined by network (**AT+COLP=0**).

Reference  
V.25ter

## Parameter

<b>&lt;n&gt;</b>	String of dialing digits and optionally V.25ter modifiers Dialing digits: <b>0-9, *, #, +, A, B, C</b> Following V.25ter modifiers are ignored: ,(comma), <b>T, P, !, W, @</b>
<b>&lt;mgsms&gt;</b>	String of GSM modifiers: <b>I</b> Activates <b>CLIR</b> (Disable presentation of own number to called party) <b>i</b> Deactivates <b>CLIR</b> (Enable presentation of own number to called party) <b>G</b> Activates closed user group invocation for this call only <b>g</b> Deactivates closed user group invocation for this call only
<b>&lt;;&gt;</b>	Only required to set up voice call, return to command state

## NOTES

- This command may be aborted generally by receiving an **ATH** command or a character during execution. The aborting is not possible during some states of connection establishment such as handshaking.
- Parameters "I" and "i" can be omitted only when there is no "\*" or "#" code within the dial string.
- See **ATX** command for setting result code and call monitoring parameters.
- Responses returned after dialing with **ATD**:  
For voice call, two different responses mode can be determined. TA returns **OK** immediately either after dialing was completed or after the call was established. The setting is controlled by **AT+COLP**. Factory default is **AT+COLP=0**, which causes the TA to return **OK** immediately after dialing was completed. Otherwise TA will return **OK, BUSY, NO DIAL TONE, or NO CARRIER**.
- Using **ATD** during an active voice call:
  - When a user originates a second voice call while there is already an active voice call, the first call will be automatically put on hold.
  - The current states of all calls can be easily checked at any time by using **AT+CLCC** command.

## Example

```
ATD10086; //Dialing out the party's number
OK
```

### 7.3. ATH Disconnect Existing Connection

The command disconnects circuit switched data calls or voice calls. **AT+CHUP** is also used to disconnect the voice call.

#### ATH Disconnect Existing Connection

Execution Command <b>ATH[n]</b>	Response Disconnect existing call by local TE from command line and terminate the call. <b>OK</b>
Maximum Response Time	90s, determined by network.
Reference V.25ter	

#### Parameter

<n>	0	Disconnect existing call from command line and terminate the call.
-----	---	--

### 7.4. AT+CVHU\* Voice Hang up Control

The command controls whether **ATH** can be used to disconnect the voice call.

#### AT+CVHU\* Voice Hang up Control

Test Command <b>AT+CVHU=?</b>	Response <b>+CVHU: (list of supported&lt;mode&gt;s)</b>  <b>OK</b>
Read Command <b>AT+CVHU?</b>	Response <b>+CVHU: &lt;mode&gt;</b>  <b>OK</b>
Write Command <b>AT+CVHU=&lt;mode&gt;</b>	Response <b>OK</b> <b>ERROR</b>
Maximum Response Time	300ms
Reference 3GPP TS 27.007	

## Parameter

<b>&lt;mode&gt;</b>	<u>0</u>	<b>ATH</b> can be used to disconnect the voice call.
	1	<b>ATH</b> is ignored but <b>OK</b> response is returned.

## 7.5. AT+CHUP\* Hang up the Call

The command cancels all voice calls in the state of Active, Waiting and Held. For data connections, use **ATH**.

### AT+CHUP\* Hang up the Call

Test Command <b>AT+CHUP=?</b>	Response <b>OK</b>
Execution Command <b>AT+CHUP</b>	Response <b>OK</b> <b>ERROR</b>
Maximum Response Time	90s, determined by network.
Reference 3GPP 27.007	

### Example

```
RING //Incoming a call
AT+CHUP //Hang up the call
OK
```

## 7.6. +++ Switch from Data Mode to Command Mode

The **+++** character sequence causes the module to switch from data mode to AT command mode. It allows inputting AT commands while maintaining the data connection with the remote device.

### +++ Switch from Data Mode to Command Mode

Execution Command <b>+++</b>	Response This command is only available when TA is in data mode. The <b>+++</b> character sequence causes the TA to cancel the data flow over the AT interface and switch to command mode. This allows you to enter AT command while maintaining the data connection with the remote server or, accordingly, the GPRS
---------------------------------	--

	connection.
	<b>OK</b>
Maximum Response Time	300ms
Reference V.25ter	

## NOTES

- To prevent the **+++** escape sequence from being misinterpreted as data, the following sequence should be followed:
  - Do not input any character within 1s before inputting **+++**.
  - Input **+++** within 1s, and no other characters can be inputted during the time.
  - Do not input any character within 1s after **+++** has been inputted.
  - Switch to command mode; otherwise return to step 1.
- To return back to data mode from command mode, please enter **ATO**. Another way to change to command mode is through DTR, and please refer to **AT&D** command for details.

## 7.7. ATO Switch from Command Mode to Data Mode

The command resumes the connection and switches back to data mode from command mode.

### ATO Switch from Command Mode to Data Mode

Execution Command <b>ATO[n]</b>	Response TA resumes the connection and switches back to data mode from command mode. If connection is not successfully resumed: <b>NO CARRIER</b>  If connection is successfully resumed, TA returns to data mode from command mode: <b>CONNECT &lt;text&gt;</b>
Maximum Response Time	300ms
Reference V.25ter	

### Parameter

<n>	0	Switch from command mode to data mode
-----	---	---------------------------------------

**NOTE**

When TA returns to data mode from command mode successfully, **CONNECT <text>** is returned. Please note that <text> outputs only when <value> is greater than 0 in **ATX<value>** parameter setting.

## 7.8. ATSO Set Number of Rings before Automatically Answering Call

The command controls automatic answering mode for the incoming calls.

### ATSO Set Number of Rings before Automatically Answering Call

Read Command <b>ATSO?</b>	Response <n>  OK
Write Command <b>ATSO=&lt;n&gt;</b>	Response This parameter setting determines the number of rings before auto-answer. OK
Maximum Response Time	300ms
Reference V.25ter	

#### Parameter

<n>	0	Automatic answering is disabled
	1-255	Enable automatic answering on the ring number specified

**NOTE**

If <n> is set too high, the calling party may hang up before the call is answered automatically.

#### Example

```

ATSO=3 //Set three rings before automatically answering a call
OK

RING //A call is incoming

RING
    
```

**RING**

//Automatically answering the call after three rings

## 7.9. ATS6 Set Pause before Blind Dialing

The command is implemented for compatibility reasons only, and has no effect.

### ATS6 Set Pause before Blind Dialing

Read Command  
**ATS6?**

Response  
<n>

**OK**

Write Command  
**ATS6=<n>**

Response  
**OK**

Maximum Response Time

300ms

Reference  
V.25ter

#### Parameter

<n> 0-2-10 Number of seconds to wait before blind dialing

## 7.10. ATS7 Set the Time to Wait for Connection Completion

The command specifies the amount of time (unit: second) to wait for the connection completion in case of answering or originating a call. If no connection is established during the time, the module disconnects from the line.

### ATS7 Set the Time to Wait for Connection Completion

Read Command  
**ATS7?**

Response  
<n>

**OK**

Write Command  
**ATS7=<n>**

Response  
This parameter setting determines the amount of time (unit: second) to wait for the connection completion in case of answering or originating a call.

	OK
Maximum Response Time	300ms
Reference V.25ter	

### Parameter

<n>	0	Disabled
	1-255	Number of seconds to wait for connection completion

## 7.11. AT\$8 Set the Time to Wait for Comma Dial Modifier

The command is implemented for compatibility reasons only, and has no effect.

### AT\$8 Set the Time to Wait for Comma Dial Modifier

Read Command AT\$8?	Response <n>  OK
Write Command AT\$8=<n>	Response OK
Maximum Response Time	300ms
Reference V.25ter	

### Parameter

<n>	0	No pause when comma encountered in dial string
	1-2-255	Number of seconds to wait

## 7.12. AT\$10 Set Disconnection Delay after Indicating the Absence of Data Carrier

The command determines the amount of time (unit: tenths of a second) during which the UE remains connected in absence of a data carrier.

### ATS10 Set Disconnection Delay after Indicating the Absence of Data Carrier

Read Command <b>ATS10?</b>	Response <n>  <b>OK</b>
Write Command <b>ATS10=&lt;n&gt;</b>	Response This parameter setting determines the amount of time (unit: tenths of a second) during which the TA remains connected in absence of a data carrier. If the data carrier is once more detected before disconnection, the TA remains connected. <b>OK</b>
Maximum Response Time	300ms
Reference V.25ter	

#### Parameter

<n>	1-15-254	Number of tenths of a second to wait before disconnecting after UE has indicated the absence of received line signal
-----	----------	--

### 7.13. AT+CSTA\* Select Type of Address

The Write Command selects the type of number for further dialing commands **ATD** according to *3GPP Specifications*. The Test Command returns values supported a compound value.

#### AT+CSTA\* Select Type of Address

Test Command <b>AT+CSTA=?</b>	Response <b>+CSTA:</b> (list of supported <type>s)  <b>OK</b>
Read Command <b>AT+CSTA?</b>	Response <b>+CSTA:</b> <type>  <b>OK</b>
Write Command <b>AT+CSTA=&lt;type&gt;</b>	Response <b>OK</b>
Maximum Response Time	300ms
Reference 3GPP TS 27.007	

## Parameter

<b>&lt;type&gt;</b>	Current address type setting.
129	Unknown type
145	International type (contains the character "+")

## 7.14. AT+CLCC\* List Current Calls of ME

The Execution Command returns the list of all current calls. If the command is executed successfully, but no calls existed, then only **OK** is sent to TE.

### AT+CLCC\* List Current Calls of ME

Test Command <b>AT+CLCC=?</b>	Response <b>OK</b>
Execution Command <b>AT+CLCC</b>	<p>Response</p> <p>TA returns a list of current calls of ME. If the command is executed successfully, but no calls are existed, then only <b>OK</b> is sent to TE.</p> <p><b>[+CLCC :</b>  <b>&lt;id1&gt;,&lt;dir&gt;,&lt;stat&gt;,&lt;mode&gt;,&lt;mpty&gt;[,&lt;number&gt;,&lt;type&gt;[,&lt;alpha&gt;]]</b>  <b>[+CLCC:</b>  <b>&lt;id2&gt;,&lt;dir&gt;,&lt;stat&gt;,&lt;mode&gt;,&lt;mpty&gt;[,&lt;number&gt;,&lt;type&gt;[,&lt;alpha&gt;]]</b>  <b>[...]</b></p> <p><b>OK</b></p> <p>If there is an error related to ME functionality:  <b>+CME ERROR: &lt;err&gt;</b></p>
Maximum Response Time	300ms

## Parameter

<b>&lt;idx&gt;</b>	Integer type. Call identification number as described in <i>3GPP TS 22.030 sub clause 4.5.5.1</i> . This number can be used in <b>AT+CHLD</b> command operations
<b>&lt;dir&gt;</b>	0 Mobile originated (MO) call 1 Mobile terminated (MT) call
<b>&lt;stat&gt;</b>	State of the call 0 Active

	1	Held
	2	Dialing (MO call)
	3	Alerting (MO call)
	4	Incoming (MT call)
	5	Waiting (MT call)
<b>&lt;mode&gt;</b>	Bearer/tele service	
	0	Voice
	1	Data
	2	FAX
<b>&lt;empty&gt;</b>	0	Call is not one of the multiparty (conference) call parties
	1	Call is one of the multiparty (conference) call parties
<b>&lt;number&gt;</b>	Phone number in string type in format specified by <b>&lt;type&gt;</b>	
<b>&lt;type&gt;</b>	Type of address of octet in integer format (Refer to 3GPP TS 24.008 subclause 10.5.4.7 for details). Usually, it has three kinds of values:	
	129	Unknown type
	145	International type (contains the character "+")
	161	National type
<b>&lt;alpha&gt;</b>	Alphanumeric representation of <b>&lt;number&gt;</b> corresponding to the entry found in phonebook.	

### Example

```

ATD10086; //Establish a call
OK
AT+CLCC
+CLCC: 1,0,0,1,0,"",128 //PS call in LTE mode
+CLCC: 2,0,0,0,0,"10086",129 //Establish a call, and the call has been answered
OK

```

## 7.15. AT+CR\* Service Reporting Control

The command controls the module whether or not to transmit an intermediate result code **+CR: <serv>** to the TE when a call is being set up.

If it is enabled, an intermediate result code is transmitted at the point during connect negotiation at which the TA has determined which speed and quality of service will be used, before any error control or data compression reports are transmitted, and before any final result code (e.g. **CONNECT**) is transmitted.

### AT+CR\* Service Reporting Control

Test Command	Response
AT+CR=?	+CR: (list of supported <mode>s)

	OK
Read Command <b>AT+CR?</b>	Response <b>+CR: &lt;mode&gt;</b>
	OK
Write Command <b>AT+CR=[&lt;mode&gt;]</b>	Response TA controls whether or not the intermediate result code <b>+CR: &lt;serv&gt;</b> is returned from the TA to the TE when a call is set up. OK
Maximum Response Time	300ms
Reference 3GPP TS 27.007	

### Parameter

<b>&lt;mode&gt;</b>	0	Disable
	1	Enable
<b>&lt;serv&gt;</b>	ASYNC	Asynchronous transparent
	SYNC	Synchronous transparent
	REL ASYNC	Asynchronous non-transparent
	REL SYNC	Synchronous non-transparent
	GPRS	GPRS

## 7.16. AT+CRG Set Cellular Result Codes for Incoming Call Indication

The command controls whether or not to use the extended format of incoming call indication. When it is enabled, an incoming call is indicated to the TE with unsolicited result code **+CRING: <type>** instead of the normal **RING**.

### AT+CRG Set Cellular Result Codes for Incoming Call Indication

Test Command <b>AT+CRG=?</b>	Response <b>+CRG: (list of supported &lt;mode&gt;s)</b>
	OK
Read Command <b>AT+CRG?</b>	Response <b>+CRG: &lt;mode&gt;</b>
	OK
Write Command <b>AT+CRG=[&lt;mode&gt;]</b>	Response TA controls whether or not the extended format of incoming

	call indication is used. <b>OK</b>
Maximum Response Time	300ms
Reference	
3GPP TS 27.007	

### Parameter

<b>&lt;mode&gt;</b>	<u>0</u>	Disable extended format
	1	Enable extended format
<b>&lt;type&gt;</b>	ASYNC	Asynchronous transparent
	SYNC	Synchronous transparent
	REL ASYNC	Asynchronous non-transparent
	REL SYNC	Synchronous non-transparent
	FAX	Facsimile
	VOICE	Voice

### Example

```

AT+CRC=1 //Enable extended format
OK
+CRING: VOICE //Indicate incoming call to the TE
ATH
OK
AT+CRC=0 //Disable extended format
OK
RING //Indicate incoming call to the TE
ATH
OK
    
```

## 7.17. AT+CRLP\* Select Radio Link Protocol Parameter

The Write Command sets radio link protocol (RLP) parameters used when non-transparent data calls are originated.

### AT+CRLP\* Select Radio Link Protocol Parameter

Test Command	Response
AT+CRLP=?	TA returns values supported. RLP (Radio Link Protocol)

	<p>versions 0 and 1 share the same parameter set. TA returns only one line for this set (where <b>&lt;ver&gt;</b> is not presented).</p> <p><b>+CRLP:</b> (list of supported <b>&lt;iws&gt;</b>s),(list of supported <b>&lt;mws&gt;</b>s),(list of supported <b>&lt;T1&gt;</b>s),(list of supported <b>&lt;N2&gt;</b>s), <b>&lt;ver&gt;</b></p> <p><b>+CRLP:</b> (list of supported <b>&lt;iws&gt;</b>s),(list of supported <b>&lt;mws&gt;</b>s),(list of supported <b>&lt;T1&gt;</b>s),(list of supported <b>&lt;N2&gt;</b>s), <b>&lt;ver&gt;</b></p> <p><b>+CRLP:</b> (list of supported <b>&lt;iws&gt;</b>s),(list of supported <b>&lt;mws&gt;</b>s),(list of supported <b>&lt;T1&gt;</b>s),(list of supported <b>&lt;N2&gt;</b>s), <b>&lt;ver&gt;</b></p> <p><b>OK</b></p>
<p>Read Command <b>AT+CRLP?</b></p>	<p>Response</p> <p>TA returns current settings for RLP version. RLP versions 0 and 1 share the same parameter set. TA returns only one line for this set (where <b>&lt;ver&gt;</b> is not presented).</p> <p><b>+CRLP: &lt;iws&gt;,&lt;mws&gt;,&lt;T1&gt;,&lt;N2&gt;,&lt;ver&gt;</b> <b>+CRLP: &lt;iws&gt;,&lt;mws&gt;,&lt;T1&gt;,&lt;N2&gt;,&lt;ver&gt;</b> <b>+CRLP: &lt;iws&gt;,&lt;mws&gt;,&lt;T1&gt;,&lt;N2&gt;,&lt;ver&gt;</b></p> <p><b>OK</b></p>
<p>Write Command <b>AT+CRLP=[&lt;iws&gt;,&lt;mws&gt;,&lt;T1&gt;,&lt;N2&gt;,&lt;ver&gt;]</b></p>	<p>Response</p> <p>TA sets radio link protocol (RLP) parameters used when non-transparent data calls are set up.</p> <p><b>OK</b></p>
<p>Maximum Response Time</p>	<p>300ms</p>
<p>Reference 3GPP TS27.007</p>	

### Parameter

<b>&lt;iws&gt;</b>	0- <u>61</u> 0- <u>240</u> -488	Interworking window size (IWF to MS) For <b>&lt;ver&gt;</b> =2
<b>&lt;mws&gt;</b>	0- <u>61</u> 0- <u>240</u> -488	Mobile window size (MS to IWF) For <b>&lt;ver&gt;</b> =2
<b>&lt;T1&gt;</b>	38- <u>48</u> -255 42- <u>52</u> -255	Acknowledgment timer T1 in a unit of 10ms For <b>&lt;ver&gt;</b> =2
<b>&lt;N2&gt;</b>	1- <u>6</u> -255	Retransmission attempts N2
<b>&lt;ver&gt;</b>	0-2	RLP version number in integer format

## 7.18. AT+QECCNUM Configure Emergency Call Numbers

The command can be used to query, add or delete ECC numbers (emergency call numbers). There are two kinds of ECC numbers: ECC numbers without (U)SIM and ECC numbers with (U)SIM. The default ECC numbers without (U)SIM is 911, 112, 00, 08, 110, 999, 118 and 119. The default ECC number with (U)SIM is 911 and 112. 911 and 112 will always be supported as ECC numbers, and cannot be deleted. ECC numbers can be saved into NV automatically. If the (U)SIM card contains ECC File, the numbers in ECC File can also be regarded as ECC numbers.

The maximal supported ECC numbers of each type is 20.

AT+QECCNUM Configure Emergency Call Numbers	
Test Command <b>AT+QECCNUM=?</b>	Response <b>+QECCNUM: (0-2)</b>  <b>OK</b>
Write Command <b>AT+QECCNUM=&lt;mode&gt;,&lt;type&gt;[,&lt;eccnum1&gt;[,&lt;eccnum2&gt;,...[,&lt;eccnumN&gt;]] ]</b>	Response If <b>&lt;mode&gt;</b> is equal to 0, query the ECC numbers. In this case, <b>&lt;eccnumN&gt;</b> should be omitted, and the response is: <b>+QECCNUM: &lt;type&gt;,&lt;eccnum1&gt;,&lt;eccnum2&gt;[...]</b>  <b>OK</b>  If <b>&lt;mode&gt;</b> is not equal to 0: <b>&lt;mode&gt;=1</b> is used to add the ECC number; <b>&lt;mode&gt;=2</b> is used to delete the ECC number. In this case, at least one ECC number <b>&lt;eccnumN&gt;</b> should be inputted, and the response is: <b>OK</b> <b>ERROR</b>
Read Command <b>AT+QECCNUM?</b>	Response <b>+QECCNUM: 0,&lt;eccnum1&gt;,&lt;eccnum2&gt;[...]</b> <b>+QECCNUM: 1,&lt;eccnum1&gt;,&lt;eccnum2&gt;[...]</b>  <b>OK</b>
Maximum Response Time	300ms

### Parameter

<b>&lt;mode&gt;</b>	ECC number operation mode
0	Query ECC numbers
1	Add ECC numbers
2	Delete ECC numbers

<b>&lt;type&gt;</b>	ECC number type 0 ECC numbers without (U)SIM 1 ECC numbers with (U)SIM
<b>&lt;eccnum&gt;</b>	String type. ECC numbers ( e.g.110, 119)

### Example

```

AT+QECCNUM=? //Query the supported ECC number operation mode
+QECCNUM: (0-2)

OK
AT+QECCNUM? //Query the ECC numbers with or without (U)SIM
+QECCNUM: 0,"911","112","00","08","110","999","118","119"
+QECCNUM: 1,"911","112"

OK
AT+QECCNUM=0,1 //Query the ECC numbers with (U)SIM
+QECCNUM: 1,"911","112"

OK
AT+QECCNUM=1,1,"110","234" //Add "110" and "234" into the type of ECC numbers with (U)SIM
OK
AT+QECCNUM=0,1 //Query the ECC numbers with (U)SIM
+QECCNUM: 1,"911","112","110","234"

OK
AT+QECCNUM=2,1,"110" //Delete "110" from the type of ECC numbers with (U)SIM
OK
AT+QECCNUM=0,1 //Query the ECC numbers with (U)SIM
+QECCNUM: 1,"911","112","234"

OK

```

## 7.19. AT+QHUP\* Hang up Call with a Specific Release Cause

The command can terminate a call or calls (including both voice calls and data calls) with a specific 3GPP TS 24.008 release cause specified by the host.

### AT+QHUP\* Hang up Call with a Specific Release Cause

Test Command	Response
AT+QHUP=?	OK

Write Command <b>AT+QHUP=&lt;cause&gt;[,&lt;idx&gt;]</b>	Response <b>OK</b> <b>ERROR</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	90s, determined by network.

## Parameter

<b>&lt;cause&gt;</b>	Release cause, <i>3GPP TS 24.008</i> release cause to be indicated to the network.
1	Release cause "unassigned (unallocated) number"
16	Release cause "normal call clearing"
17	Release cause "user busy"
18	Release cause "no user responding"
21	Release cause "call rejected"
27	Release cause "destination out of order"
31	Release cause "normal, unspecified"
88	Release cause "incompatible destination"
<b>&lt;idx&gt;</b>	Call identification number is an optional index in the list of current calls indicated by <b>AT+CLCC</b> . <b>AT+QHUP</b> will terminate the call identified by the given call number. The default call number 0 is not assigned to any call, but signifies all calls.
0	Terminate all known calls. However, if circuit switches data calls and voice calls at the same time, this command only terminates the CSD calls.
1...7	Terminate the specific call with identification number.

## Example

```

AT+QHUP=?           //Test Command
OK
ATD10010;           //Dial 10010
OK
ATD10086;           //Dial 10086
OK
AT+CLCC             //Query the status of calls
+CLCC: 1,0,1,0,0,"10010",129
+CLCC: 2,0,0,0,0,"10086",129

OK
AT+QHUP=17,1       //Terminate the call of which call ID is 1. Disconnect cause is "user busy"
OK
AT+CLCC             //Query the status of calls

```

```
+CLCC: 1,0,0,0,0,"10086",129
```

```
OK
```

```
AT+QHUP=16
```

```
//Terminate all existed calls. Disconnect cause is "normal call clearing"
```

```
OK
```

```
AT+CLCC
```

```
OK
```

Quectel  
Confidential

# 8 Phonebook Commands\*

All commands in this chapter are still under development.

## 8.1. AT+CNUM Subscriber Number

The command can get the subscribers' own number(s) from the (U)SIM.

AT+CNUM Subscriber Number	
Test Command <b>AT+CNUM=?</b>	Response <b>OK</b>
Execution Command <b>AT+CNUM</b>	Response <b>[+CNUM: [&lt;alpha&gt;, &lt;number&gt;,&lt;type&gt;]</b> <b>[+CNUM: [&lt;alpha&gt;, &lt;number&gt;,&lt;type&gt;]</b>  <b>OK</b> <b>ERROR</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms
Reference 3GPP 27.007	

### Parameter

<b>&lt;alpha&gt;</b>	Optional alphanumeric string associated with <b>&lt;number&gt;</b> . The used character set should be the one selected with <b>AT+CSCS</b> command.
<b>&lt;number&gt;</b>	String type phone number of format specified by <b>&lt;type&gt;</b>
<b>&lt;type&gt;</b>	Type of address of octet in integer format (Refer to <i>3GPP TS 24.008 subclause 10.5.4.7</i> for details). Usually, it has three kinds of values: 129 Unknown type 145 International type (contains the character "+") 161 National type

## 8.2. AT+CPBF Find Phonebook Entries

The command can search the phonebook entries starting with the given **<findtext>** string from the current phonebook memory storage selected with **AT+CPBS**, and return all found entries sorted in alphanumeric order.

### AT+CPBF Find Phonebook Entries

Test Command <b>AT+CPBF=?</b>	Response <b>+CPBF: &lt;nlength&gt;,&lt;tlength&gt;</b>  <b>OK</b>
Write Command <b>AT+CPBF=&lt;findtext&gt;</b>	Response <b>[+CPBF: &lt;index&gt;,&lt;number&gt;,&lt;type&gt;,&lt;text&gt;]</b> <b>[...]</b>  <b>OK</b> <b>ERROR</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	Depends on the storage of phonebook entries.
Reference 3GPP 27.007	

### Parameter

<b>&lt;nlength&gt;</b>	Integer type. Indicates the maximum length of field <b>&lt;number&gt;</b> .
<b>&lt;tlength&gt;</b>	Integer type. Indicates the maximum length of field <b>&lt;text&gt;</b> .
<b>&lt;findtext&gt;</b>	String type. Field of maximum length <b>&lt;tlength&gt;</b> in current TE character set specified by <b>AT+CSCS</b> .
<b>&lt;index&gt;</b>	Integer type. In the range of location numbers of phone book memory.
<b>&lt;type&gt;</b>	Type of address of octet in integer format (Refer to <i>3GPP TS 24.008 subclause 10.5.4.7</i> for details). Usually, it has three kinds of values: 129 Unknown type 145 International type (contains the character "+") 161 National type
<b>&lt;text&gt;</b>	String type. Field of maximum length <b>&lt;tlength&gt;</b> in current TE character set specified by <b>AT+CSCS</b> .

### 8.3. AT+CPBR Read Phonebook Entries

The command can return phonebook entries in location number range **<index1>... <index2>** from the current phonebook memory storage selected with **AT+CPBS**. If **<index2>** is left out, only location **<index1>** is returned.

AT+CPBR Read Phonebook Entries	
Test Command <b>AT+CPBR=?</b>	Response <b>+CPBR:</b> (list of supported <b>&lt;index&gt;</b> s), <b>&lt;nlength&gt;</b> , <b>&lt;tlength&gt;</b>  <b>OK</b>
Write Command <b>AT+CPBR=&lt;index1&gt;[,&lt;index2&gt;]</b>	Response <b>+CPBR:</b> <b>&lt;index1&gt;</b> , <b>&lt;number&gt;</b> , <b>&lt;type&gt;</b> , <b>&lt;text&gt;</b> <b>[+CPBR:</b> <b>&lt;index2&gt;</b> , <b>&lt;number&gt;</b> , <b>&lt;type&gt;</b> , <b>&lt;text&gt;</b> <b>[...]]</b>  <b>OK</b> <b>ERROR</b>  If there is an error related to ME functionality: <b>+CME ERROR:</b> <b>&lt;err&gt;</b>
Maximum Response Time	Depends on the storage of phonebook entries.
Reference 3GPP 27.007	

#### Parameter

<b>&lt;index&gt;</b>	Integer type. In the range of location numbers of phone book memory.
<b>&lt;nlength&gt;</b>	Integer type. Indicates the maximum length of field <b>&lt;number&gt;</b> .
<b>&lt;tlength&gt;</b>	Integer type. Indicates the maximum length of field <b>&lt;text&gt;</b> .
<b>&lt;index1&gt;</b>	The first phone book record to read.
<b>&lt;index2&gt;</b>	The last phonebook record to read.
<b>&lt;type&gt;</b>	Type of address of octet in integer format (Refer to <i>3GPP TS 24.008 subclause 10.5.4.7</i> for details). Usually, it has three kinds of values: 129 Unknown type 145 International type(contains the character "+") 161 National type
<b>&lt;text&gt;</b>	String type. Field of maximum length <b>&lt;tlength&gt;</b> in current TE character set specified by <b>AT+CSCS</b> .

## 8.4. AT+CPBS Select Phonebook Memory Storage

The command selects phonebook memory storage, which is used by other phonebook commands. The Read Command returns currently selected memory, the number of used locations and the total number of locations in the memory when supported by the manufacturer. The Test Command returns supported storages as compound value.

### AT+CPBS Select Phonebook Memory Storage

Test Command <b>AT+CPBS=?</b>	Response <b>+CPBS:</b> (list of supported <storage>s)  <b>OK</b> <b>ERROR</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Read Command <b>AT+CPBS?</b>	Response <b>+CPBS:</b> <storage>,<used>,<total>  <b>OK</b> <b>ERROR</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Write Command <b>AT+CPBS=&lt;storage&gt;</b>	Response <b>OK</b> <b>ERROR</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms
Reference 3GPP 27.007	

#### Parameter

<storage>	"SM"	(U)SIM phonebook
	"DC"	ME dialed calls list ( <b>AT+CPBW</b> may not be applicable to this storage)
	"FD"	(U)SIM fix dialing-phone book ( <b>AT+CPBW</b> operation needs the authority of PIN2)
	"LD"	(U)SIM last-dialing-phone book ( <b>AT+CPBW</b> may not be applicable to this storage)
	"MC"	ME missed (unanswered) calls list ( <b>AT+CPBW</b> may not be applicable to this storage)

"ME"	Mobile equipment phonebook
"RC"	ME received calls list ( <b>AT+CPBW</b> may not be applicable to this storage)
"EN"	(U)SIM (or ME) emergency number ( <b>AT+CPBW</b> may not be applicable to this storage)
"ON"	(U)SIM own numbers (MSISDNs) list
<used>	Integer type. Indicates the total number of used locations in selected memory.
<total>	Integer type. Indicates the total number of locations in selected memory.

## 8.5. AT+CPBW Write Phonebook Entry

The command writes phonebook entry in location number <index> in the current phonebook memory storage selected with **AT+CPBS**. It can also delete a phonebook entry in location number <index>.

### AT+CPBW Write Phonebook Entry

Test Command <b>AT+CPBW=?</b>	Response <b>+CPBW:</b> (The range of supported <index>s), <nlength>, (list of supported <type>s), <tlength>  <b>OK</b> <b>ERROR</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Write Command <b>AT+CPBW=[&lt;index&gt;][,&lt;number&gt;[,&lt;type&gt;[,&lt;text&gt;]]]</b>	Response <b>OK</b> <b>ERROR</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms
Reference 3GPP 27.007	

### Parameter

<index>	Integer type. In the range of location numbers of phone book memory. If <index> is not given, the first free entry will be used. If <index> is given as the only parameter, the phonebook entry specified by <location> is deleted.
<nlength>	Integer type. Indicates the maximum length of field <number>.
<tlength>	Integer type. Indicates the maximum length of field <text>.
<type>	Type of address of octet in integer format (Refer to 3GPP TS 24.008 subclause

---

10.5.4.7 for details). Usually, it has three kinds of values:

129 Unknown type

145 International type (contains the character "+")

161 National type

**<text>** String type field of maximum length **<tlength>** in current TE character set specified by **AT+CSCS**.

---

### Example

```
AT+CSCS="GSM"  
OK  
AT+CPBW=10,"15021012496",129,"QUECTEL" //Make a new phonebook entry at location 10  
OK  
AT+CPBW=10 //Delete entry at location 10  
OK
```

Quectel  
Confidential

# 9 Short Message Service Commands

## 9.1. AT+CSMS Select Message Service

The command selects messaging service and returns the types of messages supported by the ME.

AT+CSMS Select Message Service	
Test Command AT+CSMS=?	Response +CSMS: (list of supported <service>s)  OK
Read Command AT+CSMS?	Response +CSMS: <service>,<mt>,<mo>,<bm>  OK
Write Command AT+CSMS=<service>	Response +CSMS: <mt>,<mo>,<bm>  OK  If there is an error related to ME functionality: +CMS ERROR: <err>
Maximum Response Time	300ms
Reference	3GPP TS 27.005

### Parameter

<service>	Type of message service
0	3GPP TS 23.040 and 3GPP TS 23.041 (the syntax of SMS AT commands is compatible with 3GPP TS 27.005 Phase 2 version 4.7.0; Phase 2+ features which do not require new command syntax may be supported, e.g. correct routing of messages with new Phase 2+ data coding schemes).
1	3GPP TS 23.040 and 3GPP TS 23.041 (the syntax of SMS AT commands is compatible with 3GPP TS 27.005 Phase 2+ version; the requirement of <service> setting 1 is mentioned under corresponding command

		descriptions).
<b>&lt;mt&gt;</b>	Mobile terminated messages	
	0	Type not supported
	1	Type supported
<b>&lt;mo&gt;</b>	Mobile originated messages	
	0	Type not supported
	1	Type supported
<b>&lt;bm&gt;</b>	Broadcast type messages	
	0	Type not supported
	1	Type supported

### Example

```

AT+CSMS=? //Test command
+CSMS: (0,1)

OK
AT+CSMS=1 //Set type of message service as 1
+CSMS: 1,1,1

OK
AT+CSMS? //Read command
+CSMS: 1,1,1,1

OK

```

## 9.2. AT+CMGF Message Format

The command specifies the input and output format of the short messages. **<mode>** indicates the format of messages used with Test, Read, Write and Execution Commands and unsolicited result codes resulting from received messages.

The format of messages can be either PDU mode (entire TP data units used) or text mode (headers and body of the messages given as separate parameters). Text mode uses the value of parameter **<chset>** specified by **AT+CSCS** command to inform the character set to be used in the message body in the TA-TE interface.

### AT+CMGF Message Format

Test Command	Response
AT+CMGF=?	+CMGF: (list of supported <mode>s)
	OK

Read Command <b>AT+CMGF?</b>	Response <b>+CMGF: &lt;mode&gt;</b>  <b>OK</b>
Write Command <b>AT+CMGF[=&lt;mode&gt;]</b>	Response TA sets parameter to denote which kind of I/O format of messages is used. <b>OK</b>
Maximum Response Time	300ms
Reference 3GPP TS 27.005	

### Parameter

<b>&lt;mode&gt;</b>	<u>0</u>	PDU mode
	1	Text mode

### 9.3. AT+CSCA Service Center Address

The Write Command updates the SMSC address when mobile originated SMS are transmitted. In text mode, the setting is used by Write Command. In PDU mode, setting is used by the same command, but only when the length of the SMSC address is coded into the **<pdu>** parameter which equals to zero.

<b>AT+CSCA Service Center Address</b>	
Test Command <b>AT+CSCA=?</b>	Response <b>OK</b>
Read Command <b>AT+CSCA?</b>	Response <b>+CSCA: &lt;sca&gt;,&lt;tosca&gt;</b>  <b>OK</b>
Write Command <b>AT+CSCA=&lt;sca&gt;[,&lt;tosca&gt;]</b>	Response <b>OK</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms
Reference 3GPP TS 27.005	

## Parameter

<b>&lt;sca&gt;</b>	Service center address. 3GPP TS 24.011 RP SC address Address-Value field in string format. BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set (refer to command <b>AT+CSCS</b> in 3GPP TS 27.007); type of address is given by <b>&lt;tosca&gt;</b> .
<b>&lt;tosca&gt;</b>	Type of service center address. 3GPP TS 24.011 RP SC address Type-of-Address octet in integer format (default refer to <b>&lt;toda&gt;</b> ).

## Example

```
AT+CSCA="+8613800210500",145 //Set SMS service center address
OK
AT+CSCA? //Query SMS service center address
+CSCA: "+8613800210500",145
OK
```

## 9.4. AT+CPMS Preferred Message Storage

The command selects the memory storages **<mem1>**, **<mem2>** and **<mem3>** to be used for reading, writing, etc.

### AT+CPMS Preferred Message Storage

Test Command <b>AT+CPMS=?</b>	Response <b>+CPMS:</b> (list of supported <b>&lt;mem1&gt;s</b> ),(list of supported <b>&lt;mem2&gt;s</b> ),(list of supported <b>&lt;mem3&gt;s</b> )  <b>OK</b>
Read Command <b>AT+CPMS?</b>	Response <b>+CPMS:</b> <b>&lt;mem1&gt;,&lt;used1&gt;,&lt;total1&gt;,&lt;mem2&gt;,&lt;used2&gt;,&lt;total2&gt;,&lt;mem3&gt;,&lt;used3&gt;,&lt;total3&gt;</b>  <b>OK</b>
Write Command <b>AT+CPMS=&lt;mem1&gt;[,&lt;mem2&gt;[,&lt;mem3&gt;]]</b>	Response TA selects memory storages <b>&lt;mem1&gt;</b> , <b>&lt;mem2&gt;</b> and <b>&lt;mem3&gt;</b> to be used for reading, writing, etc. <b>+CPMS:</b> <b>&lt;used1&gt;,&lt;total1&gt;,&lt;used2&gt;,&lt;total2&gt;,&lt;used3&gt;,&lt;total3&gt;</b>  <b>OK</b>

	If there is an error related to ME functionality: <b>+CMS ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms
Reference	3GPP TS 27.005

## Parameter

<b>&lt;mem1&gt;</b>	Messages to be read and deleted from this memory storage. “SM” (U)SIM message storage “ME” Mobile equipment message storage “MT” The same as “ME” storage
<b>&lt;mem2&gt;</b>	Messages will be written and sent to this memory storage. “SM” (U)SIM message storage “ME” Mobile equipment message storage “MT” Same as “ME” storage
<b>&lt;mem3&gt;</b>	Received messages will be placed in this memory storage if routing to PC is not set ( <b>AT+CNMI</b> ). “SM” (U)SIM message storage “ME” Mobile equipment message storage “MT” Same as “ME” storage
<b>&lt;usedx&gt;</b>	Integer type. Number of current messages in <b>&lt;memx&gt;</b> .
<b>&lt;totalx&gt;</b>	Integer type. Total number of messages which can be stored in <b>&lt;memx&gt;</b> .

## Example

```

AT+CPMS? //Query the current SMS message storage
+CPMS: "ME",0,255,"ME",0,255,"ME",0,255

OK
AT+CPMS="SM","SM","SM" //Set SMS message storage as "SM"
+CPMS: 0,50,0,50,0,50

OK
AT+CPMS? //Query the current SMS message storage
+CPMS: "SM",0,50,"SM",0,50,"SM",0,50

OK
  
```

## 9.5. AT+CMGD Delete Messages

The command deletes short messages from the preferred message storage **<mem1>** location **<index>**. If **<delflag>** is presented and not set to 0, then the ME shall ignore **<index>** and follow the rules of **<delflag>** shown as below.

AT+CMGD Delete Messages	
Test Command <b>AT+CMGD=?</b>	Response <b>+CMGD:</b> (list of supported <b>&lt;index&gt;</b> s),(list of supported <b>&lt;delflag&gt;</b> s)  <b>OK</b>
Write Command <b>AT+CMGD=&lt;index&gt;[,&lt;delflag&gt;]</b>	Response TA deletes message from preferred message storage <b>&lt;mem1&gt;</b> location <b>&lt;index&gt;</b> . <b>OK</b>  If there is an error related to ME functionality: <b>+CMS ERROR:&lt;err&gt;</b>
Maximum Response Time	300ms. Note: Operation of <b>&lt;delflag&gt;</b> depends on the storage of deleted messages.
Reference 3GPP TS 27.005	

### Parameter

<b>&lt;index&gt;</b>	Integer type. In the range of location numbers supported by the associated memory.
<b>&lt;delflag&gt;</b>	<ul style="list-style-type: none"> <li>0 Delete the message specified in <b>&lt;index&gt;</b></li> <li>1 Delete all read messages from <b>&lt;mem1&gt;</b> storage</li> <li>2 Delete all read messages from <b>&lt;mem1&gt;</b> storage and sent mobile originated messages</li> <li>3 Delete all read messages from <b>&lt;mem1&gt;</b> storage, sent and unsent mobile originated messages</li> <li>4 Delete all messages from <b>&lt;mem1&gt;</b> storage</li> </ul>

### Example

```

AT+CMGD=1 //Delete the message specified in <index>=1
OK
AT+CMGD=1,4 //Delete all messages from <mem1> storage
OK
    
```

## 9.6. AT+CMGL List Messages

The Read Command returns messages with status value **<stat>** from preferred message storage **<mem1>** to the TE. If the status of the message is “REC UNREAD”, the status in the storage changes to “REC READ”. When executing **AT+CMGL** command without status value **<stat>**, it will report the list of SMS with “REC UNREAD” status.

### AT+CMGL List Messages

Test Command

**AT+CMGL=?**

Response

**+CMGL:** (list of supported **<stat>**s)

**OK**

Write Command

**AT+CMGL[=<stat>]**

Response

If in text mode (**AT+CMGF=1**) and the command is executed successfully:

For SMS-SUBMITs and/or SMS-DELIVERs:

**+CMGL:**

**<index>,<stat>,<oa/da>,[<alpha>],[<scts>][,<tooa/toda>,<length>]<CR><LF><data>[<CR><LF>**

**+CMGL:**

**<index>,<stat>,<da/oa>,[<alpha>],[<scts>][,<tooa/toda>,<length>]<CR><LF><data>[...]**

For SMS-STATUS-REPORTs:

**+CMGL:**

**<index>,<stat>,<fo>,<mr>,[<ra>],[<tora>],<scts>,<dt>,<st>[<CR><LF>**

**+CMGL:**

**<index>,<stat>,<fo>,<mr>,[<ra>],[<tora>],<scts>,<dt>,<st>[...]**

For SMS-COMMANDs:

**+CMGL: <index>,<stat>,<fo>,<ct>[<CR><LF>**

**+CMGL: <index>,<stat>,<fo>,<ct>[...]**

For CBM storage:

**+CMGL:<index>,<stat>,<sn>,<mid>,<page>,<pages><CR><LF><data>[<CR><LF>**

**+CMGL:**

**<index>,<stat>,<sn>,<mid>,<page>,<pages><CR><LF><data>[...]**

**OK**

	<p>If in PDU mode (<b>AT+CMGF=0</b>) and the command is executed successfully:</p> <p><b>+CMGL:&lt;index&gt;,&lt;stat&gt;,[&lt;alpha&gt;],&lt;length&gt;&lt;CR&gt;&lt;LF&gt;&lt; pdu&gt;&lt;CR&gt;&lt;LF&gt;</b></p> <p><b>+CMGL:</b> <b>&lt;index&gt;,&lt;stat&gt;,[alpha],&lt;length&gt;&lt;CR&gt;&lt;LF&gt;&lt;pdu&gt;[...]]</b></p> <p><b>OK</b></p> <p>If there is an error related to ME functionality:</p> <p><b>+CMS ERROR: &lt;err&gt;</b></p>
Execution Command <b>AT+CMGL</b>	<p>Response</p> <p>List all messages with “REC UNREAD” status from message storage <b>&lt;mem1&gt;</b>, and then the status in the storage changes to “REC READ”.</p>
Maximum Response Time	<p>300ms.</p> <p>Note: Operation of <b>&lt;stat&gt;</b> depends on the storage of listed messages.</p>
Reference 3GPP TS 27.005	

## Parameter

<b>&lt;stat&gt;</b>	<p>In text mode:</p> <p>“REC UNREAD”      Received unread messages</p> <p>“REC READ”        Received read messages</p> <p>“STO UNSENT”      Stored unsent messages</p> <p>“STO SENT”        Stored sent messages</p> <p>“ALL”                All messages</p> <p>In PDU mode:</p> <p>0                     Received unread messages</p> <p>1                     Received read messages</p> <p>2                     Stored unsent messages</p> <p>3                     Stored sent messages</p> <p>4                     All messages</p>
<b>&lt;index&gt;</b>	Integer type. In the range of location numbers supported by the associated memory.
<b>&lt;da&gt;</b>	Destination Address. 3GPP TS 23.040 TP-Destination-Address Address-Value field in string format. BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set (refer to <b>AT+CSCS</b> command in <i>3GPP TS 27.007</i> ). Type of address is given by <b>&lt;toda&gt;</b> .
<b>&lt;oa&gt;</b>	Originating address. 3GPP TS 23.040 TP-Originating-Address Address-Value field in string format. BCD numbers (or GSM 7 bit default alphabet characters) are converted

---

	to characters of the currently selected TE character set (refer to <b>AT+CSCS</b> command in 3GPP TS 27.007). The type of address is given by <b>&lt;toa&gt;</b> .
<b>&lt;alpha&gt;</b>	String type alphanumeric representation of <b>&lt;da&gt;</b> or <b>&lt;oa&gt;</b> corresponding to the entry found in MT phonebook. Implementation of this feature is manufacturer specified. The used character set should be the one selected with <b>AT+CSCS</b> command (see definition of this command in 3GPP TS 27.007).
<b>&lt;scts&gt;</b>	Service center time stamp. 3GPP TS 23.040 TP-Service-Centre-Time-Stamp in time-string format (refer to <b>&lt;dt&gt;</b> ).
<b>&lt;toa&gt;</b>	Type of recipient address. 3GPP TS 24.011 TP-Recipient-Address Type-of-Address octet in integer format.
<b>&lt;toa&gt;</b>	Type of originating address. 3GPP TS 24.011 TP-Originating-Address Type-of-Address octet in integer format (default refer to <b>&lt;toa&gt;</b> ).
<b>&lt;length&gt;</b>	Message length, integer type. Indicating in text mode ( <b>AT+CMGF=1</b> ) the length of the message body <b>&lt;data&gt;</b> (or <b>&lt;cdata&gt;</b> ) in characters, or in PDU mode ( <b>AT+CMGF=0</b> ) the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length).
<b>&lt;data&gt;</b>	<p>In the case of SMS: 3GPP TS 23.040 TP-User-Data in text mode responses; format:</p> <ul style="list-style-type: none"><li>- If <b>&lt;dcsc&gt;</b>, indicates that 3GPP TS 23.038 GSM 7 bit default alphabet is used and <b>&lt;fo&gt;</b> indicates that 3GPP TS 23.040 TP-User-Data-Header-Indication is not set.</li><li>- If TE character set other than "HEX" (refer to <b>AT+CSCS</b> command in 3GPP TS 27.007): ME/TA converts GSM alphabet into current TE character set according to rules of Annex A.</li><li>- If TE character set is "HEX": ME/TA converts each 7-bit character of GSM 7 bit default alphabet into two IRA character long hexadecimal number (e.g. character II (GSM 7 bit default alphabet 23) is presented as 17 (IRA 49 and 55)).</li><li>- If <b>&lt;dcsc&gt;</b>, indicates that 8-bit or UCS2 data coding scheme is used, or <b>&lt;fo&gt;</b> indicates that 3GPP TS 23.040 TP-User-Data-Header-Indication is set: ME/TA converts each 8-bit octet into two IRA character long hexadecimal number (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)).</li></ul> <p>In the case of CBS: 3GPP TS 23.041 CBM Content of Message in text mode responses; format:</p> <ul style="list-style-type: none"><li>- If <b>&lt;dcsc&gt;</b>, indicates that 3GPP TS 23.038 GSM 7 bit default alphabet is used:</li><li>- If TE character set other than "HEX" (refer to <b>AT+CSCS</b> command in 3GPP TS 27.007): ME/TA converts GSM alphabet into current TE character set according to rules of Annex A.</li><li>- If TE character set is "HEX": ME/TA converts each 7-bit character of the GSM 7 bit default alphabet into two IRA character long hexadecimal number.</li><li>- If <b>&lt;dcsc&gt;</b>, indicates that 8-bit or UCS2 data coding scheme is used: ME/TA converts each 8-bit octet into two IRA character long hexadecimal number.</li></ul>
<b>&lt;pdu&gt;</b>	In the case of SMS: 3GPP TS 24.011 SC address followed by 3GPP TS 23.040 TPDU in hexadecimal format: ME/TA converts each octet of TP data unit into two IRA character long hexadecimal number (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)).

---

### Example

```

AT+CMGF=1 //Set SMS message format as text mode
OK
AT+CMGL="ALL" //List all messages from message storage
+CMGL: 1,"STO UNSENT","",,
<This is a test from Quectel>
+CMGL: 2,"STO UNSENT","",,
<This is a test from Quectel>
OK
    
```

## 9.7. AT+CMGR Read Messages

The Read Command returns SMS messages with location value **<index>** from message storage **<mem1>** to the TE. If status of the message is "REC UNREAD", status in the storage changes to "REC READ".

### AT+CMGR Read Messages

Test Command	Response
<b>AT+CMGR=?</b>	<b>OK</b>
Write Command <b>AT+CMGR=&lt;index&gt;</b>	<p>Response</p> <p>TA returns SMS message with location value <b>&lt;index&gt;</b> from message storage <b>&lt;mem1&gt;</b> to the TE. If status of the message is "REC UNREAD", status in the storage changes to "REC READ".</p> <p>If text mode (<b>+CMGF=1</b>) and command is executed successfully:</p> <p>For SMS-DELIVER:</p> <p><b>+CMGR:</b>  <b>&lt;stat&gt;,&lt;oa&gt;,[&lt;alpha&gt;],[&lt;scts&gt;],[&lt;tooa&gt;,&lt;fo&gt;,&lt;pid&gt;,&lt;dcsc&gt;,&lt;sca&gt;,&lt;tosca&gt;,&lt;length&gt;]&lt;CR&gt;&lt;LF&gt;&lt;data&gt;</b></p> <p><b>OK</b></p> <p>For SMS-SUBMIT:</p> <p><b>+CMGR:</b>  <b>&lt;stat&gt;,&lt;da&gt;,[&lt;alpha&gt;][,&lt;toda&gt;,&lt;fo&gt;,&lt;pid&gt;,&lt;dcsc&gt;,[&lt;vp&gt;],&lt;sca&gt;,&lt;tosca&gt;,&lt;length&gt;]&lt;CR&gt;&lt;LF&gt;&lt;data&gt;</b></p> <p><b>OK</b></p>

For SMS-STATUS-REPORTs:

**+CMGR:**

<stat>,<fo>,<mr>,[<ra>],[<tora>],<scts>,<dt>,<st>

OK

For SMS-COMMANDs:

**+CMGR:**

<stat>,<fo>,<ct>[,<pid>,[<mn>],[<da>],[<toda>],<length><CR><LF><cdata>]

OK

For CBM storage:

**+CMGR:**

<stat>,<sn>,<mid>,<dcs>,<page>,<pages><CR><LF><data>

OK

If in PDU mode (**AT+CMGF=0**) and the command is executed successfully:

**+CMGR:** <stat>,[<alpha>],<length><CR><LF><pdu>

OK

If there is an error related to ME functionality:

**+CMS ERROR:** <err>

Maximum Response Time

Depends on the length of message content.

Reference

3GPP TS 27.005

## Parameter

<index>	Integer type. In the range of location numbers supported by the associated memory.	
<stat>	Text mode	Explanation
	“REC UNREAD”	Received unread messages
	“REC READ”	Received read messages
	“STO UNSENT”	Stored unsent messages
	“STO SENT”	Stored sent messages
	“ALL”	All messages
	PDU mode	Explanation

	0	Received unread messages
	1	Received read messages
	2	Stored unsent messages
	3	Stored sent messages
	4	All messages
<b>&lt;alpha&gt;</b>	String type alphanumeric representation of <b>&lt;da&gt;</b> or <b>&lt;oa&gt;</b> corresponding to the entry found in MT phonebook. Implementation of this feature is manufacturer specified. The used character set should be the one selected with <b>AT+CSCS</b> command (see definition of this command in <i>3GPP TS 27.007</i> ).	
<b>&lt;da&gt;</b>	Destination address. 3GPP TS 23.040 TP-Destination-Address Address-Value field in string format. BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set (refer to <b>AT+CSCS</b> command in <i>3GPP TS 27.007</i> ). The type of address is given by <b>&lt;toda&gt;</b> .	
<b>&lt;oa&gt;</b>	Originating address. 3GPP TS 23.040 TP-Originating-Address Address-Value field in string format. BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set (refer to <b>AT+CSCS</b> command in <i>3GPP TS 27.007</i> ). The type of address is given by <b>&lt;tooa&gt;</b> .	
<b>&lt;scts&gt;</b>	Service center time stamp. 3GPP TS 23.040 TP-Service-Centre-Time-Stamp in time-string format (refer to <b>&lt;dt&gt;</b> ).	
<b>&lt;fo&gt;</b>	First octet. Depending on the command or result code: First octet of 3GPP TS 23.040 SMS-DELIVER, SMS-SUBMIT (default 17), SMS-STATUS-REPORT, or SMS-COMMAND in integer format. If a valid value has been entered once, the parameter can be omitted.	
<b>&lt;pid&gt;</b>	Protocol identifier. 3GPP TS 23.040 TP-Protocol-Identifier in integer format (default 0).	
<b>&lt;dcs&gt;</b>	Data coding scheme. Depending on the command or result code: 3GPP TS 23.038 SMS Data Coding Scheme (default 0), or Cell Broadcast Data Coding Scheme in integer format.	
<b>&lt;vp&gt;</b>	Validity period. Depending on SMS-SUBMIT <b>&lt;fo&gt;</b> setting: 3GPP TS 23.040 TP-Validity-Period either in integer format or in time-string format (refer to <b>&lt;dt&gt;</b> ).	
<b>&lt;mn&gt;</b>	Message number. 3GPP TS 23.040 TP-Message-Number in integer format.	
<b>&lt;mr&gt;</b>	Message reference. 3GPP TS 23.040 TP-Message-Reference in integer format.	
<b>&lt;ra&gt;</b>	Recipient address. 3GPP TS 23.040 TP-Recipient-Address Address-Value field in string format. BCD numbers (or GSM default alphabet characters) are converted to characters of the currently selected TE character set (refer to <b>AT+CSCS</b> command). The type of address is given by <b>&lt;tora&gt;</b> .	
<b>&lt;tora&gt;</b>	Type of recipient address. 3GPP TS 24.011 TP-Recipient-Address Type-of-Address octet in integer format (default refer to <b>&lt;toda&gt;</b> ).	
<b>&lt;toda&gt;</b>	Type of recipient address. 3GPP TS 24.011 TP-Recipient-Address Type-of-Address octet in integer format.	
<b>&lt;tooa&gt;</b>	Type of originating address. 3GPP TS 24.011 TP-Originating-Address Type-of-Address octet in integer format (default refer to <b>&lt;toda&gt;</b> ).	
<b>&lt;sca&gt;</b>	Service center address. 3GPP TS 24.011 RP SC address Address-Value field in string format. BCD numbers (or GSM 7 bit default alphabet characters) are converted to	

---

	characters of the currently selected TE character set (refer to <b>AT+CSCS</b> command in 3GPP TS 27.007). The type of address is given by <b>&lt;tosca&gt;</b> .
<b>&lt;tosca&gt;</b>	Type of service center address. 3GPP TS 24.011 RP SC address Type-of-Address octet in integer format (default refer to <b>&lt;toda&gt;</b> ).
<b>&lt;length&gt;</b>	Message length, integer type. Indicating in text mode ( <b>AT+CMGF=1</b> ) the length of the message body <b>&lt;data&gt;</b> (or <b>&lt;cdata&gt;</b> ) in characters, or in PDU mode ( <b>AT+CMGF=0</b> ) the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length).
<b>&lt;data&gt;</b>	The text of short message. Please refer to <b>Chapter 14.8</b> for the detail.
<b>&lt;pdu&gt;</b>	In the case of SMS: 3GPP TS 24.011 SC address followed by 3GPP TS 23.040 TPDU in hexadecimal format: ME/TA converts each octet of TP data unit into two IRA character long hexadecimal number (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)).
<b>&lt;prt&gt;</b>	Priority 0 Normal 1 Interactive 2 Urgent 3 Emergency
<b>&lt;fmt&gt;</b>	Format 0 GSM 7 bit 1 ASCII 6 UNICODE
<b>&lt;prv&gt;</b>	Privacy 0 Normal 1 Restricted 2 Confidential 3 Secret
<b>&lt;lang&gt;</b>	Language 0 Unspecified 1 English 2 French 3 Spanish 4 Japanese 5 Korean 6 Chinese 7 Hebrew
<b>&lt;type&gt;</b>	0 Normal 1 CPT 2 Voice Mail 3 SMS Report

---

### Example

```
+CMTI: "SM",3 //Indicates that a new message has been received and
                saved to <index>=3 of "SM"

AT+CSDH=1
OK
AT+CMGR=3 //Read message
+CMGR: "REC UNREAD","+8615021012496","13/12/13,15:06:37+32",145,4,0,0,"+861380021050
0",145,27

<This is a test from Quectel>

OK
```

## 9.8. AT+CMGS Send Messages

The Write Command sends a short message from TE to network (SMS-SUBMIT). After invoking the Write Command, wait for the prompt > and then start to write the message. After that, enter <CTRL-Z> to indicate the ending of PDU and begin to send the message. Sending can be cancelled by giving <ESC> character. Abortion is acknowledged with **OK**, though the message will not be sent. The message reference <mr> is returned to the TE on successful message delivery. The value can be used to identify message upon unsolicited delivery status report result code.

### AT+CMGS Send Messages

Test Command	Response
<b>AT+CMGS=?</b>	<b>OK</b>
Write Command 1) If in text mode ( <b>AT+CMGF=1</b> ): <b>AT+CMGS=&lt;da&gt;[,&lt;toda&gt;]&lt;CR&gt;</b> text is entered <Ctrl+Z/ESC> ESC means quit without sending  2) If in PDU mode ( <b>AT+CMGF=0</b> ): <b>AT+CMGS=&lt;length&gt;&lt;CR&gt;</b> PDU is given <Ctrl+Z/ESC>	Response TA sends message from TE to the network (SMS-SUBMIT). The message reference value <mr> is returned to the TE on successful message delivery. Optionally (when <b>AT+CSMS &lt;service&gt;</b> value is 1 and network supports) <scts> is returned. Values can be used to identify message upon unsolicited delivery status report result code.  If in text mode ( <b>AT+CMGF=1</b> ) and sent successfully: <b>+CMGS: &lt;mr&gt;</b>  <b>OK</b>  If in PDU mode ( <b>AT+CMGF=0</b> ) and sent successfully: <b>+CMGS: &lt;mr&gt;</b>  <b>OK</b>

	If there is an error related to ME functionality: <b>+CMS ERROR: &lt;err&gt;</b>
Maximum Response Time	120s, determined by network.
Reference	
3GPP TS 27.005	

## Parameter

<b>&lt;da&gt;</b>	Destination address. 3GPP TS 23.040 TP-Destination-Address Address-Value field in string format. BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set (refer to command <b>AT+CSCS</b> in 3GPP TS 27.007). The type of address is given by <b>&lt;toda&gt;</b> .
<b>&lt;toda&gt;</b>	Type of recipient address. 3GPP TS 24.011 TP-Recipient-Address Type-of-Address octet in integer format.
<b>&lt;length&gt;</b>	Message length, integer type. indicating in the text mode ( <b>AT+CMGF=1</b> ) the length of the message body <b>&lt;data&gt;</b> (or <b>&lt;cdata&gt;</b> ) in characters, or in PDU mode ( <b>AT+CMGF=0</b> ), the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length).
<b>&lt;mr&gt;</b>	Message reference. 3GPP TS 23.040 TP-Message-Reference in integer format.

## Example

```

AT+CMGF=1 //Set SMS message format as text mode
OK
AT+CSCS="GSM" //Set character set as GSM which is used by the TE
OK
AT+CMGS="15021012496"
> <This is a test from Quectel> //Enter in text. Use <Ctrl+Z> to send message, or
//ESC> to quit without sending.
+CMGS: 247
OK

```

## 9.9. AT+CMMS More Messages to Send

The command controls the continuity of the SMS relay protocol link. If the feature is enabled (and supported by the currently used network) multiple messages can be sent faster as the link is kept open.

AT+CMMS More Messages to Send	
Test Command <b>AT+CMMS=?</b>	Response <b>+CMMS:</b> (list of supported<n>s)  <b>OK</b>
Read Command <b>AT+CMMS?</b>	Response <b>+CMMS:</b> <n>  <b>OK</b>
Write Command <b>AT+CMMS=&lt;n&gt;</b>	Response <b>OK</b> <b>ERROR</b>  If there is an error related to ME functionality: <b>+CMS ERROR: &lt;err&gt;</b>
Maximum Response Time	120s, determined by network.
Reference 3GPP TS 27.005	

### Parameter

- |     |   |   |
|-----|---|---|
| <n> | 0 | Feature disabled  |
|     | 1 | Keep enabled until the time between the response of the latest message-sending command ( <b>AT+CMGS</b> , <b>AT+CMSS</b> , etc.) and the next message-sending command exceeds 1-5 seconds (the exact value is up to ME implementation), and then the ME shall close the link and TA switches <n> back to 0 automatically. |
|     | 2 | Feature enabled. If the time between the response of the latest message-sending command and the next message-sending command exceeds 1-5 seconds (the exact value is up to ME implementation), the ME shall close the link but TA will not switch <n> back to 0 automatically.  |

#### NOTE

After the use of Read Command, a delay of 5-10 seconds is required before issuing the Write Command. Otherwise **+CMS ERROR: 500** may appear.

## 9.10. AT+CMGW Write Messages to Memory

The Write and Execution Commands store short messages from TE to memory storage <mem2>. Memory location <index> of the stored message is returned. Message status will be set to “stored”

unsent” by default, but parameter **<stat>** also allows other status values to be given.

The syntax of input text is the same as the one specified in the Write Command **AT+CMGS**.

### AT+CMGW Write Messages to Memory

Test Command <b>AT+CMGW=?</b>	Response <b>OK</b>
Write Command 1) If in text mode ( <b>AT+CMGF=1</b> ): <b>AT+CMGW=&lt;oa/da&gt;[,&lt;tooa/toda&gt;[,&lt;stat&gt;]]&lt;CR&gt;</b> text is entered <Ctrl+Z/ESC> <ESC> means quit without writing  2) If in PDU mode ( <b>AT+CMGF=0</b> ): <b>AT+CMGW=&lt;length&gt;[,&lt;stat&gt;]&lt;CR&gt;</b> PDU is given <Ctrl+Z/ESC>	Response TA transmits SMS message (either SMS-DELIVER or SMS-SUBMIT) from TE to memory storage <b>&lt;mem2&gt;</b> . Memory location <b>&lt;index&gt;</b> of the stored message is returned. By default message status will be set to ‘stored unsent’, but parameter <b>&lt;stat&gt;</b> also allows other status values to be given.  If writing is successful: <b>+CMGW: &lt;index&gt;</b>  <b>OK</b>  If there is an error related to ME functionality: <b>+CMS ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms
Reference 3GPP TS 27.005	

### Parameter

<b>&lt;da&gt;</b>	Destination address. 3GPP TS 23.040 TP-Destination-Address Address-Value field in string format. BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set (refer to <b>AT+CSCS</b> command in <i>3GPP TS 27.007</i> ). The type of address is given by <b>&lt;toda&gt;</b> .		
<b>&lt;oa&gt;</b>	Originating address. 3GPP TS 23.040 TP-Originating-Address Address-Value field in string format. BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set (refer to <b>AT+CSCS</b> command in <i>3GPP TS 27.007</i> ). The type of address is given by <b>&lt;tooa&gt;</b> .		
<b>&lt;tooa&gt;</b>	Type of originating address. 3GPP TS 24.011 TP-Originating-Address Type-of-Address octet in integer format (default refer to <b>&lt;toda&gt;</b> ).		
<b>&lt;stat&gt;</b>	PDU mode	Text mode	Explanation
	0	“REC UNREAD”	Received unread messages
	1	“REC READ”	Received read messages
	2	“STO UNSENT”	Stored unsent messages
	3	“STO SENT”	Stored sent messages
	4	“ALL”	All messages

<b>&lt;tda&gt;</b>	Type of recipient address. 3GPP TS 24.011 TP-Recipient-Address Type-of-Address octet in integer format.
<b>&lt;length&gt;</b>	Message length, integer type. Indicating in the text mode ( <b>AT+CMGF=1</b> ) the length of the message body <b>&lt;data&gt;</b> (or <b>&lt;cdata&gt;</b> ) in characters, or in PDU mode ( <b>AT+CMGF=0</b> ), the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length).
<b>&lt;pdu&gt;</b>	In the case of SMS: 3GPP TS 24.011 SC address followed by 3GPP TS 23.04 TPDU in hexadecimal format: ME/TA converts each octet of TP data unit into two IRA character long hexadecimal number (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)).
<b>&lt;index&gt;</b>	Index of message in selected storage <b>&lt;mem2&gt;</b> .

### Example

```

AT+CMGF=1 //Set SMS message format as text mode
OK
AT+CSCS="GSM" //Set character set as GSM which is used by the TE
OK
AT+CMGW="15021012496"
> <This is a test from Quectel> //Enter in text. Use <CTRL+Z> to write message, or
<ESC> to quit without writing.
+CMGW: 4

OK
AT+CMGF=0 //Set SMS message format as PDU mode
OK
AT+CMGW=18
> 0051FF00000008000A0500030002016D4B8BD5
+CMGW: 5

OK

```

## 9.11. AT+CMSS Send Messages from Storage

The Write Command sends messages with location value **<index>** from message storage **<mem2>** to the network. If new recipient address **<da>** is given for SMS-SUBMIT, it shall be used instead of the one stored with the message.

### AT+CMSS Send Messages from Storage

Test Command	Response
AT+CMSS=?	OK

<p>Write Command <b>AT+CMSS=&lt;index&gt;[,&lt;da&gt;[,&lt;toda&gt;]]</b></p>	<p>Response</p> <p>TA sends message with location value <b>&lt;index&gt;</b> from message storage <b>&lt;mem2&gt;</b> to the network (SMS-SUBMIT). If new recipient address <b>&lt;da&gt;</b> is given, it shall be used instead of the one stored with the message. Reference value <b>&lt;mr&gt;</b> is returned to the TE on successful message delivery. Values can be used to identify message upon unsolicited delivery status report result code.</p> <p>If in text mode (<b>AT+CMGF=1</b>) and sent successfully: <b>+CMSS: &lt;mr&gt;[,&lt;scts&gt;]</b></p> <p><b>OK</b></p> <p>If in PDU mode (<b>AT+CMGF=0</b>) and sent successfully: <b>+CMSS: &lt;mr&gt; [,&lt;ackpdu&gt;]</b></p> <p><b>OK</b></p> <p>If there is an error related to ME functionality: <b>+CMS ERROR: &lt;err&gt;</b></p>
<p>Maximum Response Time</p>	<p>120s, determined by network.</p>
<p>Reference 3GPP TS 27.005</p>	

## Parameter

<b>&lt;index&gt;</b>	Integer type. In the range of location numbers supported by the associated memory.
<b>&lt;da&gt;</b>	Destination Address. 3GPP TS 23.040 TP-Destination-Address Address-Value field in string format. BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set (refer to <b>AT+CSCS</b> command in <i>3GPP TS 27.007</i> ). The type of address is given by <b>&lt;toda&gt;</b> .
<b>&lt;toda&gt;</b>	Type of recipient address. 3GPP TS 24.011 TP-Recipient-Address Type-of-Address octet in integer format.
<b>&lt;mr&gt;</b>	Message reference. 3GPP TS 23.040 TP-Message-Reference in integer format.
<b>&lt;scts&gt;</b>	Service center time stamp. 3GPP TS 23.040 TP-Service-Centre-Time-Stamp in time-string format (refer to <b>&lt;dt&gt;</b> ).
<b>&lt;ackpdu&gt;</b>	Format is same for <b>&lt;pdu&gt;</b> in case of SMS, but without 3GPP TS 24.011 SC address field and parameter shall be bounded by double quote characters like a normal string type parameter.

### Example

```

AT+CMGF=1 //Set SMS message format as text mode
OK
AT+CSCS="GSM" //Set character set as GSM which is used by the TE
OK
AT+CMGW="15021012496"
> Hello //Enter in text. Use <CTRL+Z> to send message, or
<ESC> to quit without sending.

+CMGW: 4

OK
AT+CMSS=4 //Send the message of index 4 from memory storage.
+CMSS: 54

OK
    
```

## 9.12. AT+CNMA New Message Acknowledgement to UE/TE

The Write and Execution Commands confirm successful receipt of a new message (SMS-DELIVER or SMS-STATUS-REPORT) routed directly to the TE. If the UE does not receive acknowledgement within required time (network timeout), it sends an **RP-ERROR** message to the network. The UE will automatically disable routing to the TE by setting both **<mt>** and **<ds>** values of **AT+CNMI** to 0.

### AT+CNMA New Message Acknowledgement to UE/TE

Test Command <b>AT+CNMA=?</b>	Response <b>+CNMA:</b> (list of supported <b>&lt;n&gt;s</b> )  <b>OK</b>
Execution Command <b>AT+CNMA</b>	Response <b>OK</b> <b>ERROR</b>  If there is an error related to ME functionality: <b>+CMS ERROR: &lt;err&gt;</b>
Write Command <b>AT+CNMA=&lt;n&gt;</b>	Response <b>OK</b> <b>ERROR</b>  If there is an error related to ME functionality: <b>+CMS ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms

Reference  
3GPP TS 27.005

## Parameter

<b>&lt;n&gt;</b>	Parameter required only for PDU mode
0	Command operates similarly as in text mode
1	Send positive ( <b>RP-ACK</b> ) acknowledgement to the network. Accepted only in PDU mode.
2	Send negative ( <b>RP-ERROR</b> ) acknowledgement to the network. Accepted only in PDU mode.

### NOTE

Execute and Write Commands shall only be used when **AT+CSMS** parameter **<service>** equals to 1 (phase 2+) and an appropriate URC has been issued by the module, i.e.:

- +CMT for **<mt>**=2 incoming message classes 0, 1, 3 and none;
- +CMT for **<mt>**=3 incoming message classes 0 and 3;
- +CDS for **<ds>**=1.

## Example

```

AT+CSMS=1
OK
AT+CNMI=1,2,0,0,0
OK

+CMT: "+8615021012496",,"13/03/18,17:07:21+32",145,4,0,0,"+8613800551500",145,28
This is a test from Quectel.           //A short message is outputted directly when SMS is incoming.
AT+CNMA                               //Send ACK to the network
OK
AT+CNMA
+CMS ERROR: 340                       //The second time return error. It needs ACK only once.

```

## 9.13. AT+CNMI SMS Event Reporting Configuration

The Write Command selects the procedure on how the received new messages from the network are indicated to the TE when TE is active, e.g. DTR is at low level. If TE is inactive (e.g. DTR is at high level), message receiving should be done as specified in *3GPP TS 23.038*.

## AT+CNMI SMS Event Reporting Configuration

Test Command <b>AT+CNMI=?</b>	Response <b>+CNMI:</b> (list of supported <b>&lt;mode&gt;</b> s),(list of supported <b>&lt;mt&gt;</b> s),(list of supported <b>&lt;bm&gt;</b> s),(list of supported <b>&lt;ds&gt;</b> s),(list of supported <b>&lt;bfr&gt;</b> s)  <b>OK</b>
Read Command <b>AT+CNMI?</b>	Response <b>+CNMI:</b> <b>&lt;mode&gt;</b> , <b>&lt;mt&gt;</b> , <b>&lt;bm&gt;</b> , <b>&lt;ds&gt;</b> , <b>&lt;bfr&gt;</b>  <b>OK</b>
Write Command <b>AT+CNMI[=&lt;mode&gt;[,&lt;mt&gt;[,&lt;bm&gt;[,&lt;ds&gt;[,&lt;bfr&gt;]]]]]</b>	Response TA selects the procedure on how the received new messages from the network are indicated to the TE when TE is active, e.g. DTR is at low level. If TE is inactive (e.g. DTR is at high level), message receiving should be done as specified in <i>3GPP TS 23.038</i> .  <b>OK</b> <b>ERROR</b>  If there is an error related to ME functionality: <b>+CMS ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms
Reference	3GPP TS 27.005

### Parameter

<b>&lt;mode&gt;</b>	0	Buffer unsolicited result codes in the TA. If TA result code buffer is full, indications can be buffered in some other place or the oldest indications may be discarded and replaced with the new received indications.
	1	Discard indication and reject new received message unsolicited result codes when TA-TE link is reserved (e.g. in data mode). Otherwise forward them directly to the TE.
	<u>2</u>	Buffer unsolicited result codes in the TA when TA-TE link is reserved (e.g. in data mode) and flush them to the TE after reservation. Otherwise forward them directly to the TE.
<b>&lt;mt&gt;</b>		The rules for storing received SMS depend on its data coding scheme (refer to <i>3GPP TS 23.038</i> ) and preferred memory storage ( <b>AT+CPMS</b> ) setting, and the value is:
	0	No SMS-DELIVER indications are routed to the TE.
	<u>1</u>	If SMS-DELIVER is stored into ME/TA, indication of the memory location is routed

		to the TE by using unsolicited result code: <b>+CMTI: &lt;mem&gt;,&lt;index&gt;</b>
	2	SMS-DELIVERs (except class 2) are routed directly to the TE using unsolicited result code: <b>+CMT: [&lt;alpha&gt;],&lt;length&gt;&lt;CR&gt;&lt;LF&gt;&lt;pdu&gt;</b> (PDU mode enabled) or <b>+CMT: &lt;oa&gt;,&lt;alpha&gt;,&lt;scts&gt;,&lt;tooa&gt;,&lt;fo&gt;,&lt;pid&gt;,&lt;dcs&gt;,&lt;sca&gt;,&lt;tosca&gt;,&lt;length&gt;]&lt;CR&gt;&lt;LF&gt;&lt;data&gt;</b> (text mode enabled; about parameters in italics, refer to <b>AT+CSDH</b> ). Class 2 messages result in indication as defined in <b>&lt;mt&gt;=1</b> .
	3	Class 3 SMS-DELIVERs are routed directly to TE by using unsolicited result codes defined in <b>&lt;mt&gt;=2</b> . Messages of other classes result in indication as defined in <b>&lt;mt&gt;=1</b> .
<b>&lt;bm&gt;</b>		The rules for storing received CBMs depend on its data coding scheme (refer to <i>3GPP TS 23.038</i> ) and the setting of Select CBM Types ( <b>AT+CSCB</b> ), and the value is:
	0	No CBM indications are routed to the TE.
	2	New CBMs are routed directly to the TE using unsolicited result code: <b>+CBM: &lt;length&gt;&lt;CR&gt;&lt;LF&gt;&lt;pdu&gt;</b> (PDU mode); or <b>+CBM: &lt;sn&gt;,&lt;mid&gt;,&lt;dcs&gt;,&lt;page&gt;,&lt;pages&gt;&lt;CR&gt;&lt;LF&gt;&lt;data&gt;</b> (text mode)
<b>&lt;ds&gt;</b>	0	No SMS-STATUS-REPORTs are routed to the TE.
	1	SMS-STATUS-REPORTs are routed to the TE using unsolicited result code: <b>+CDS: &lt;length&gt;&lt;CR&gt;&lt;LF&gt;&lt;pdu&gt;</b> (PDU mode) <b>+CDS: &lt;fo&gt;,&lt;mr&gt;,&lt;ra&gt;,&lt;tora&gt;,&lt;scts&gt;,&lt;st&gt;</b> (text mode)
	2	If SMS-STATUS-REPORT is stored into ME/TA, indication of the memory location is routed to the TE using unsolicited result code: <b>+CDSI: &lt;mem&gt;,&lt;index&gt;</b>
<b>&lt;bfr&gt;</b>	0	TA buffer of unsolicited result codes defined within this command is flushed to the TE when <b>&lt;mode&gt;</b> 1...2 is entered ( <b>OK</b> response shall be given before flushing the codes).
	1	TA buffer of unsolicited result codes defined within this command is cleared when <b>&lt;mode&gt;</b> 1...2 is entered.

**NOTE**

Unsolicited result code:

<b>+CMTI: &lt;mem&gt;,&lt;index&gt;</b>	Indicates that a new message has been received
<b>+CMT: [&lt;alpha&gt;],&lt;length&gt;&lt;CR&gt;&lt;LF&gt;&lt;pdu&gt;</b>	A short message is outputted directly
<b>+CBM: &lt;length&gt;&lt;CR&gt;&lt;LF&gt;&lt;pdu&gt;</b>	Cell broadcast message is outputted directly

**Example**

```

AT+CMGF=1 //Set SMS message format as text mode
OK
AT+CSCS="GSM" //Set character set as GSM which is used by the TE
OK
AT+CNMI=1,2,0,1,0 //Set SMS-DELIVERs are routed directly to the TE
OK
    
```

**+CMT: "+8615021012496", "13/03/18,17:07:21+32",145,4,0,0,"+8613800551500",145,28**  
**This is a test from Quectel.** //A short message is outputted directly when SMS is incoming.

## 9.14. AT+CSCB\* Select Cell Broadcast Message Types

The Write Command selects which types of CBMs are to be received by the ME. The command writes the parameters in NON-VOLATILE memory.

### AT+CSCB\* Select Cell Broadcast Message Types

Test Command <b>AT+CSCB=?</b>	Response It returns supported modes as a compound value. <b>+CSCB:</b> (list of supported <b>&lt;mode&gt;</b> s)  <b>OK</b>
Read Command <b>AT+CSCB?</b>	Response <b>+CSCB :</b> <b>&lt;mode&gt;</b> , <b>&lt;mids&gt;</b> , <b>&lt;dcss&gt;</b>  <b>OK</b>
Write Command <b>AT+CSCB=&lt;mode&gt;[,&lt;mids&gt;[,&lt;dcss&gt;]]</b>	Response TA selects which types of CBMs are to be received by the ME. <b>OK</b>  If there is an error related to ME functionality: <b>+CMS ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms
Reference 3GPP TS 27.005	

#### Parameter

<b>&lt;mode&gt;</b>	0	Message types specified in <b>&lt;mids&gt;</b> and <b>&lt;dcss&gt;</b> are accepted
	1	Message types specified in <b>&lt;mids&gt;</b> and <b>&lt;dcss&gt;</b> are not accepted
<b>&lt;mids&gt;</b>	String type. All different possible combinations of CBM message identifiers (refer to <b>&lt;mid&gt;</b> ) (default is empty string), e.g. "0,1,5,320-478,922".	
<b>&lt;dcss&gt;</b>	String type. All different possible combinations of CBM data coding schemes (refer to <b>&lt;dcs&gt;</b> ) (default is empty string), e.g. "0-3,5".	

## 9.15. AT+CSDH Show SMS Text Mode Parameters

The Write Command controls whether detailed header information is shown in text mode result codes.

### AT+CSDH Show SMS Text Mode Parameters

Test Command <b>AT+CSDH=?</b>	Response <b>+CSDH:</b> (list of supported <b>&lt;show&gt;</b> s)  <b>OK</b>
Read Command <b>AT+CSDH?</b>	Response <b>+CSDH:</b> <b>&lt;show&gt;</b>  <b>OK</b>
Write Command <b>AT+CSDH[=&lt;show&gt;]</b>	Response <b>OK</b> <b>ERROR</b>
Maximum Response Time	300ms
Reference	3GPP TS 27.005

#### Parameter

<b>&lt;show&gt;</b>	<u>0</u>	Do not show header values defined in commands <b>+CSCA</b> , <b>+CSMP</b> ( <b>&lt;sca&gt;</b> , <b>&lt;tosca&gt;</b> , <b>&lt;fo&gt;</b> , <b>&lt;vp&gt;</b> , <b>&lt;pid&gt;</b> , <b>&lt;dcs&gt;</b> ) and <b>&lt;length&gt;</b> , <b>&lt;toda&gt;</b> or <b>&lt;tooa&gt;</b> in <b>+CMT</b> , <b>+CMGL</b> , <b>+CMGR</b> result codes for SMS-DELIVERs and SMS-SUBMITs in text mode.
	1	Show the values in result codes.

#### Example

```
AT+CSDH=0
OK
AT+CMGR=2
+CMGR: "STO UNSENT", "",
<This is a test from Quectel>
OK
AT+CSDH=1
OK
AT+CMGR=2
+CMGR: "STO UNSENT", "",,128,17,0,0,143,"+8613800551500",145,18
```

<This is a test from Quectel>

OK

## 9.16. AT+CSMP Set SMS Text Mode Parameters

The command is used to set values for additional parameters needed when a short message is sent to the network or placed in a storage in text mode.

### AT+CSMP Set SMS Text Mode Parameters

Test Command <b>AT+CSMP=?</b>	Response <b>OK</b>
Read Command <b>AT+CSMP?</b>	Response <b>+CSMP: &lt;fo&gt;,&lt;vp&gt;,&lt;pid&gt;,&lt;dcS&gt;</b>  <b>OK</b>
Write Command <b>AT+CSMP=&lt;fo&gt;[,&lt;vp&gt;[,&lt;pid&gt;[,&lt;dcS&gt;]] ]</b>	Response TA selects values for additional parameters needed when SM is sent to the network or placed in a storage when text mode is selected ( <b>AT+CMGF=1</b> ). It is possible to set the validity period starting from when the SM is received by the SMSC ( <b>&lt;vp&gt;</b> ranges from 0 to 255) or define the absolute time of the validity period termination ( <b>&lt;vp&gt;</b> is a string). <b>OK</b>
Maximum Response Time	300ms
Reference 3GPP TS 27.005	

#### Parameter

<b>&lt;fo&gt;</b>	First octet. Depending on the command or result code: First octet of 3GPP TS 23.040 SMS-DELIVER, SMS-SUBMIT (default 17), SMS-STATUS-REPORT, SMS-COMMAND in integer format. If a valid value has been entered once, parameter can be omitted.
<b>&lt;vp&gt;</b>	Validity period. Depending on SMS-SUBMIT <b>&lt;fo&gt;</b> setting: 3GPP TS 23.040 TP-Validity-Period either in integer format or in time-string format (refer to <b>&lt;dt&gt;</b> ).
<b>&lt;pid&gt;</b>	Protocol identifier. 3GPP TS 23.040 TP-Protocol-Identifier in integer format (default 0).
<b>&lt;dcS&gt;</b>	Data coding scheme. Depending on the command or result code: 3GPP TS 23.038 SMS Data Coding Scheme (default 0), or Cell Broadcast Data Coding Scheme in integer format.

## 9.17. AT+QCMGS\* Send Concatenated Messages

The command is used to send concatenated messages. Different from **AT+CMGS**, when sending a concatenated message via this command, each segment of the concatenated message must be identified by the additional parameters: **<uid>**, **<msg\_seg>** and **<msg\_total>**. When sending all segments of the message one by one, **AT+QCMGS** must be executed multiple times (equal to **<msg\_total>**) for each segment. This command is only used in text mode (**AT+CMGF=1**).

### AT+QCMGS\* Send Concatenated Messages

Test Command <b>AT+QCMGS=?</b>	Response <b>OK</b>
Write Command If in text mode ( <b>AT+CMGF=1</b> ): <b>AT+QCMGS=&lt;da&gt;[,&lt;toda&gt;][,&lt;uid&gt;,&lt;msg_seg&gt;,&lt;msg_total&gt;]&lt;CR&gt;</b> text is entered <Ctrl+Z/ESC>	Response If in text mode ( <b>AT+CMGF=1</b> ) and sent successfully: <b>+QCMGS: &lt;mr&gt;</b>  <b>OK</b> <b>ERROR</b>  If there is an error related to ME functionality: <b>+CMS ERROR: &lt;err&gt;</b>
Maximum Response Time	120s, determined by network.

### Parameter

<b>&lt;uid&gt;</b>	Message identification in the user data header (UDH). Range: 0-255. This parameter is defined and inputted by the user. All segments of a same concatenated message must have the same <b>&lt;uid&gt;</b> . Different concatenated messages should have different <b>&lt;uid&gt;</b> .
<b>&lt;msg_seg&gt;</b>	Sequence number of a concatenated message. Range: 0-7. <b>&lt;msg_seg&gt;=0</b> means: ignore the value and regarded it as a non-concatenated message.
<b>&lt;msg_total&gt;</b>	The total number of the segments of one concatenated message. Range: 0-7. <b>&lt;msg_total&gt;=0</b> or <b>1</b> means: ignore the value and regard it as a non-concatenated message.
<b>&lt;da&gt;,&lt;toda&gt;,&lt;mr&gt;</b>	Please refer to <b>AT+CMGS</b> .

### NOTES

- For concatenated messages, the maximum length will be reduced by the length of the user data header (UDH). *3GPP TS 23.040* defines two kinds of UDH length: 6 bytes and 7 bytes, so the two kinds of **<uid>** are 8 bit (6 bytes) and 16 bit (7 bytes). **AT+QCMGS** uses 8 bit **<uid>**.

- In the case of GSM 7 bit default alphabet data coding scheme, the maximum length of each segment of a concatenated message is  $(140 \text{ octets} - 6) * 8 / 7 = 153$  characters.
  - In the case of 16 bit UCS2 data coding scheme, the maximum length of each segment is  $(140 - 6) / 2 = 67$  characters.
  - In the case of 8-bit data coding scheme, the maximum length of each segment is  $140 - 6 = 134$ .
2. **<mr>**, Message-Reference field gives an integer representation of a reference number of the SMS-SUBMIT or SMS-COMMAND submitted to the SC by the MS, and it is used to confirm whether the SMS-DELIVER has been received from SC duplicate or not. **<uid>**, the field of UDH, is message identification of the concatenated SMS, which is different from **<mr>**. Each segment in a concatenated message should have the same **<uid>**, but **<mr>** must be incremented for each segment of a concatenated message.
  3. **AT+QCMGS** does not support to send message in PDU mode (**AT+CMGF=0**).

### Example

```

AT+CMGF=1 //Set SMS message format as text mode
OK
AT+CSCS="GSM" //Set character set as GSM which is used by the TE
OK
AT+QCMGS="15056913384",120,1,2 <CR> //Input 120 for <uid>, send the first segment of the
concatenated SMS

>ABCD<Ctrl-Z>
+QCMGS: 190

OK
AT+QCMGS="15056913384",120,2,2 <CR> //Send the second segment of the concatenated SMS.
>EFGH<Ctrl-Z>
+QCMGS: 191

OK

```

## 9.18. AT+QCMGR\* Read Concatenated Messages

The function of this command is similar to **AT+CMGR**, except that the message to be read is a segment of concatenated messages, and parameters: **<uid>**, **<msg\_seg>** and **<msg\_total>** would be shown in the result. Several segments should be concatenated to a whole concatenated message according to these three parameters. Similar to **AT+QCMGS**, **AT+QCMGR** is only used in text mode (**AT+CMGF=1**).

### AT+QCMGR\* Read Concatenated Messages

Test Command	Response
AT+QCMGR=?	OK

Write Command

**AT+QCMGR=<index>**

Response

If in text mode (**AT+CMGF=1**) and the command is executed successfully:

For SMS-DELIVER:

**+QCMGR:**

<stat>,<oa>,[<alpha>],<scts>[,<tooa>,<fo>,<pid>,<dcsc>,<sca>,<tosca>,<length>][,<uid>,<msg\_seg>,<msg\_total>]  
<CR><LF><data>

**OK**

For SMS-SUBMIT:

**+QCMGR:**

<stat>,<da>,[<alpha>][,<toda>,<fo>,<pid>,<dcsc>,[<vp>],<sca>,<tosca>,<length>][,<uid>,<msg\_seg>,<msg\_total>]  
<CR><LF><data>

**OK**

For SMS-STATUS-REPORTs:

**+QCMGR:**

<stat>,<fo>,<mr>,[<ra>],[<tora>],<scts>,<dt>,<st>

**OK**

For SMS-COMMANDs:

**+QCMGR:**

<stat>,<fo>,<ct>[,<pid>,[<mn>],[<da>],[<toda>],<length><CR><LF><cdata>]

**OK**

If there is an error related to ME functionality:

**+CMS ERROR: <err>**

Maximum Response Time

Depends on the length of message content.

**Parameter**

<b>&lt;uid&gt;</b>	Message identification in the user data header (UDH). Range: 0-65535 (see NOTES). All segments of a same concatenated message have same <b>&lt;uid&gt;</b> . Different concatenated messages should have different <b>&lt;uid&gt;</b> .
<b>&lt;msg_seg&gt;</b>	Sequence number of a concatenated message. Range: 1-7.
<b>&lt;msg_total&gt;</b>	The total number of the segments of one concatenated message. Range: 2-7. Other parameters please refer to <b>AT+CMGR</b> .

## NOTES

1. The **<uid>** in **AT+QCMGR** is different from the **<uid>** in **AT+QCMGS**. It is possible that UE receives concatenated messages with 8 bits or 16 bits **<uid>**. So its maximal value is 255 with 8 bits and 65535 with 16 bits.
2. If the message to be read is not a concatenated message, **<uid>**, **<msg\_seg>** and **<msg\_total>** would not be shown in the result.

## Example

```
+CMTI: "SM",3           //The first segment of a concatenated message comes
+CMTI: "SM",4           //The second segment of a concatenated message comes

AT+QCMGR= 3             //Read the first segment of the concatenated message
+QCMGR: "REC UNREAD", "+8615056913384", "13/07/30,14:44:37+32",120,1,2
ABCD

OK
AT+QCMGR= 4             //Read the second segment of the concatenated message
+QCMGR: "REC UNREAD", "+8615056913384", "13/07/30,14:44:37+32",120,2,2
EFGH

OK
```

## 9.19. AT+QSMSR\* Read Messages

The Read Command returns SMS message with location value **<index>** from message storage **<mem1>** to the TE. If status of the message is "REC UNREAD", status in the storage changes to "REC READ".

### AT+QSMSR\* Read Messages

Test Command <b>AT+QSMSR=?</b>	Response <b>OK</b>
Write Command <b>AT+QSMSR=&lt;index&gt;</b>	Response TA returns SMS message with location value <b>&lt;index&gt;</b> from message storage <b>&lt;mem1&gt;</b> to the TE. If status of the message is "REC UNREAD", status in the storage changes to "REC READ".  If in text mode ( <b>+CMGF=1</b> ) and the command is executed successfully:

For SMS-DELIVER:

**+QSMSR:**

<smstype>,<stat>,<oa>,[<alpha>],<scts>[,<tooa>,<fo>,<pid>,<dc  
s>,<vp>],<sca>,<tosca>,<length>]<CR><LF><data>

OK

For SMS-SUBMIT:

**+QSMSR:**

<smstype>,<stat>,<da>,[<alpha>][,<toda>,<fo>,<pid>,<dc  
s>,<vp>],<sca>,<tosca>,<length>]<CR><LF><data>

OK

For SMS-STATUS-REPORTs:

**+QSMSR:**

<smstype>,<stat>,<fo>,<mr>,[<ra>],[<tora>],<scts>,<dt>,  
<st>

OK

For SMS-COMMANDs:

**+QSMSR:**

<smstype>,<stat>,<fo>,<ct>[,<pid>,[<mn>],[<da>],[<toda  
>],<length>]<CR><LF><cdata>]

OK

For CBM storage:

**+QSMSR:**

<smstype>,<stat>,<sn>,<mid>,<dc>,<page>,<pages><C  
R><LF><data>

OK

If in PDU mode (**AT+CMGF=0**) and the command is executed successfully:

**+QSMSR:**

<smstype>,<stat>,[<alpha>],<length>]<CR><LF><pdu>

OK

If there is an error related to ME functionality:

**+CMS ERROR: <err>**

Maximum Response Time

Depends on the length of message content.

## Parameter

<b>&lt;smstype&gt;</b>	SMS type
	0 CDMA SMS
	1 Non-CDMA SMS
<b>&lt;index&gt;</b>	Integer type. In the range of location numbers supported by the associated memory.
<b>&lt;stat&gt;</b>	PDU mode Text mode Explanation
	0 "REC UNREAD" Received unread messages
	1 "REC READ" Received read messages
	2 "STO UNSENT" Stored unsent messages
	3 "STO SENT" Stored sent messages
	4 "ALL" All messages
<b>&lt;alpha&gt;</b>	String type alphanumeric representation of <b>&lt;da&gt;</b> or <b>&lt;oa&gt;</b> corresponding to the entry found in MT phonebook. Implementation of this feature is manufacturer specified. The used character set should be the one selected with <b>AT+CSCS</b> command (see definition of this command in <i>3GPP TS 27.007</i> ).
<b>&lt;da&gt;</b>	Destination address. 3GPP TS 23.040 TP-Destination-Address Address-Value field in string format. BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set (refer to <b>AT+CSCS</b> command in <i>3GPP TS 27.007</i> ). The type of address is given by <b>&lt;toda&gt;</b> .
<b>&lt;oa&gt;</b>	Originating address. 3GPP TS 23.040 TP-Originating-Address Address-Value field in string format. BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set (refer to <b>AT+CSCS</b> command in <i>3GPP TS 27.007</i> ). The type of address is given by <b>&lt;tooa&gt;</b> .
<b>&lt;scts&gt;</b>	Service center time stamp. 3GPP TS 23.040 TP-Service-Centre-Time-Stamp in time-string format (refer to <b>&lt;dt&gt;</b> ).
<b>&lt;fo&gt;</b>	First octet. Depending on the command or result code: First octet of 3GPP TS 23.040 SMS-DELIVER, SMS-SUBMIT (default 17), SMS-STATUS-REPORT, or SMS-COMMAND in integer format. If a valid value has been entered once, the parameter can be omitted.
<b>&lt;pid&gt;</b>	Protocol identifier. 3GPP TS 23.040 TP-Protocol-Identifier in integer format (default 0).
<b>&lt;dcs&gt;</b>	Data coding scheme. Depending on the command or result code: 3GPP TS 23.038 SMS Data Coding Scheme (default 0), or Cell Broadcast Data Coding Scheme in integer format.
<b>&lt;vp&gt;</b>	Validity period. Depending on SMS-SUBMIT <b>&lt;fo&gt;</b> setting: 3GPP TS 23.040 TP-Validity-Period either in integer format or in time-string format (refer to <b>&lt;dt&gt;</b> ).
<b>&lt;mn&gt;</b>	Message number. 3GPP TS 23.040 TP-Message-Number in integer format.
<b>&lt;mr&gt;</b>	Message reference. 3GPP TS 23.040 TP-Message-Reference in integer format.
<b>&lt;ra&gt;</b>	Recipient address. 3GPP TS 23.040 TP-Recipient-Address Address-Value field in string format. BCD numbers (or GSM default alphabet characters) are converted to

---

	characters of the currently selected TE character set (refer to <b>AT+CSCS</b> command). The type of address is given by <b>&lt;tora&gt;</b> .
<b>&lt;tora&gt;</b>	Type of recipient address. 3GPP TS 24.011 TP-Recipient-Address Type-of-Address octet in integer format (default refer to <b>&lt;toda&gt;</b> ).
<b>&lt;toda&gt;</b>	Type of recipient address. 3GPP TS 24.011 TP-Recipient-Address Type-of-Address octet in integer format.
<b>&lt;tooa&gt;</b>	Type of originating address. 3GPP TS 24.011 TP-Originating-Address Type-of-Address octet in integer format (default refer to <b>&lt;toda&gt;</b> ).
<b>&lt;sca&gt;</b>	Service center address. 3GPP TS 24.011 RP SC address Address-Value field in string format. BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set (refer to <b>AT+CSCS</b> command in 3GPP TS 27.007). The type of address is given by <b>&lt;tosca&gt;</b> .
<b>&lt;tosca&gt;</b>	Type of service center address. 3GPP TS 24.011 RP SC address Type-of-Address octet in integer format (default refer to <b>&lt;toda&gt;</b> ).
<b>&lt;length&gt;</b>	Message length, integer type. Indicating in text mode ( <b>AT+CMGF=1</b> ) the length of the message body <b>&lt;data&gt;</b> (or <b>&lt;cdata&gt;</b> ) in characters, or in PDU mode ( <b>AT+CMGF=0</b> ) the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length).
<b>&lt;data&gt;</b>	The text of short message. Please refer to <b>Chapter 14.8</b> for the details.
<b>&lt;pdu&gt;</b>	In the case of SMS: 3GPP TS 24.011 SC address followed by 3GPP TS 23.040 TPDU in hexadecimal format: ME/TA converts each octet of TP data unit into two IRA character long hexadecimal number (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)).
<b>&lt;prt&gt;</b>	Priority 0 Normal 1 Interactive 2 Urgent 3 Emergency
<b>&lt;fmt&gt;</b>	Format 0 GSM 7 bit 1 ASCII 6 UNICODE
<b>&lt;prv&gt;</b>	Privacy 0 Normal 1 Restricted 2 Confidential 3 Secret
<b>&lt;lang&gt;</b>	Language 0 Unspecified 1 English 2 French 3 Spanish 4 Japanese 5 Korean

---

<b>&lt;type&gt;</b>	6	Chinese
	7	Hebrew
	0	Normal
	1	CPT
	2	Voice Mail
	3	SMS Report

**NOTE**

**<smstype>=0** is invalid in this command for BG96.

## 9.20. AT+QSMSL\* List Messages

The Read Command returns messages with status value **<stat>** from preferred message storage **<mem1>** to the TE. If the status of the message is “REC UNREAD”, the status in the storage changes to “REC READ”. When executing this command without status value **<stat>**, it will report the list of SMS with “REC UNREAD” status.

### AT+QSMSL\* List Messages

Test Command <b>AT+QSMSL=?</b>	Response <b>+QSMSL:</b> (list of supported <b>&lt;stat&gt;</b> s)  <b>OK</b>
Write Command <b>AT+QSMSL[=&lt;stat&gt;]</b>	Response If in text mode ( <b>AT+CMGF=1</b> ) and the command is executed successfully: For SMS-SUBMITs and/or SMS-DELIVERs: <b>+QSMSL:</b> <b>&lt;smstype&gt;,&lt;index&gt;,&lt;stat&gt;,&lt;oa/da&gt;,[&lt;alpha&gt;],[&lt;scts&gt;][,&lt;toa/toda&gt;,&lt;length&gt;]&lt;CR&gt;&lt;LF&gt;&lt;data&gt;[&lt;CR&gt;&lt;LF&gt;</b> <b>+QSMSL:</b> <b>&lt;smstype&gt;,&lt;index&gt;,&lt;stat&gt;,&lt;da/oa&gt;,[&lt;alpha&gt;],[&lt;scts&gt;][,&lt;toa/toda&gt;,&lt;length&gt;]&lt;CR&gt;&lt;LF&gt;&lt;data&gt;[...]</b>  For SMS-STATUS-REPORTs: <b>+QSMSL:</b> <b>&lt;smstype&gt;,&lt;index&gt;,&lt;stat&gt;,&lt;fo&gt;,&lt;mr&gt;,[&lt;ra&gt;],[&lt;tora&gt;],&lt;scts&gt;,&lt;dt&gt;,&lt;st&gt;[&lt;CR&gt;&lt;LF&gt;</b> <b>+QSMSL:</b> <b>&lt;smstype&gt;,&lt;index&gt;,&lt;stat&gt;,&lt;fo&gt;,&lt;mr&gt;,[&lt;ra&gt;],[&lt;tora&gt;],&lt;scts&gt;,&lt;dt&gt;,&lt;st&gt;[...]</b>

	<p>For SMS-COMMANDS:  <b>+QSMSL:</b>          &lt;smstype&gt;,&lt;index&gt;,&lt;stat&gt;,&lt;fo&gt;,&lt;ct&gt;[&lt;CR&gt;&lt;LF&gt;  <b>+QSMSL:</b> &lt;smstype&gt;,&lt;index&gt;,&lt;stat&gt;,&lt;fo&gt;,&lt;ct&gt;[...]]</p> <p>For CBM storage:  <b>+QSMSL:</b>&lt;smstype&gt;,&lt;index&gt;,&lt;stat&gt;,&lt;sn&gt;,&lt;mid&gt;,&lt;page&gt;,&lt;pages&gt;&lt;CR&gt;&lt;LF&gt;&lt;data&gt;[&lt;CR&gt;&lt;LF&gt;  <b>+QSMSL:</b>          &lt;smstype&gt;,&lt;index&gt;,&lt;stat&gt;,&lt;sn&gt;,&lt;mid&gt;,&lt;page&gt;,&lt;pages&gt;&lt;CR&gt;&lt;LF&gt;&lt;data&gt;[...]]</p> <p><b>OK</b></p> <p>If in PDU mode (<b>AT+CMGF=0</b>) and the command is executed successfully:  <b>+QSMSL:</b>&lt;smstype&gt;,&lt;index&gt;,&lt;stat&gt;,&lt;alpha&gt;,&lt;length&gt;&lt;CR&gt;&lt;LF&gt;&lt;pdu&gt;&lt;CR&gt;&lt;LF&gt;  <b>+QSMSL:</b>          &lt;smstype&gt;,&lt;index&gt;,&lt;stat&gt;,&lt;alpha&gt;,&lt;length&gt;&lt;CR&gt;&lt;LF&gt;&lt;pdu&gt;[...]]</p> <p><b>OK</b></p> <p>If there is an error related to ME functionality:  <b>+CMS ERROR: &lt;err&gt;</b></p>
Execution Command <b>AT+QSMSL</b>	Response List all messages with "REC UNREAD" status from message storage <mem1>, and then the status in the storage changes to "REC READ".
Maximum Response Time	300ms. Note: Operation of <stat> depends on the storage of listed messages.

**Parameter**

<smstype>	SMS type	
	0	CDMA SMS
	1	Non-CDMA SMS
<stat>	In text mode:	
	"REC UNREAD"	Received unread messages
	"REC READ"	Received read messages

	"STO UNSENT"	Stored unsend messages
	"STO SENT"	Stored send messages
	"ALL"	All messages
	In PDU mode:	
	0	Received unread messages
	1	Received read messages
	2	Stored unsend messages
	3	Stored send messages
	4	All messages
<b>&lt;index&gt;</b>	Integer type. In the range of location numbers supported by the associated memory.	
<b>&lt;da&gt;</b>	Destination Address. 3GPP TS 23.040 TP-Destination-Address Address-Value field in string format. BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set (refer to <b>AT+CSCS</b> command in 3GPP TS 27.007). The type of address is given by <b>&lt;toda&gt;</b> .	
<b>&lt;oa&gt;</b>	Originating address. 3GPP TS 23.040 TP-Originating-Address Address-Value field in string format. BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set (refer to <b>AT+CSCS</b> command in 3GPP TS 27.007). The type of address is given by <b>&lt;toa&gt;</b> .	
<b>&lt;alpha&gt;</b>	String type alphanumeric representation of <b>&lt;da&gt;</b> or <b>&lt;oa&gt;</b> corresponding to the entry found in MT phonebook. Implementation of this feature is manufacturer specified. The used character set should be the one selected with <b>AT+CSCS</b> command (see definition of this command in 3GPP TS 27.007).	
<b>&lt;scts&gt;</b>	Service center time stamp. 3GPP TS 23.040 TP-Service-Centre-Time-Stamp in time-string format (refer to <b>&lt;dt&gt;</b> ).	
<b>&lt;toda&gt;</b>	Type of recipient address. 3GPP TS 24.011 TP-Recipient-Address Type-of-Address octet in integer format.	
<b>&lt;toa&gt;</b>	Type of originating address. 3GPP TS 24.011 TP-Originating-Address Type-of-Address octet in integer format (default refer to <b>&lt;toda&gt;</b> ).	
<b>&lt;length&gt;</b>	Message length, integer type. Indicating in text mode ( <b>AT+CMGF=1</b> ) the length of the message body <b>&lt;data&gt;</b> (or <b>&lt;cdata&gt;</b> ) in characters, or in PDU mode ( <b>AT+CMGF=0</b> ) the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length).	
<b>&lt;data&gt;</b>	In the case of SMS: 3GPP TS 23.040 TP-User-Data in text mode responses; format: <ul style="list-style-type: none"> <li>- If <b>&lt;dc&gt;</b>, indicates that 3GPP TS 23.038 GSM 7 bit default alphabet is used and <b>&lt;fo&gt;</b> indicates that 3GPP TS 23.040 TP-User-Data-Header-Indication is not set.</li> <li>- If TE character set other than "HEX" (refer to <b>AT+CSCS</b> command in 3GPP TS 27.007): ME/TA converts GSM alphabet into current TE character set according to rules of Annex A.</li> <li>- If TE character set is "HEX": ME/TA converts each 7-bit character of GSM 7 bit default alphabet into two IRA character long hexadecimal number (e.g. character II (GSM 7 bit default alphabet 23) is presented as 17 (IRA 49 and 55)).</li> <li>- If <b>&lt;dc&gt;</b>, indicates that 8-bit or UCS2 data coding scheme is used, or <b>&lt;fo&gt;</b> indicates that 3GPP TS 23.040 TP-User-Data-Header-Indication is set: ME/TA converts each 8-bit octet into two IRA character long hexadecimal number (e.g.</li> </ul>	

octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)).

In the case of CBS: 3GPP TS 23.041 CBM Content of Message in text mode responses; format:

- If **<dcs>**, indicates that 3GPP TS 23.038 GSM 7 bit default alphabet is used:
- If TE character set other than "HEX" (refer to **AT+CSCS** command in 3GPP TS27.007): ME/TA converts GSM alphabet into current TE character set according to rules of Annex A.
- If TE character set is "HEX": ME/TA converts each 7-bit character of the GSM 7 bit default alphabet into two IRA character long hexadecimal number.
- If **<dcs>**, indicates that 8-bit or UCS2 data coding scheme is used: ME/TA converts each 8-bit octet into two IRA character long hexadecimal number.

**<pdu>**

In the case of SMS: 3GPP TS 24.011 SC address followed by 3GPP TS 23.040 TPDU in hexadecimal format: ME/TA converts each octet of TP data unit into two IRA character long hexadecimal number (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)) 3GPP TS 27.007.

**NOTE**

**<smstype>=0** is invalid in this command for BG96.

# 10 Packet Domain Commands

## 10.1. AT+CGATT Attachment or Detachment of PS

The Write Command is used to attach the MT to, or detach the MT from the Packet Domain service. After the command has been completed, the MT remains in V.25ter command state. If the MT is already in the requested state, the command is ignored and the **OK** response will be returned. If the requested state cannot be achieved, an **ERROR** or **+CME ERROR** response is returned.

AT+CGATT Attachment or Detachment of PS	
Test Command AT+CGATT=?	Response +CGATT: (list of supported <state>s)  OK
Read Command AT+CGATT?	Response +CGATT: <state>  OK
Write Command AT+CGATT=<state>	Response OK  If there is an error related to ME functionality: +CME ERROR: <err>
Maximum Response Time	140s, determined by network.
Reference 3GPP TS 27.007	

### Parameter

<state>	Indicates the state of PS attachment
0	Detached
1	Attached
Other values are reserved and will result in an <b>ERROR</b> response to the Write Command.	

### Example

```

AT+CGATT=1 //Attach to PS service
OK
AT+CGATT=0 //Detach from PS service
OK
AT+CGATT? //Query the current PS service state
+CGATT: 0
OK
    
```

## 10.2. AT+CGDCONT Define PDP Context

The command specifies PDP context parameters for a specific context **<cid>**. A special form of the Write Command (**AT+CGDCONT=<cid>**) causes the values for context **<cid>** to become undefined. It is not allowed to change the definition of an already activated context.

The Read Command returns the current settings for each defined PDP context.

### AT+CGDCONT Define PDP Context

Test Command <b>AT+CGDCONT=?</b>	Response <b>+CGDCONT:</b> (range of supported <b>&lt;cid&gt;</b> s), <b>&lt;PDP_type&gt;</b> , <b>&lt;APN&gt;</b> , <b>&lt;PDP_addr&gt;</b> , (list of supported <b>&lt;data_comp&gt;</b> s), (list of supported <b>&lt;head_comp&gt;</b> s)  <b>OK</b>
Read Command <b>AT+CGDCONT?</b>	Response <b>+CGDCONT:</b> <b>&lt;cid&gt;</b> , <b>&lt;PDP_type&gt;</b> , <b>&lt;APN&gt;</b> , <b>&lt;PDP_addr&gt;</b> , <b>&lt;data_comp&gt;</b> , <b>&lt;head_comp&gt;</b> [...]  <b>OK</b>
Write Command <b>AT+CGDCONT=&lt;cid&gt;</b> [, <b>&lt;PDP_type&gt;</b> ],[ <b>&lt;APN&gt;</b> ],[ <b>&lt;PDP_addr&gt;</b> ],[ <b>&lt;data_comp&gt;</b> ],[ <b>&lt;head_comp&gt;</b> ]]]]	Response <b>OK</b> <b>ERROR</b>
Maximum Response Time	300ms
Reference	3GPP TS 27.007

## Parameter

<b>&lt;cid&gt;</b>	PDP context identifier. A numeric parameter which specifies a particular PDP context definition. The parameter is local to the TE-MT interface and is used in other PDP context-related commands. The range of permitted values (minimum value=1) is returned by the test form of the command.
<b>&lt;PDP_type&gt;</b>	Packet data protocol type. A string parameter which specifies the type of packet data protocol. "IP" IPv4 "PPP" "IPV6" "IPV4V6"
<b>&lt;APN&gt;</b>	Access point name. A string parameter that is a logical name used to select the GGSN or the external packet data network. If the value is null or omitted, then the subscription value will be requested.
<b>&lt;PDP_addr&gt;</b>	A string parameter identifies the MT in the address space applicable to the PDP. If the value is null or omitted, then a value may be provided by the TE during the PDP startup procedure or, failing that, a dynamic address will be requested. The allocated address may be read using the <b>AT+CGPADDR</b> command.
<b>&lt;data_comp&gt;</b>	A numeric parameter that controls PDP data compression (applicable for SNDCP only) (refer to <i>3GPP TS 44.065</i> ). <u>0</u> OFF (Default value if the parameter is omitted) 1 ON (Manufacturer preferred compression) 2 V.42bis 3 V.44 (Not supported currently)
<b>&lt;head_comp&gt;</b>	A numeric parameter that controls PDP header compression (refer to <i>3GPP TS 44.065</i> and <i>3GPP TS 25.323</i> ). <u>0</u> OFF 1 ON 2 RFC1144 3 RFC2507 4 RFC3095

### 10.3. AT+CGQREQ\* Quality of Service Profile (Requested)

The command allows the TE to specify the quality of service profile that is used when the MT activates a PDP context.

The Write Command specifies a profile for the context **<cid>**. A special form of the Write Command, **AT+CGQREQ=<cid>** causes the requested profile for context number **<cid>** to become undefined. The Read Command returns the current settings for each defined context. Details can be found in *3GPP TS 23.107* and all parameters are saved in NV automatically.

## AT+CGQREQ\* Quality of Service Profile (Requested)

Test Command <b>AT+CGQREQ=?</b>	Response <b>+CGQREQ: &lt;PDP_type&gt;</b> , (list of supported <b>&lt;precedence&gt;s</b> ), (list of supported <b>&lt;delay&gt;s</b> ), (list of supported <b>&lt;reliability&gt;s</b> ), (list of supported <b>&lt;peak&gt;s</b> ), (list of supported <b>&lt;mean&gt;s</b> )  <b>OK</b>
Read Command <b>AT+CGQREQ?</b>	Response <b>[+CGQREQ:</b> <b>&lt;cid&gt;,&lt;precedence&gt;,&lt;delay&gt;,&gt;reliability&gt;,&lt;peak&gt;,&lt;mean</b> <b>&gt;]</b> <b>[+CGQREQ:</b> <b>&lt;cid&gt;,&lt;precedence&gt;,&lt;delay&gt;,&lt;reliability&gt;,&lt;peak&gt;,&lt;mean</b> <b>&gt;]</b> <b>[...]</b>  <b>OK</b>
Write Command <b>AT+CGQREQ=&lt;cid&gt;[,&lt;precedence&gt;[,&lt;delay&gt;[,&lt;reliability&gt;[,&lt;peak&gt;[,&lt;mean&gt;]]]]]</b>	Response <b>OK</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms
Reference	3GPP TS 27.007

### Parameter

<b>&lt;cid&gt;</b>	A numeric parameter which specifies a particular PDP context definition (see <b>AT+CGDCONT</b> command)
<b>&lt;PDP_type&gt;</b>	Packet Data Protocol type "IP" Internet Protocol (IETF STD 5) "PPP" "IPV6" "IPV4V6"
<b>&lt;precedence&gt;</b>	A numeric parameter which specifies the precedence class <u>0</u> Network subscribed value 1 High Priority. Service commitments shall be maintained ahead of precedence classes 2 and 3.

	2	Normal priority. Service commitments shall be maintained ahead of precedence class 3.
	3	Low priority. Service commitments shall be maintained.
<b>&lt;delay&gt;</b>		A numeric parameter which specifies the delay class. This parameter defines the end-to-end transfer delay incurred in the transmission of SDUs through the network. For the details, please refer to <b>Table 5</b> .
	<u>0</u>	Network subscribed value
<b>&lt;reliability&gt;</b>		A numeric parameter which specifies the reliability class
	<u>0</u>	Network subscribed value
	1	Non real-time traffic, error-sensitive application that cannot cope with data loss
	2	Non real-time traffic, error-sensitive application that can cope with infrequent data loss
	3	Non real-time traffic, error-sensitive application that can cope with data loss, GMM/SM, and SMS
	4	Real-time traffic, error-sensitive application that can cope with data loss
	5	Real-time traffic, error non-sensitive application that can cope with data loss
<b>&lt;peak&gt;</b>		A numeric parameter which specifies the peak throughput class, in octets per second.
	<u>0</u>	Network subscribed value
	1	Up to 1 000 (8kbit/s)
	2	Up to 2 000 (16kbit/s)
	3	Up to 4 000 (32kbit/s)
	4	Up to 8 000 (64kbit/s)
	5	Up to 16 000 (128kbit/s)
	6	Up to 32 000 (256kbit/s)
	7	Up to 64 000 (512kbit/s)
	8	Up to 128 000 (1024kbit/s)
	9	Up to 256 000 (2048kbit/s)
<b>&lt;mean&gt;</b>		A numeric parameter which specifies the mean throughput class, in octets per hour.
	<u>0</u>	Network subscribed value
	1	100 (~0.22bit/s)
	2	200 (~0.44bit/s)
	3	500 (~1.11bit/s)
	4	1 000 (~2.2bit/s)
	5	2 000 (~4.4bit/s)
	6	5 000 (~11.1bit/s)
	7	10 000 (~22bit/s)
	8	20 000 (~44bit/s)
	9	50 000 (~111bit/s)
	10	100 000 (~0.22kbit/s)
	11	200 000 (~0.44kbit/s)
	12	500 000 (~1.11kbit/s)
	13	1000 000 (~2.2kbit/s)
	14	2 000 000 (~4.4kbit/s)
	15	5 000 000 (~11.1kbit/s)

16	10 000 000 (~22kbit/s)
17	20 000 000 (~44kbit/s)
18	50 000 000 (~111kbit/s)
31	Best effort

**Table 4: Delay Class**

SDU Size	Delay Class	Mean Transfer Delay	95 Percentile
128 octets	1 (Predictive)	<0.5	<1.5
	2 (Predictive)	<5	<25
	3 (Predictive)	<50	<250
	4 (Best Effort)	Unspecified	-
1024 octets	1 (Predictive)	<0.5	<1.5
	2 (Predictive)	<5	<25
	3 (Predictive)	<50	<250
	4 (Best Effort)	Unspecified	-

## 10.4. AT+CGQMIN\* Quality of Service Profile (Minimum Acceptable)

The command allows the TE to specify a minimum acceptable profile which is checked by the MT against the negotiated profile when a PDP context is activated. The Write Command specifies a profile for the context identified by the context identification parameter **<cid>**.

A special form of the Write Command, **AT+CGQMIN=<cid>** causes the minimum acceptable profile for context number **<cid>** to become undefined. In this case no check is made against the negotiated profile. The Read Command returns the current settings for each defined context. Details can be found in *3GPP TS 23.107* and all parameters are saved in NV automatically.

### AT+CGQMIN\* Quality of Service Profile (Minimum Acceptable)

Test Command  
**AT+CGQMIN=?**

Response  
**+CGQMIN: <PDP\_type>**,  
(list of supported **<precedence>**s),  
(list of supported **<delay>**s),  
(list of supported **<reliability>**s),  
(list of supported **<peak>**s),

	(list of supported <mean>s)
	<b>OK</b>
Read Command <b>AT+CGQMIN?</b>	Response <b>[+CGQMIN:</b> <cid>,<precedence>,<delay>,<reliability>,<peak>,<mean >] <b>[+CGQMIN:</b> <cid>,<precedence>,<delay>,<reliability>,<peak>,<mean >] [...]
	<b>OK</b>
Write Command <b>AT+CGQMIN=&lt;cid&gt;[,&lt;precedence&gt;[,&lt;delay&gt;[,&lt;reliability&gt;[,&lt;peak&gt;[,&lt;mean&gt;]]]]]</b>	Response <b>OK</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms
Reference 3GPP TS 27.007	

**Parameter**

<cid>	A numeric parameter which specifies a particular PDP context definition (see <b>AT+CGDCONT</b> command).
<PDP_type>	Packet Data Protocol type “IP” Internet Protocol (IETF STD 5) “PPP” “IPV6” “IPV4V6”
<precedence>	A numeric parameter which specifies the precedence class 0 Network subscribed value 1 High Priority. Service commitments shall be maintained ahead of precedence classes 2 and 3. 2 Normal priority. Service commitments shall be maintained ahead of precedence class 3. 3 Low priority. Service commitments shall be maintained.
<delay>	A numeric parameter which specifies the delay class. This parameter defines the end-to-end transfer delay incurred in the transmission of SDUs through the network. For the details please refer to <b>Table 5</b> . <u>0</u> Network subscribed value
<reliability>	A numeric parameter which specifies the reliability class.

	<u>0</u>	Network subscribed value
	1	Non real-time traffic, error-sensitive application that cannot cope with data loss
	2	Non real-time traffic, error-sensitive application that can cope with infrequent data loss
	3	Non real-time traffic, error-sensitive application that can cope with data loss, GMM/SM, and SMS
	4	Real-time traffic, error-sensitive application that can cope with data loss
	5	Real-time traffic, error non-sensitive application that can cope with data loss
<b>&lt;peak&gt;</b>		A numeric parameter which specifies the peak throughput class, in octets per second.
	<u>0</u>	Network subscribed value
	1	Up to 1 000 (8kbit/s)
	2	Up to 2 000 (16kbit/s)
	3	Up to 4 000 (32kbit/s)
	4	Up to 8 000 (64kbit/s)
	5	Up to 16 000 (128kbit/s)
	6	Up to 32 000 (256kbit/s)
	7	Up to 64 000 (512kbit/s)
	8	Up to 128 000 (1024kbit/s)
	9	Up to 256 000 (2048kbit/s)
<b>&lt;mean&gt;</b>		A numeric parameter which specifies the mean throughput class, in octets per hour.
	<u>0</u>	Network subscribed value
	1	100 (~0.22bit/s)
	2	200 (~0.44bit/s)
	3	500 (~1.11bit/s)
	4	1 000 (~2.2bit/s)
	5	2 000 (~4.4bit/s)
	6	5 000 (~11.1bit/s)
	7	10 000 (~22bit/s)
	8	20 000 (~44bit/s)
	9	50 000 (~111bit/s)
	10	100 000 (~0.22kbit/s)
	11	200 000 (~0.44kbit/s)
	12	500 000 (~1.11kbit/s)
	13	1000 000 (~2.2kbit/s)
	14	2 000 000 (~4.4kbit/s)
	15	5 000 000 (~11.1kbit/s)
	16	10 000 000 (~22kbit/s)
	17	20 000 000 (~44kbit/s)
	18	50 000 000 (~111kbit/s)
	31	Best effort

## 10.5. AT+CGACT Activate or Deactivate PDP Contexts

The Write Command is used to activate or deactivate the specified PDP context(s). After the command has been completed, the MT remains in V.250 command state. If any PDP context is already in the requested state, the state for that context remains unchanged. If the MT is not PS attached when the activation form of the command is executed, the MT first performs a PS attach and then attempts to activate the specified contexts. If no **<cid>**s specify the activation/deactivation form of the command, it will activate or deactivate all defined contexts.

### AT+CGACT Activate or Deactivate PDP Contexts

Test Command <b>AT+CGACT=?</b>	Response <b>+CGACT:</b> (list of supported <b>&lt;state&gt;</b> s)  <b>OK</b>
Read Command <b>AT+CGACT?</b>	Response <b>+CGACT:</b> <b>&lt;cid&gt;</b> , <b>&lt;state&gt;</b> [ <b>&lt;CR&gt;&lt;LF&gt;</b> <b>+CGACT:</b> <b>&lt;cid&gt;</b> , <b>&lt;state&gt;</b> <b>&gt;...</b> ]  <b>OK</b>
Write Command <b>AT+CGACT=&lt;state&gt;</b> , <b>&lt;cid&gt;</b>	Response <b>OK</b> <b>NO CARRIER</b>  If there is an error related to ME functionality: <b>+CME ERROR:</b> <b>&lt;err&gt;</b>
Maximum Response Time	150s, determined by network.
Reference 3GPP TS 27.007	

### Parameter

<b>&lt;state&gt;</b>	Indicates the state of PDP context activation. 0 Deactivated 1 Activated Other values are reserved and will result in an <b>ERROR</b> response to the Write Command
<b>&lt;cid&gt;</b>	A numeric parameter which specifies a particular PDP context definition (see <b>AT+CGDCONT</b> command).

### Example

```
AT+CGDCONT=1,"IP","UNINET" //Define a PDP context
OK
```

```
AT+CGACT=1,1 //Activated the PDP
OK
AT+CGACT=0,1 //Deactivated the PDP
OK
```

## 10.6. AT+CGDATA\* Enter Data Mode

The Write Command causes the MT to perform whatever actions that are necessary to establish communication between the TE and the network using one or more packet domain PDP types. This may include performing a PS attach and one or more PDP context activations. Commands following the **AT+CGDATA** command in the AT command line will not be processed by the MT.

If the **<L2P>** parameter value is unacceptable to the MT, the MT shall return an **ERROR** or **+CME ERROR** response. Otherwise, the MT issues the intermediate result code **CONNECT** and enters V.250 online data state. After data transfer is completed, and the layer 2 protocol termination procedure has been completed successfully, the command mode is reentered and the MT returns the final result code **OK**.

### AT+CGDATA\* Enter Data Mode

Test Command <b>AT+CGDATA=?</b>	Response <b>+CGDATA:</b> (list of supported <b>&lt;L2P&gt;</b> s)  <b>OK</b>
Write Command <b>AT+CGDATA=&lt;L2P&gt;[,&lt;cid&gt;[,&lt;cid&gt;[,...]]]</b>	Response <b>CONNECT</b> <b>ERROR</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms
Reference 3GPP TS 27.007	

### Parameter

<b>&lt;L2P&gt;</b>	A string parameter that indicates the layer 2 protocol to be used between the TE and MT: PPP (Point to Point protocol) for a PDP such as IP. Other values are not supported and will result in an <b>ERROR</b> response to the Execution Command.
<b>&lt;cid&gt;</b>	A numeric parameter which specifies a particular PDP context definition (see <b>AT+CGDCONT</b> command).

## 10.7. AT+CGPADDR Show PDP Address

The Write Command returns a list of PDP addresses for the specified context identifiers. If no **<cid>** is specified, the addresses for all defined contexts are returned.

### AT+CGPADDR Show PDP Address

Test Command <b>AT+CGPADDR=?</b>	Response <b>+CGPADDR:</b> (list of defined <b>&lt;cid&gt;</b> s)  <b>OK</b>
Write Command <b>AT+CGPADDR[=&lt;cid&gt;[,&lt;cid&gt;[,...]]]</b>	Response <b>+CGPADDR:</b> <b>&lt;cid&gt;</b> , <b>&lt;PDP_addr&gt;</b> <b>[+CGPADDR:</b> <b>&lt;cid&gt;</b> , <b>&lt;PDP_addr&gt;</b> <b>[...]]</b>  <b>OK</b> <b>ERROR</b>
Maximum Response Time	300ms
Reference	3GPP TS 27.007

#### Parameter

- <cid>** A numeric parameter which specifies a particular PDP context definition (see **AT+CGDCONT** command).
- <PDP\_addr>** A string that identifies the MT in the address space applicable to the PDP. The address may be static or dynamic. For a static address, it will be the one set by the **AT+CGDCONT** command when the context was defined. For a dynamic address it will be the one assigned during the last PDP context activation that used the context definition referred to by **<cid>**. **<PDP\_address>** is omitted if none is available.

#### Example

```
AT+CGDCONT=1,"IP","UNINET" //Define a PDP context
OK
AT+CGACT=1,1 //Activated the PDP
OK
AT+CGPADDR=1 //Show the PDP address
+CGPADDR: 1,"10.76.51.180"
OK
```

## 10.8. AT+CGCLASS\* GPRS Mobile Station Class

The command is used to set the MT to operate according to the specified mode of operation. See 3GPP TS 23.060.

### AT+CGCLASS\* GPRS Mobile Station Class

Test Command <b>AT+CGCLASS=?</b>	Response <b>+CGCLASS:</b> (list of supported <class>s)  <b>OK</b>
Read Command <b>AT+CGCLASS?</b>	Response <b>+CGCLASS:</b> <class>  <b>OK</b>
Write Command <b>AT+CGCLASS=&lt;class&gt;</b>	Response <b>OK</b> <b>ERROR</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms
Reference 3GPP TS 27.007	

#### Parameter

<class>	A string parameter which indicates the GPRS mobile class (functionality in descending order) "A" Class A
---------	---

## 10.9. AT+CGREG Network Registration Status

The command queries the network registration status and controls the presentation of an unsolicited result code **+CGREG: <stat>** when <n>=1 and there is a change in the MT's GPRS network registration status in GERAN, or unsolicited result code **+CGREG: <stat>,[<lac>],[<ci>],[<Act>],[<rac>]** when <n>=2 and there is a change of the network cell in GERAN.

**AT+CGREG Network Registration Status**

Test Command <b>AT+CGREG=?</b>	Response <b>+CGREG:</b> (list of supported <n>s)  <b>OK</b>
Read Command <b>AT+CGREG?</b>	Response <b>+CGREG:</b> <n>,<stat>[,<lac>,<ci>[,<Act>]]  <b>OK</b> <b>OK</b>
Write Command <b>AT+CGREG[=&lt;n&gt;]</b>	Response <b>OK</b> <b>ERROR</b>
Maximum Response Time	300ms
Reference 3GPP TS 27.007	

**Parameter**

<n>	0	Disable network registration unsolicited result code
	1	Enable network registration unsolicited result code: <b>+CGREG:&lt;stat&gt;</b>
	2	Enable network registration and location information unsolicited result code: <b>+CGREG: &lt;stat&gt;[,&lt;lac&gt;,&lt;ci&gt;[,&lt;Act&gt;]]</b>
<stat>	0	Not registered. MT is not currently searching an operator to register to. The UE is in GMM state GMM-NULL or GMM-DEREGISTERED-INITIATED. The GPRS service is disabled, but the UE is allowed to attach for GPRS if requested by the user.
	1	Registered, home network. The UE is in GMM state GMM-REGISTERED or GMM-ROUTING-AREA-UPDATING-INITIATED INITIATED on the home PLMN.
	2	Not registered, but MT is currently trying to attach or searching an operator to register to. The UE is in GMM state GMM-DEREGISTERED or GMM-REGISTERED-INITIATED. The GPRS service is enabled, but an allowable PLMN is currently not available. The UE will start a GPRS attach as soon as an allowable PLMN is available.
	3	Registration denied. The UE is in GMM state GMM-NULL. The GPRS service is disabled, and the UE is not allowed to attach for GPRS if requested by the user.
	4	Unknown
	5	Registered, roaming
<lac> in		String type. Two-byte location area code in hexadecimal format (e.g. "00C3" equals to 195 decimal)
<ci>		String type. Two-byte cell ID in hexadecimal format.
<Act>		Access technology selected.
	0	GSM

8	LTE Cat.M1
9	LTE Cat.NB1

### Example

```
AT+CGREG=2
OK
AT+CGATT=0
OK

+CGREG: 2
AT+CGATT=1
OK

+CGREG: 1,"D504","80428B5",2
```

## 10.10. AT+CGEREP\* Packet Domain Event Report

The Write Command enables or disables sending of unsolicited result codes **+CGEV: XXX** from MT to TE in the case of certain events occurring in the packet domain MT or the network. **<mode>** controls the processing of unsolicited result codes specified within this command. **<bfr>** controls the effect on buffered codes when **<mode>** 1 or 2 is entered.

### AT+CGEREP\* Packet Domain Event Report

Test Command <b>AT+CGEREP=?</b>	Response <b>+CGEREP:</b> (list of supported <b>&lt;mode&gt;</b> s),(list of supported <b>&lt;bfr&gt;</b> s)  <b>OK</b>
Read Command <b>AT+CGEREP?</b>	Response <b>+CGEREP:</b> <b>&lt;mode&gt;</b> , <b>&lt;bfr&gt;</b>  <b>OK</b>
Write Command <b>AT+CGEREP=mode[,&lt;bfr&gt;]</b>	Response <b>OK</b> <b>ERROR</b>
Execution Command <b>AT+CGEREP</b>	Response <b>OK</b>
Maximum Response Time	300ms
Reference 3GPP TS 27.007	

## Parameter

<mode>	<u>0</u>	Buffer unsolicited result codes in the MT. If MT result code buffer is full, the oldest ones can be discarded. No codes are forwarded to the TE.
	1	Discard unsolicited result codes when MT-TE link is reserved (e.g. in on-line data mode); otherwise forward them directly to the TE.
	2	Buffer unsolicited result codes in the MT when MT-TE link is reserved (e.g. in on-line data mode) and flush them to the TE when MT-TE link becomes available; otherwise forward them directly to the TE.
<bfr>	<u>0</u>	MT buffer of unsolicited result codes defined within this command is cleared when <b>&lt;mode&gt;</b> 1 or 2 is entered.
	1	MT buffer of unsolicited result codes defined within this command is flushed to the TE when <b>&lt;mode&gt;</b> 1 or 2 is entered ( <b>OK</b> response shall be given before flushing the codes).

### NOTE

The unsolicited result codes and the corresponding events are defined as follows:

1. **+CGEV: REJECT <PDP\_type>, <PDP\_addr>**: A network request for PDP context activation occurred when the MT was unable to report it to the TE with a **+CRING** unsolicited result code and was automatically rejected.  
Note: This event is not applicable for EPS.
2. **+CGEV: NW REACT <PDP\_type>, <PDP\_addr>, [<cid>]**: The network has requested a context reactivation. The **<cid>** used to reactivate the context is provided if known to the MT.  
Note: This event is not applicable for EPS.
3. **+CGEV: NW DEACT <PDP\_type>, <PDP\_addr>, [<cid>]**: The network has forced a context deactivation. The **<cid>** used to activate the context is provided if known to the MT.
4. **+CGEV: ME DEACT <PDP\_type>, <PDP\_addr>, [<cid>]**: The mobile equipment has forced a context deactivation. The **<cid>** used to activate the context is provided if known to the MT.
5. **+CGEV: NW DETACH**: The network has forced a Packet Domain detach. This implies that all active contexts have been deactivated. These are not reported separately.
6. **+CGEV: ME DETACH**: The mobile equipment has forced a Packet Domain detach. This implies that all active contexts have been deactivated. These are not reported separately.
7. **+CGEV: NW CLASS <class>**: The network has forced a change of MS class. The highest available class is reported (see **AT+CGCLASS**).
8. **+CGEV: ME CLASS <class>**: The mobile equipment has forced a change of MS class. The highest available class is reported (see **AT+CGCLASS**).
9. **+CGEV: PDN ACT <cid>**: Activated a context. The context represents a PDN connection in LTE or a Primary PDP context in GSM.
10. **+CGEV: PDN DEACT <cid>**: Deactivated a context. The context represents a PDN connection in LTE or a primary PDP context in GSM.

### Example

```
AT+CGEREP=?
+CGEREP: (0-2),(0,1)

OK
AT+CGEREP?
+CGEREP: 0,0

OK
```

## 10.11. AT+CGSMS Select Service for MO SMS Messages

The command specifies the service or service preference that the MT will use to send MO (mobile originated) SMS messages.

<b>AT+CGSMS Select Service for MO SMS Messages</b>	
Test Command <b>AT+CGSMS=?</b>	Response <b>+CGSMS:</b> (list of currently available <b>&lt;service&gt;</b> s)  <b>OK</b>
Read Command <b>AT+CGSMS?</b>	Response <b>+CGSMS:</b> <b>&lt;service&gt;</b>  <b>OK</b>
Write Command <b>AT+CGSMS=[&lt;service&gt;]</b>	Response <b>OK</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms
Reference	3GPP TS 27.007

### Parameter

<b>&lt;service&gt;</b>	A numeric parameter which indicates the service or service preference to be used
0	GPRS
1	Circuit switch
2	GPRS preferred (use circuit switched if GPRS is not available)
3	Circuit switch preferred (use GPRS if circuit switched is not available)

**NOTE**

The circuit switched service route is the default method.

## 10.12. AT+CEREG EPS Network Registration Status

The command queries the network registration status and controls the presentation of:

- the unsolicited result code **+CEREG: <stat>** when **<n>=1** and there is a change in the MT's EPS network registration status in E-UTRAN,
- the unsolicited result code **+CEREG: <stat>,[<tac>],[<ci>],[<Act>]** when **<n>=2** and there is a change of the network cell in E-UTRAN, and
- the unsolicited result code **+CEREG: <stat>,[<tac>],[<ci>],[<AcT>],[,],[<Active-Time>],[<Periodic-TAU>]]]]** when **<n>=4** and there is a change of the network cell in E-UTRAN.

### AT+CEREG EPS Network Registration Status

Test Command <b>AT+CEREG=?</b>	Response <b>+CEREG:</b> (list of supported <b>&lt;n&gt;s</b> )  <b>OK</b>
Read Command <b>AT+CEREG?</b>	Response When <b>&lt;n&gt;=0, 1, or 2</b> and command successful: <b>+CEREG:</b> <b>&lt;n&gt;,&lt;stat&gt;,[&lt;tac&gt;],[&lt;ci&gt;],[&lt;AcT&gt;],[&lt;cause_type&gt;,&lt;reject_cause&gt;]]]</b>  When <b>&lt;n&gt;=4</b> and command successful: <b>+CEREG:</b> <b>&lt;n&gt;,&lt;stat&gt;,[&lt;tac&gt;],[&lt;ci&gt;],[&lt;AcT&gt;],[&lt;rac&gt;],[&lt;cause_type&gt;],[&lt;reject_cause&gt;],[&lt;Active-Time&gt;],[&lt;Periodic-TAU&gt;]]]]</b>  <b>OK</b>
Write Command <b>AT+CEREG[=&lt;n&gt;]</b>	Response <b>OK</b> <b>ERROR</b>
Maximum Response Time	300ms
Reference 3GPP TS 27.007	

## Parameter

<b>&lt;n&gt;</b>	<ul style="list-style-type: none"> <li>0 Disable network registration unsolicited result code</li> <li>1 Enable network registration unsolicited result code: <b>+CEREG:&lt;stat&gt;</b></li> <li>2 Enable network registration and location information unsolicited result code: <b>+CEREG: &lt;stat&gt;[,&lt;tac&gt;,&lt;ci&gt;[,&lt;Act&gt;]]</b></li> <li>4 For a UE that wants to apply PSM, enable network registration and location information unsolicited result code: <b>+CEREG: &lt;stat&gt;[,&lt;tac&gt;],[&lt;ci&gt;],[&lt;Act&gt;][,],[&lt;Active-Time&gt;],[&lt;Periodic-TAU&gt;]]]</b></li> </ul>										
<b>&lt;stat&gt;</b>	<ul style="list-style-type: none"> <li>0 Not registered. MT is not currently searching an operator to register to.</li> <li>1 Registered, home network</li> <li>2 Not registered, but MT is currently trying to attach or searching an operator to register to.</li> <li>3 Registration denied</li> <li>4 Unknown</li> <li>5 Registered, roaming</li> </ul>										
<b>&lt;tac&gt;</b>	String type. Two-byte tracking area code in hexadecimal format.										
<b>&lt;ci&gt;</b>	String type. Four-byte E-UTRAN cell ID in hexadecimal format.										
<b>&lt;Act&gt;</b>	Access technology selected <ul style="list-style-type: none"> <li>0 GSM</li> <li>8 LTE Cat.M1</li> <li>9 LTE Cat.NB1</li> </ul>										
<b>&lt;cause_type&gt;</b>	Integer type. The type of <b>&lt;reject_cause&gt;</b> . <ul style="list-style-type: none"> <li>0 Indicates that <b>&lt;reject_cause&gt;</b> contains an EMM cause value.</li> <li>1 Indicates that <b>&lt;reject_cause&gt;</b> contains a manufacturer-specific cause.</li> </ul>										
<b>&lt;reject_cause&gt;</b>	Integer type. Contains the cause of the failed registration. The value is of type as defined by <b>&lt;cause_type&gt;</b> .										
<b>&lt;Active-Time&gt;</b>	String type. One byte in an 8 bit format. Active Time value (T3324) to be allocated to the UE. (e.g. "00001111" equals to 1 minute) Bits 5 to 1 represent the binary coded timer value. Bits 6 to 8 define the timer value unit as follows: Bits <table border="0" style="margin-left: 20px;"> <tr> <td style="padding-right: 10px;">8 7 6</td> <td></td> </tr> <tr> <td>0 0 0</td> <td>value is incremented in multiples of 2 seconds</td> </tr> <tr> <td>0 0 1</td> <td>value is incremented in multiples of 1 minute</td> </tr> <tr> <td>0 1 0</td> <td>value is incremented in multiples of decihours</td> </tr> <tr> <td>1 1 1</td> <td>value indicates that the timer is deactivated.</td> </tr> </table>	8 7 6		0 0 0	value is incremented in multiples of 2 seconds	0 0 1	value is incremented in multiples of 1 minute	0 1 0	value is incremented in multiples of decihours	1 1 1	value indicates that the timer is deactivated.
8 7 6											
0 0 0	value is incremented in multiples of 2 seconds										
0 0 1	value is incremented in multiples of 1 minute										
0 1 0	value is incremented in multiples of decihours										
1 1 1	value indicates that the timer is deactivated.										
<b>&lt;Periodic-TAU&gt;</b>	String type. One byte in an 8 bit format. Extend periodic TAU value (T3412_ext) to be allocated to the UE in E-UTRAN. (e.g. "00001010" equals to 100 minutes) Bits 5 to 1 represent the binary coded timer value. Bits 6 to 8 define the timer value unit as follows:										

Bits	
8 7 6	
0 0 0	value is incremented in multiples of 10 minutes
0 0 1	value is incremented in multiples of 1 hour
0 1 0	value is incremented in multiples of 10 hours
0 1 1	value is incremented in multiples of 2 seconds
1 0 0	value is incremented in multiples of 30 seconds
1 0 1	value is incremented in multiples of 1 minute

### 10.13. AT+QGDCNT Packet Data Counter

The command allows the application to check how much bytes are sent to or received by the module.

#### AT+QGDCNT Packet Data Counter

Test Command <b>AT+QGDCNT=?</b>	Response <b>+QGDCNT: (0,1)</b>  <b>OK</b>
Read Command <b>AT+QGDCNT?</b>	Response <b>+QGDCNT: &lt;bytes_sent&gt;,&lt;bytes_rcv&gt;</b>  <b>OK</b>
Write Command <b>AT+QGDCNT=&lt;op&gt;</b>	Response <b>OK</b> <b>ERROR</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms

#### Parameter

<b>&lt;op&gt;</b>	A numeric parameter. The operation about data counter 0 Reset the data counter 1 Save the results of data counter to NV If results need to be automatically saved, please refer to <b>AT+QAUGDCNT</b> command.
<b>&lt;bytes_sent&gt;</b>	A numeric parameter. The amount of sent bytes.
<b>&lt;bytes_rcv&gt;</b>	A numeric parameter. The amount of received bytes.

**NOTE**

When the module is powered on, **<bytes\_sent>** and **<bytes\_rcv>** will be loaded from results of data counter in NV. The default result in NV is 0.

**Example**

```
AT+QGDCNT=? //Test command
+QGDCNT: (0,1)
```

OK

```
AT+QGDCNT? //Query the current bytes sent and received
+QGDCNT: 3832,4618
```

OK

```
AT+QGDCNT=1 //Save the results to NV
OK
```

```
AT+QGDCNT =0 //Reset the counter
OK
```

### 10.14. AT+QAUGDCNT Auto Save Packet Data Counter

The command allows command **AT+QGDCNT** to save results to NV automatically.

#### AT+QAUGDCNT Auto Save Packet Data Counter

Test Command <b>AT+QAUGDCNT=?</b>	Response <b>+QAUGDCNT: (0,(30-65535))</b>  <b>OK</b>
Read Command <b>AT+ QAUGDCNT?</b>	Response <b>+QAUGDCNT: &lt;value&gt;</b>  <b>OK</b>
Write Command <b>AT+QAUGDCNT=&lt;value&gt;</b>	Response <b>OK</b> <b>ERROR</b>

	If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms

### Parameter

**<value>** A numeric parameter. Default value is 0. The parameter is the time-interval for **AT+QGDCNT** command to save results to NV automatically. If it is set to 0, auto-save feature would be disabled. Unit is second.

#### NOTE

The configuration would not be saved into NV.

### Example

```

AT+QAUGDCNT=? //Test command
+QAUGDCNT: (0,30-65535)

OK

AT+QGDCNT=35 //Set <value>
OK

AT+QAUGDCNT? //Query the interval of auto-save
+QAUGDCNT: 35

OK

```

# 11 Supplementary Service Commands\*

All commands in this chapter are still under development.

## 11.1. AT+CCFC Call Forwarding Number and Conditions Control

The command allows control of the call forwarding supplementary service according to 3GPP TS 22.082. Registration, erasure, activation, deactivation and status query are supported.

### AT+CCFC Call Forwarding Number and Conditions Control

Test Command  
**AT+CCFC=?**

Response  
**+CCFC:** (list of supported <reads>s)  
  
**OK**

Write Command  
**AT+CCFC=<reads>,<mode>[,<number>[,<type>[,<class>[,<subaddr>[,<satype>[,<time>]]]]]]]**

Response  
TA controls the call forwarding supplementary service. Registration, erasure, activation, deactivation, and status query are supported.  
Only <reads> and <mode> should be entered with mode (0-2, 4)

If <mode> is not equal to 2 and the command is executed successfully:  
**OK**

If <mode>=2 and the command is executed successfully (only in connection with <reads> 0-3):  
For registered call forwarding numbers:  
**+CCFC:**  
<status>,<class1>[,<number>,<type>[,<subaddr>,<satype>[,<time>]]] [**<CR><LF>+CCFC: ....**]

**OK**

If no call forwarding numbers are registered (and therefore all classes are inactive):  
**+CCFC: <status>,<class>**

	<p><b>OK</b> where <b>&lt;status&gt;</b>=0 and <b>&lt;class&gt;</b>=15</p> <p>If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p>
Maximum Response Time	300ms
Reference	3GPP TS 27.007

### Parameter

<b>&lt;reads&gt;</b>	0	Unconditional
	1	Mobile busy
	2	No reply
	3	Not reachable
	4	All call forwarding (0-3)
	5	All conditional call forwarding (1-3)
<b>&lt;mode&gt;</b>	0	Disable
	1	Enable
	2	Query status
	3	Registration
	4	Erasure
<b>&lt;number&gt;</b>	Phone number in string type of forwarding address in format specified by <b>&lt;type&gt;</b>	
<b>&lt;type&gt;</b>	Type of address in integer format. Default value is 145 when dialing string includes international access code character "+", otherwise 129.	
<b>&lt;subaddr&gt;</b>	String type sub-address of format specified by <b>&lt;satype&gt;</b>	
<b>&lt;satype&gt;</b>	Type of sub-address in integer	
<b>&lt;class&gt;</b>	1	Voice
	2	Data
	4	FAX
	7	All telephony except SMS
	8	Short message service
	16	Data circuit sync
	32	Data circuit async
<b>&lt;time&gt;</b>	1...30	When "no reply" ( <b>&lt;reads&gt;</b> =no reply) is enabled or queried, this gives the time in seconds to wait before the call is forwarded. The default value is 20.
<b>&lt;status&gt;</b>	0	Not active
	1	Active

### Example

```

AT+CCFC=0,3,"15021012496" //Register the destination number for unconditional call
                           forwarding (CFU)
OK
AT+CCFC=0,2 //Query the status of CFU without specifying <class>
+CCFC: 1,1,"+8615021012496",145,,,
OK
AT+CCFC=0,4 //Erase the registered CFU destination number
OK
AT+CCFC=0,2 //Query the status, no destination number
+CCFC: 0,255
OK

```

## 11.2. AT+CCWA Call Waiting Control

The command allows control of the call waiting supplementary service according to 3GPP TS 22.083. Activation, deactivation and status query are supported.

### AT+CCWA Call Waiting Control

Test Command <b>AT+CCWA=?</b>	Response <b>+CCWA:</b> (list of supported <n>s)  <b>OK</b>
Read Command <b>AT+CCWA?</b>	Response <b>+CCWA:</b> <n>  <b>OK</b>
Write Command <b>AT+CCWA[=&lt;n&gt;][,&lt;mode&gt;[,&lt;class&gt;]]</b>	Response TA controls the call waiting supplementary service. Activation, deactivation and status query are supported. If <mode> is not equal to 2 and the command is executed successfully: <b>OK</b>  If <mode>=2 and the command is executed successfully: <b>+CCWA:</b> <status>,<class1>[<CR><LF>+CCWA:<status>,<class2>[. .]]

	OK
	If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms
Reference	3GPP TS 27.007

## Parameter

<b>&lt;n&gt;</b>	0	Disable presentation of an unsolicited result code
	1	Enable presentation of an unsolicited result code
<b>&lt;mode&gt;</b>	When <b>&lt;mode&gt;</b> parameter is not given, network is not interrogated	
	0	Disable
	1	Enable
	2	Query status
<b>&lt;class&gt;</b>	A sum of integers, each integer represents a class of information	
	1	Voice (telephony)
	2	Data (bearer service)
	4	FAX (facsimile)
	16	Data circuit synchronization
	32	Data circuit asynchronization
<b>&lt;status&gt;</b>	0	Disable
	1	Enable
<b>&lt;number&gt;</b>	Phone number in string type of calling address in format specified by <b>&lt;type&gt;</b>	
<b>&lt;type&gt;</b>	Type of address octet in integer format	
	129	Unknown type (ISDN format number)
	145	International number type (ISDN format )
<b>&lt;alpha&gt;</b>	Optional string type alphanumeric representation of <b>&lt;number&gt;</b> corresponding to the entry found in phone book	

## NOTES

- <status>**=0 should be returned only if service is not active for any **<class>** i.e. **+CCWA: 0, 7** will be returned in this case.
- When **<mode>**=2, all active call waiting classes will be reported. In this mode the command can be aborted by pressing any key.
- Unsolicited result code:  
When the presentation call waiting at the TA is enabled (and call waiting is enabled) and a terminating call set up during an established call, an unsolicited result code is returned:  
**+CCWA: <number>,<type>,<class>[,<alpha>]**

## Example

```

AT+CCWA=1,1 //Enable presentation of an unsolicited result code
OK
ATD10086; //Establish a call
OK
+CCWA: "02154450293",129,1 //Indication of a call that has been waiting
    
```

## 11.3. AT+CHLD Call Related Supplementary Services

The command allows the control of the following call related services:

- A call can be temporarily disconnected from the MT but the connection is retained by the network;
- Multiparty conversation (conference calls);
- The served subscriber who has two calls (one held and the other either active or alerting) can connect the other parties and release the served subscriber's own connection.

Calls can be put on hold, recovered, released and added to a conversation, and transferred similarly as defined in *3GPP TS 22.030*.

This is based on the GSM/UMTS supplementary services HOLD (Call Hold; refer to *3GPP TS 22.083 clause 2*), MPTY (MultiParty; refer to *3GPP TS 22.084*) and ECT (Explicit Call Transfer; refer to *3GPP TS 22.091*). The interaction of this command with other commands based on other GSM/UMTS supplementary services is described in the GSM/UMTS standards. Call Hold, MultiParty and Explicit Call Transfer are only applicable to teleservice 11.

### AT+CHLD Call Related Supplementary Services

Test Command <b>AT+CHLD=?</b>	Response <b>+CHLD:</b> (list of supported <n>s)  <b>OK</b>
Write Command <b>AT+CHLD[=&lt;n&gt;]</b>	Response TA controls the supplementary services call hold, multiparty and explicit call transfer. Calls can be put on hold, recovered, released, added to conversation and transferred. <b>OK</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms

Reference  
3GPP TS 27.007

### Parameter

<n>	0	Terminate all held calls or UDUB (User Determined User Busy) for a waiting call. If a call is waiting, terminate the waiting call. Otherwise, terminate all held calls (if any).
	1	Terminate all active calls (if any) and accept the other call (waiting call or held call)
	1X	Terminate the specific call number X (X=1-7)
	<u>2</u>	Place all active calls on hold (if any) and accept the other call (waiting call or held call) as the active call
	2X	Place all active calls except call X (X=1-7) on hold
	3	Add the held call to the active calls
	4	Connects the two calls and disconnects the subscriber from both calls (ECT)

### Example

```

ATD10086; //Establish a call
OK
+CCWA: "02154450293",129,1 //Indication of a call that has been waiting
AT+CHLD=2 //Place the active call on hold and accept the waiting call as
           //the active call
OK
AT+CLCC
+CLCC: 1,0,1,0,0,"10086",129 //The first call on hold
+CLCC: 2,1,0,0,0,"02154450293",129 //The second call be active
OK
AT+CHLD=21 //Place the active call except call X=1 on hold
OK
AT+CLCC
+CLCC: 1,0,0,0,0,"10086",129 //The first call be active
+CLCC: 2,1,1,0,1,"02154450293",129 //The second call on hold
OK
AT+CHLD=3 //Add a held call to the active calls in order to set up a
           //conference (multiparty) call
OK
AT+CLCC

```

```
+CLCC: 1,0,0,0,1,"10086",129

+CLCC: 2,1,0,0,1,"02154450293",129

OK
```

## 11.4. AT+CLIP Calling Line Identification Presentation

The command refers to the GSM/UMTS supplementary service CLIP (Calling Line Identification Presentation) that enables a called subscriber to get the calling line identity (CLI) of the calling party when receiving a mobile terminated call.

### AT+CLIP Calling Line Identification Presentation

Test Command <b>AT+CLIP=?</b>	Response <b>+CLIP:</b> (list of supported <n>s)  <b>OK</b>
Read Command <b>AT+CLIP?</b>	Response <b>+CLIP:</b> <n>,<m>  <b>OK</b>
Write Command <b>AT+CLIP=&lt;n&gt;</b>	Response TA enables or disables the presentation of the calling line identity (CLI) at the TE. It has no effect on the execution of the supplementary service CLIP in the network. <b>OK</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	15s, determined by network.
Reference 3GPP TS 27.007	

#### Parameter

<n>	0	Suppress unsolicited result codes
	1	Display unsolicited result codes
<m>	0	CLIP not provisioned
	1	CLIP provisioned
	2	Unknown
<number>	Phone number in string type of calling address in format specified by <type>	

<b>&lt;subaddr&gt;</b>	String type subaddress of format specified by <b>&lt;satype&gt;</b>
<b>&lt;satype&gt;</b>	Type of subaddress octet in integer format (refer to <i>3GPP TS 24.008 [8] subclause 10.5.4.8</i> )
<b>&lt;type&gt;</b>	Type of address octet in integer format; 129 Unknown type (ISDN format) 145 International number type (ISDN format) 161 National number
<b>&lt;alpha&gt;</b>	String type alphanumeric representation of <b>&lt;number&gt;</b> corresponding to the entry found in phone book.
<b>&lt;CLI validity&gt;</b>	0 CLI valid 1 CLI has been withheld by the originator 2 CLI is not available due to interworking problems or limitations of originating network

**NOTE**

Unsolicited result code:

When the presentation of the CLIP at the TE is enabled (and calling subscriber allows), an unsolicited result code is returned after every **RING** (or **+CRING: <type>**) at a mobile terminating call:

**+CLIP: <number>,<type>,[subaddr],[satype],[<alpha>],<CLI validity>**

**Example**

```
AT+CPBW=1,"02151082965",129,"QUECTEL"
OK
AT+CLIP=1
OK
RING
+CLIP: "02151082965",129,,,"QUECTEL",0
```

## 11.5. AT+CLIR Calling Line Identification Restriction

The command refers to the CLIR supplementary service (Calling Line Identification Restriction) according to *3GPP TS 22.081* and the OIR supplementary service (Originating Identification Restriction) according to *3GPP TS 24.607* that allows a calling subscriber to enable or disable the presentation of the calling line identity (CLI) to the called party when originating a call.

## AT+CLIR Calling Line Identification Restriction

Test Command <b>AT+CLIR=?</b>	Response <b>+CLIR:</b> (list of supported <n>s)  <b>OK</b>
Read Command <b>AT+CLIR?</b>	Response <b>+CLIR:</b> <n>,<m>  <b>OK</b>
Write Command <b>AT+CLIR[=&lt;n&gt;]</b>	Response TA restricts or enables the presentation of the calling line identity (CLI) to the called party when originating a call. The command overrides the CLIR subscription (default is restricted or allowed) when temporary mode is provisioned as a default adjustment for all following outgoing calls. This adjustment can be revoked by using the opposite command. <b>OK</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	15s, determined by network.
Reference 3GPP TS 27.007	

### Parameter

<n>	Parameter sets the adjustment for outgoing calls
0	Presentation indicator is used according to the subscription of the CLIR service
1	CLIR invocation
2	CLIR suppression
<m>	Parameter shows the subscriber CLIR service status in the network
0	CLIR not provisioned
1	CLIR provisioned in permanent mode
2	Unknown (e.g. no network, etc.)
3	CLIR temporary mode presentation restricted
4	CLIR temporary mode presentation allowed

## 11.6. AT+COLP Connected Line Identification Presentation

The command refers to the GSM/UMTS supplementary service COLP (Connected Line Identification Presentation) that enables a calling subscriber to get the connected line identity (COL) of the called party after setting up a mobile originated call. The command enables or disables the presentation of the COL at the TE. It has no effect on the execution of the supplementary service COLR in the network.

### AT+COLP Connected Line Identification Presentation

Test Command <b>AT+COLP=?</b>	Response <b>+COLP:</b> (list of supported <n>s)  <b>OK</b>
Read Command <b>AT+COLP?</b>	Response <b>+COLP:</b> <n>,<m>  <b>OK</b>
Write Command <b>AT+COLP[=&lt;n&gt;]</b>	Response TA enables or disables the presentation of the COL (Connected Line) at the TE for a mobile originating a call. It has no effect on the execution of the supplementary service COLR in the network.  Intermediate result code is returned from TA to TE before any +CR or V.25ter responses. <b>OK</b>
Maximum Response Time	15s, determined by network.
Reference 3GPP TS 27.007	

#### Parameter

<n>	Parameter sets/shows the result code presentation status in the TA 0            Disable 1            Enable
<m>	Parameter shows the subscriber COLP service status in the network 0            COLP not provisioned 1            COLP provisioned 2            Unknown (e.g. no network, etc.)
<number>	Phone number in string type. Format specified by <type>.
<type>	Type of address octet in integer format 129         Unknown type (ISDN format number) 145         International number type (ISDN format )

<b>&lt;subaddr&gt;</b>	String type sub-address of format specified by <b>&lt;satype&gt;</b>
<b>&lt;satype&gt;</b>	Type of sub-address octet in integer format (refer to 3GPP TS 24.008 sub clause 10.5.4.8)
<b>&lt;alpha&gt;</b>	Optional string type alphanumeric representation of <b>&lt;number&gt;</b> corresponding to the entry found in phone book

**NOTE**

Intermediate result code:  
When enabled (and called subscriber allows), an intermediate result code is returned before any +CR or V.25ter responses:  
**+COLP: <number>,<type>,[<subaddr>],[<satype>],[<alpha>]**

**Example**

```
AT+CPBW=1,"02151082965",129,"QUECTEL"
OK
AT+COLP=1
OK
ATD02151082965;
+COLP: "02151082965",129,,,"QUECTEL"
OK
```

## 11.7. AT+CSSN Supplementary Service Notifications

The command refers to supplementary service related network initiated notifications. The Write Command enables/disables the presentation of notification result codes from TA to TE.

<b>AT+CSSN Supplementary Service Notifications</b>	
Test Command <b>AT+CSSN=?</b>	Response <b>+CSSN:</b> (list of supported <n>s),(list of supported <m>s)  <b>OK</b>
Read Command <b>AT+CSSN?</b>	Response <b>+CSSN:</b> <n>,<m>  <b>OK</b>
Write Command <b>AT+CSSN=&lt;n&gt;[,&lt;m&gt;]</b>	Response <b>OK</b> <b>ERROR</b>

	If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms
Reference	
3GPP TS 27.007	

## Parameter

<b>&lt;n&gt;</b>	Integer type. Sets/shows the <b>+CSSI</b> intermediate result code presentation status to the TE. <u>0</u> Disable 1    Enable
<b>&lt;m&gt;</b>	Integer type. Sets/shows the <b>+CSSU</b> unsolicited result code presentation status to the TE. <u>0</u> Disable 1    Enable
<b>&lt;code1&gt;</b>	Integer type. It is manufacturer specific, and supports the following codes: 0    Unconditional call forwarding is active 1    Some of the conditional call forwardings are active 2    Call has been forwarded 3    Waiting call is pending 5    Outgoing call is barred
<b>&lt;code2&gt;</b>	Integer type. It is manufacturer specific, and supports the following codes: 0    The incoming call is a forwarded call 2    Call has been put on hold (during a voice call) 3    Call has been retrieved (during a voice call) 5    Held call was terminated by another party 10    Additional incoming call forwarded

### NOTES

- When **<n>**=1 and a supplementary service notification is received after a mobile originated call is setup, the **+CSSI** intermediate result code is sent to TE before any other MO call setup result codes:  
**+CSSI: <code1>**
- When **<m>**=1 and a supplementary service notification is received during a mobile terminated call setup or during a call, the **+CSSU** unsolicited result code is sent to TE:  
**+CSSU: <code2>**

## 11.8. AT+CUSD Unstructured Supplementary Service Data

The command allows control of the Unstructured Supplementary Service Data (USSD) according to 3GPP TS 22.090. Both network and mobile initiated operations are supported.

Parameter **<mode>** is used to disable/enable the presentation of an unsolicited result code. The value **<mode>=2** is used to cancel an ongoing USSD session. For an USSD response from the network, or a network initiated operation, the format is: **+CUSD: <status>[,<rspstr>[,<dcsc>]]**.

When **<reqstr>** is given, a mobile initiated USSD string or a response USSD string to a network initiated operation is sent to the network. The response USSD string from the network is returned in a subsequent **+CUSD** URC.

AT+CUSD Unstructured Supplementary Service Data	
Test Command <b>AT+CUSD=?</b>	Response <b>+CUSD:</b> (list of supported <b>&lt;mode&gt;</b> s)  <b>OK</b>
Read Command <b>AT+CUSD?</b>	Response <b>+CUSD: &lt;mode&gt;</b>  <b>OK</b>
Write Command <b>AT+CUSD[=&lt;mode&gt;[,&lt;reqstr&gt;[,&lt;dcsc&gt;]]]</b>	Response <b>OK</b> <b>ERROR</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	120s, determined by network.
Reference 3GPP TS 27.007	

### Parameter

<b>&lt;mode&gt;</b>	Integer type. Sets/shows the result code presentation status to the TE <ul style="list-style-type: none"> <li><u>0</u>    Disable the result code presentation to the TE</li> <li>1    Enable the result code presentation to the TE</li> <li>2    Cancel session (not applicable to Read Command response)</li> </ul>
<b>&lt;reqstr&gt;</b>	Unstructured Supplementary Service Data (USSD) to be sent to the network. If this parameter is not given, network is not interrogated.
<b>&lt;rspstr&gt;</b>	Unstructured Supplementary Service Data (USSD) received from the network
<b>&lt;dcsc&gt;</b>	Integer type. 3GPP TS 23.038 Cell Broadcast Data Coding Scheme (default 15)

---

<b>&lt;status&gt;</b>	USSD response from the network or the network initiated operation
0	No further user action required (network initiated USSD Notify, or no further information needed after mobile initiated operation)
1	Further user action required (network initiated USSD Request, or further information needed after mobile initiated operation)
2	USSD terminated by network
3	Another local client has responded
4	Operation not supported
5	Network time out

---

Quectel  
Confidential

# 12 Audio Commands\*

All commands in this chapter are still under development.

## 12.1. AT+CLVL Loudspeaker Volume Level Selection

The command is used to select the volume of the internal loudspeaker of the MT.

AT+CLVL Loudspeaker Volume Level Selection	
Test Command AT+CLVL=?	Response +CLVL: (list of supported<level>s)  OK
Read Command AT+CLVL?	Response +CLVL: <level>  OK
Write Command AT+CLVL=<level>	Response OK  If there is an error related to ME functionality: +CME ERROR: <err>
Maximum Response Time	300ms
Reference 3GPP TS 27.007	

### Parameter

<level> Integer type value (0-3-5) with manufacturer specific range (smallest value represents the lowest sound level)

#### NOTE

The parameter will not be saved.

## 12.2. AT+CMUT Mute Control

The command is used to enable/disable the uplink voice muting during a voice call.

### AT+CMUT Mute Control

Test Command <b>AT+CMUT=?</b>	Response <b>+CMUT:</b> (list of supported<n>s)  <b>OK</b>
Read Command <b>AT+CMUT?</b>	Response <b>+CMUT:</b> <n>  <b>OK</b>
Write Command <b>AT+CMUT=&lt;n&gt;</b>	Response <b>OK</b>  If there is an error related to ME functionality: <b>+CME ERROR:</b> <err>
Maximum Response Time	300ms
Reference	3GPP TS 27.007

#### Parameter

<n>	<u>0</u>	Mute OFF
	1	Mute ON

#### NOTES

1. The command is only valid during a call.
2. The parameter will not be saved.

## 12.3. AT+QAUDLOOP Enable Audio Loop Test

This command is used to enable audio loop test.

### AT+QAUDLOOP Enable Audio Loop Test

Test Command <b>AT+QAUDLOOP=?</b>	Response <b>+QAUDLOOP:</b> (0,1),(0-2)
--------------------------------------	---

	OK
Read Command <b>AT+QAUDLOOP?</b>	Response <b>+QAUDLOOP: &lt;enable&gt;</b>
	OK
Write Command <b>AT+QAUDLOOP=&lt;enable&gt;[,&lt;path&gt;]</b>	Response <b>OK</b> <b>ERROR</b>
Maximum Response Time	300ms

### Parameter

<b>&lt;enable&gt;</b>	Numeric type. To enable or disable audio loop test.
0	Disable audio loop test
1	Enable audio loop test

#### NOTE

The parameter will not be saved.

## 12.4. AT+VTS DTMF and Tone Generation

The command is used to send ASCII characters which cause MSC to transmit DTMF tones to a remote subscriber. It can only be operated during a voice call.

### AT+VTS DTMF and Tone Generation

Test Command <b>AT+VTS=?</b>	Response <b>+VTS: (0-9,A-D,*,#),(0-255)</b>
	OK
Write Command <b>AT+VTS=&lt;dtmfstring&gt;[,&lt;duration&gt;]</b>	Response <b>OK</b> <b>ERROR</b>
	If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>

Maximum Response Time	Depends on the length of <b>&lt;dtmfstring&gt;</b> and <b>&lt;duration&gt;</b> .
Reference 3GPP TS 27.007	

## Parameter

<b>&lt;dtmfstring&gt;</b>	<p>ASCII characters in the set <b>0...9, #, *, A, B, C, D</b>. The string should be enclosed in quotation marks ("...")</p> <p>When sending multiple tones at a time, the time interval of two tones <b>&lt;interval&gt;</b> can be specified by <b>AT+VTD</b>. The maximal length of the string is 31.</p>
<b>&lt;duration&gt;</b>	<p>The duration of each tone in 1/10 seconds with tolerance.</p> <p>The value ranges from 0 to 255.</p> <p>If the duration is less than the minimum time specified by the network, the actual duration will be the network specified time.</p> <p>If this parameter is omitted, <b>&lt;duration&gt;</b> is specified by <b>AT+VTD</b>.</p>

## Example

```

ATD12345678900;           //Dial
OK
<Call connect>
AT+VTS="1"                //The remote caller can hear the DTMF tone
OK
AT+VTS="1234567890A"     //Send multiple tones at a time
OK
    
```

## 12.5. AT+VTD Set Tone Duration

The command sets the duration of DTMF tones. It can also set time interval between two tones when sending multiple tones at a time.

### AT+VTD Set Tone Duration

Test Command <b>AT+VTD=?</b>	<p>Response <b>+VTD: (0-255),(0-255)</b></p> <p><b>OK</b></p>
Read Command <b>AT+VTD?</b>	<p>Response <b>+VTD: &lt;duration&gt;,&lt;interval&gt;</b></p>

	OK
Write Command <b>AT+VTD=&lt;duration&gt;[,&lt;interval&gt;]</b>	Response OK ERROR  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms
Reference 3GPP TS 27.007	

### Parameter

<b>&lt;duration&gt;</b>	The duration tone in 1/10 seconds with tolerance. The value ranges from 0 to 255, and the default is 3. If the duration is less than the minimum time specified by the network, the actual duration will be network specified time.
<b>&lt;interval&gt;</b>	The time interval of two tones when sending multiple tones at a time by <b>AT+VTS</b> . The value ranges from 0 to 255, and the default is 0.

#### NOTE

These parameters will not be saved.

## 12.6. AT+QAUDMOD Set Audio Mode

The command sets the audio mode required for the connected device. It will take effect at next sound activity.

### AT+QAUDMOD Set Audio Mode

Test Command <b>AT+QAUDMOD=?</b>	Response <b>+QAUDMOD:</b> (list of supported <b>&lt;mode&gt;s</b> )  OK
Read command <b>AT+QAUDMOD?</b>	Response <b>+QAUDMOD:</b> <b>&lt;mode&gt;</b>  OK
Write Command	Response

AT+QAUDMOD=<mode>	OK  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms
Reference	Quectel

### Parameter

<b>&lt;mode&gt;</b>	Numeric type. Indicates the current configured audio mode.
0	Echo canceller, noise suppressor, digital gain and calibration parameter for Handset
1	Echo canceller, noise suppressor, digital gain and calibration parameter for Headset
2	Echo canceller, noise suppressor, digital gain and calibration parameter for Speaker

## 12.7. AT+QDAI Digital Audio Interface Configuration

The command is used to configure the digital audio interface. When **<io>=1**, the user can define the PCM mode (master/slave mode) by configuration setting. When **<io>=3**, the external codec chip linked with PCM interface is the ALC5616 model through the I2C. The settings will take effect after module reboot.

### AT+QDAI Digital Audio Interface Configuration

Test Command <b>AT+QDAI=?</b>	Response <b>+QDAI:</b> (list of supported <b>&lt;io&gt;s</b> ),(list of supported <b>&lt;mode&gt;s</b> ),(list of supported <b>&lt;fsync&gt;s</b> ),(list of supported <b>&lt;clock&gt;s</b> ),(list of supported <b>&lt;format&gt;s</b> )  OK
Read Command <b>AT+QDAI?</b>	Response <b>+QDAI: &lt;io&gt;[,&lt;mode&gt;,&lt;fsync&gt;,&lt;clock&gt;,&lt;format&gt;]</b>  OK
Write Command <b>AT+QDAI=&lt;io&gt;[,&lt;mode&gt;,&lt;fsync&gt;,&lt;clock&gt;[,&lt;format&gt;]]</b>	Response OK ERROR
Maximum Response Time	300ms
Reference	Quectel

## Parameter

<b>&lt;io&gt;</b>	1	Digital PCM output (customer defined)
	2	Reserved
	3	Analog output (for our default audio codec ALC5616)
<b>&lt;mode&gt;</b>	0	Master mode
	1	Slave mode
<b>&lt;fsync&gt;</b>	0	Primary mode (short-frame synchronization)
	1	Auxiliary mode (long-frame synchronization)
<b>&lt;clock&gt;</b>	0	128K
	1	256K
	2	512K
	3	1024K
	4	2048K
	5	4096K
<b>&lt;format&gt;</b>	0	16-bit linear
	1	8-bit a-law
	2	8-bit u-law

## NOTES

1. Configuration of **<io>** will be saved to NV immediately by default.
2. Both master and slave modes are supported under short-frame synchronization, and only master mode is supported under long-frame synchronization.
3. When short-frame synchronization and master mode are selected, 256K-4096K clock frequency is supported. And if long-frame synchronization and master mode are selected, only 128K clock frequency is supported.
4. If slave mode is selected, then master and synchronization clock must be provided for the module.

## Example

```

AT+QDAI=? //Query the range
+QDAI: (1-3),(0,1),(0,1),(0-5),(0-2)

OK
AT+QDAI? //Query the current interface configuration
+QDAI: 1,0,0,4,0

OK
AT+QDAI=1,1,0,4,1 //Set AUX PCM interface to slave short frame synchronization mode, PCM
format 8-bit a-law.

OK

```

## 12.8. AT+QEEC Set Echo Cancellation Parameters

The command is used to set echo cancellation parameters.

### AT+QEEC Set Echo Cancellation Parameters

Test Command <b>AT+QEEC=?</b>	Response <b>+QEEC: (0-49),(0-65535)</b>  <b>OK</b>
Read Command <b>AT+QEEC?</b>	Response <b>+QEEC: &lt;index&gt;,&lt;value&gt;</b>  ..... <b>+QEEC: &lt;index&gt;,&lt;value&gt;</b>  <b>OK</b>
Write Command <b>AT+QEEC=&lt;index&gt;,&lt;value&gt;</b>	Response <b>OK</b> <b>ERROR</b>

#### Parameter

<b>&lt;index&gt;</b>	Numeric type. Indicates the parameter's index. Range: 0-49
<b>&lt;value&gt;</b>	Numeric type. Indicates the parameter's value. Range: 0-65535

#### NOTE

These parameters will not be saved.

#### Example

```
AT+QEEC=? //Query the range
+QEEC: (0-49), (0-65535)
```

**OK**

```
AT+QEEC=6,1234 //Set the value of index 6 to 1234
```

**OK**

## 12.9. AT+QSIDET Set the Side Tone Gain in Current Mode

The command is used to set the side tone gain value in current mode. It will take effect at next sound activity.

### AT+QSIDET Set the Side Tone Gain in Current Mode

Test Command <b>AT+QSIDET=?</b>	Response <b>+QSIDET:</b> (list of supported <st_gain>s)  <b>OK</b>
Read Command <b>AT+QSIDET?</b>	Response <b>+QSIDET:</b> <st_gain>  <b>OK</b>
Write Command <b>AT+QSIDET=&lt;st_gain&gt;</b>	Response <b>OK</b> <b>ERROR</b>
Maximum Response Time	300ms
Reference Quectel	

#### Parameter

<st_gain>	Numeric type. Indicates the configured side tone gain in current mode. Range: 0-65535. Default value might be different in different audio modes.
-----------	--

#### NOTE

The parameter will not be saved.

## 12.10. AT+QMIC Set Uplink Gains of MIC

The command is used to set the uplink gains of microphone.

### AT+QMIC Set Uplink Gains of MIC

Test Command <b>AT+QMIC=?</b>	Response <b>+QMIC:</b> (0-65535),(0-65535)
----------------------------------	---

	OK
Read Command <b>AT+QMIC?</b>	Response <b>+QMIC: &lt;txgain&gt;,&lt;txdgain&gt;</b>
	OK
Write Command <b>AT+QMIC=&lt;txgain&gt;[,&lt;txdgain&gt;]</b>	Response <b>OK</b> <b>ERROR</b>
Maximum Response Time	300ms

### Parameter

- <txgain>** Numeric type. Indicates uplink codec gain and the range is 0-65535. The default value might be different in different audio modes.
- <txdgain>** Numeric type. Indicates uplink digital gain and the range is 0-65535. The default value might be different in different audio modes.

#### NOTE

These parameters will not be saved.

## 12.11. AT+QRXGAIN Set Downlink Gains of RX

The command is used to set RX digital gains to change the downlink volume.

### AT+QRXAGIN Set Downlink Gains of RX

Test Command <b>AT+QRXGAIN=?</b>	Response <b>+QRXGAIN: (0-65535)</b>  OK
Read Command <b>AT+QRXGAIN?</b>	Response <b>+QRXGAIN: &lt;rxgain&gt;</b>  OK
Write Command <b>AT+QRXGAIN=&lt;rxgain&gt;</b>	Response OK

	<b>ERROR</b>
Maximum Response Time	300ms

### Parameter

**<rxgain>** Numeric type. Indicates downlink digital gains. The range is 0-65535. The default value might be different in different audio modes.

### Example

```

AT+QTXGAIN=? //Test command
+QTXGAIN: (0-65535)

OK
AT+QTXGAIN? //Query the current value. The default value might be different in
+QTXGAIN: 20577 different audio modes.

OK
AT+QTXGAIN=8192 //Set digital gain to 8192.
OK
AT+QTXGAIN? //Query the current configuration.
+QTXGAIN: 8192

OK
    
```

## 12.12. AT+QIIC IIC Read and Write

### AT+QIIC IIC Read and Write

Test Command <b>AT+QIIC=?</b>	Response <b>+QIIC: (0,1),(0-FF),(0-FF),(1,2),(0-FFFF)</b>  <b>OK</b>
Write Command <b>AT+QIIC=&lt;rw&gt;,&lt;device&gt;,&lt;addr&gt;,&lt;bytes&gt;[,&lt;value&gt;]</b>	Response If all configuration parameters are entered: <b>OK</b>  If all configuration parameters are omitted: <b>+QIIC: &lt;value&gt;</b>

	<b>OK</b>
Maximum Response Time	300ms

### Parameter

<b>&lt;rw&gt;</b>	0	Write command
	1	Read command
<b>&lt;device&gt;</b>	0-0xFF	7-bit device address
<b>&lt;addr&gt;</b>	0-0xFF	Register address
<b>&lt;bytes&gt;</b>	1-2	Read/write bytes
<b>&lt;value&gt;</b>	0-0xFFFF	Data value

### NOTE

These parameters will not be saved.

### Example

```

AT+QIIC=1,0x1B,0x00,2 //Read register value, slave address: 0x1B, register address:
                          0x00, read two bytes.
+QIIC: 0x0021
OK

AT+QIIC=1,0x1B,0x00,2,0x0000 //Write register value, slave address: 0x1B, register address:
                                0x00, write two bytes.
OK

```

# 13 Hardware Related Commands

## 13.1. AT+QPOWD Power down

The command is used to shut down the module. The UE will return **OK** immediately when the command is executed. Then the UE deactivates the network. After it is completed, the UE outputs **POWERED DOWN** and enters into the shutdown state. The maximum time for unregistering network is 60 seconds. The UE is not allowed to turn off the power before the module's STATUS pin is set low or the URC **POWERED DOWN** is outputted to avoid data loss.

### AT+QPOWD Power down

Test Command  
**AT+QPOWD=?**

Response  
**+QPOWD: (0,1)**

**OK**

Execution Command  
**AT+QPOWD[=<n>]**

Response  
**OK**

**POWERED DOWN**

Maximum Response Time

300ms

### Parameter

<n>	0	Immediately power down
	1	Normal power down

## 13.2. AT+CCLK Clock

The command sets and queries the real time clock (RTC) of the module. The current setting is retained until the module is totally disconnected from power.

### AT+CCLK Clock

Test Command  
**AT+CCLK=?**

Response  
**OK**

Read Command <b>AT+CCLK?</b>	Response <b>+CCLK: &lt;time&gt;</b>  <b>OK</b>
Write Command <b>AT+CCLK=&lt;time&gt;</b>	Response <b>OK</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms
Reference 3GPP TS 27.007	

### Parameter

<b>&lt;time&gt;</b>	String type value. Format is “yy/MM/dd,hh:mm:ss±zz”, indicating year (last two digits), month, day, hour, minutes, seconds and time zone (indicates the difference, expressed in quarters of an hour, between the local time and GMT; range: -48...+56). E.g. May 6 <sup>th</sup> , 1994, 22:10:00 GMT+2 hours equals to “94/05/06,22:10:00+08”.
---------------------	--

### Example

```
AT+CCLK? //Query the local time
+CCLK: "08/01/04,00:19:43+00"
OK
```

## 13.3. AT+CBC\* Battery Charge

The command returns battery charge status (**<bcs>**) and battery charge level (**<bcl>**) of the MT.

### AT+CBC\* Battery Charge

Test Command <b>AT+CBC=?</b>	Response <b>+CBC:</b> (list of supported <b>&lt;bcs&gt;</b> s),(list of supported <b>&lt;bcl&gt;</b> s), <b>&lt;voltage&gt;</b>  <b>OK</b>
Execution Command <b>AT+CBC</b>	Response <b>+CBC: &lt;bcs&gt;,&lt;bcl&gt;,&lt;voltage&gt;</b>

	OK
	If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	300ms
Reference	3GPP TS 27.007

### Parameter

<b>&lt;bcs&gt;</b>	Battery charge status
	0 ME is not charging
	1 ME is charging
	2 Charging has been finished
<b>&lt;bcl&gt;</b>	Battery charge level
	0-100 Battery has 0-100 percent of capacity remaining vent
<b>&lt;voltage&gt;</b>	Battery voltage (Mv)

## 13.4. AT+QADC\* Read ADC Value

The command is used to read the voltage value of ADC channel.

AT+QADC* Read ADC Value	
Test Command <b>AT+QADC=?</b>	Response <b>+QADC: (0,1)</b>  <b>OK</b>
Read Command <b>AT+QADC=&lt;port&gt;</b>	Response <b>+QADC: &lt;status&gt;,&lt;value&gt;</b>  <b>OK</b>
Maximum Response Time	300ms

### Parameter

<b>&lt;port&gt;</b>	Channel number of the ADC
	0 ADC Channel 0
	1 ADC Channel 1
<b>&lt;status&gt;</b>	Indicate whether the ADC value is read successfully

	0	Fail
	1	Success
<b>&lt;value&gt;</b>	The voltage of specified ADC channel. Unit: mV.	

### 13.5. AT+QSCLK\* Configure Whether or Not to Enter into Sleep Mode

The command is used to control whether the module enters into sleep mode. When entering into sleep mode is enabled, DTR is pulled up, and WAKEUP\_IN is pulled up, the module can directly enter into sleep mode. If entering into sleep mode is disabled, DTR is pulled down, and WAKEUP\_IN is pulled down, there is a need to pull the DTR pin and the WAKEUP\_IN pin up first, and then the module can enter into sleep mode.

#### AT+QSCLK\* Configure Whether or Not to Enter into Sleep Mode

Test Command <b>AT+QSCLK=?</b>	Response <b>+QSCLK:</b> (list of supported <n>s)  <b>OK</b>
Read Command <b>AT+QSCLK?</b>	Response <b>+QSCLK:</b> <n>  <b>OK</b>
Write Command <b>AT+QSCLK=&lt;n&gt;</b>	Response <b>OK</b>
Maximum Response Time	300ms
Reference Quectel	

#### Parameter

<b>&lt;n&gt;</b>	<u>0</u>	Disable slow clock
	1	Enable slow clock. It is controlled by DTR.

# 14 Appendix

## 14.1. References

**Table 5: Related Documents**

SN	Document Name	Remark
[1]	V.25ter	Serial asynchronous automatic dialing and control
[2]	3GPP TS 27.007	Digital cellular telecommunications (Phase 2+); Universal Mobile Telecommunications System (UMTS); LTE; AT command set for User Equipment (UE)
[3]	3GPP TS 27.005	Digital cellular telecommunications (Phase 2+); Universal Mobile Telecommunications System (UMTS); LTE; Use of Data Terminal Equipment - Data Circuit terminating Equipment (DTE-DCE) interface for Short Message Service (SMS) and Cell Broadcast Service (CBS)

**Table 6: Terms and Abbreviations**

Abbreviation	Description
AMR	Adaptive Multi-Rate
CSD	Circuit Switch Data
DCD	Dynamic Content Delivery
DCE	Data Communication Equipment
DTE	Data Terminal Equipment
DTR	Data Terminal Ready
ECT	Explicit Call Transfer supplementary service

GPRS	General Packet Radio Service
ME	Mobile Equipment
MS	Mobile Station
PDP	Packet Data Protocol
PSC	Primary Synchronization Code
RTS/CTS	Request To Send/Clear To Send
TA	Terminal Adapter
TCP	Transmission Control Protocol
TE	Terminal Equipment
UDP	User Datagram Protocol
UE	User Equipment
NV	Non-Volatile Random Access Memory

## 14.2. Factory Default Settings Restorable with AT&F

Table 7: Factory Default Settings Restorable with AT&F

AT Command	Parameters	Factory Defaults
ATE	<value>	1
ATQ	<n>	0
ATS0	<n>	0
ATS3	<n>	13
ATS4	<n>	10
ATS5	<n>	8
ATS6	<n>	2
ATS7	<n>	0

ATS8	<n>	2
ATS10	<n>	15
ATV	<value>	1
ATX	<value>	4
AT&C	<value>	1
AT&D	<value>	1
AT+ICF	<format>,<parity>	3,3
AT+CREG	<n>	0
AT+CGREG	<n>	0
AT+CMEE	<n>	1
AT+CSCS	<chset>	"GSM"
AT+CSTA	<type>	129
AT+CR	<mode>	0
AT+CRC	<mode>	0
AT+CSMS	<service>	0
AT+CMGF	<mode>	0
AT+CSMP	<fo>,<vp>,<pid>,<dc>	17,167,0,0
AT+CSDH	<show>	0
AT+CSCB	<mode>	0
AT+CPMS	<mem1>,<mem2>,<mem3>	"ME","ME","ME"
AT+CNMI	<mode>,<mt>,<bm>,<ds>,<bfr>	2,1,0,0,0
AT+CMMS	<n>	0
AT+CVHU	<mode>	0
AT+CLIP	<n>	0
AT+COLP	<n>	0

AT+CLIR	<n>	0
AT+CSSN	<n>	0
AT+CTZR	<reporting>	0
AT+CPBS	<storage>	ME
AT+CGEREP	<mode>,<brf>	0,0
AT+CEREG	<n>	0
AT+CCWA	<n>	0
AT+CUSD	<mode>	0
AT+CLVL	<level>	3
AT+QAUDMOD	<mode>	0
AT+QAUDLOOP	<enable>	0

### 14.3. AT Command Settings Storable with AT&W

Table 8: AT Command Settings Storable with AT&W

AT Command	Parameters	Display with AT&V
ATE	<value>	Yes
ATQ	<n>	Yes
ATS0	<n>	Yes
ATS7	<n>	Yes
ATS10	<n>	Yes
ATV	<value>	Yes
ATX	<value>	Yes
AT&C	<value>	Yes
AT&D	<value>	Yes

AT+IPR	<rate>	No
AT+CREG	<n>	No
AT+CGREG	<n>	No
AT+CEREG	<n>	No

## 14.4. AT Command Settings Storable with ATZ

Table 9: AT Command Settings Storable with ATZ

AT Command	Parameters	Factory Defaults
ATE	<value>	1
ATQ	<n>	0
ATS0	<n>	0
ATS7	<n>	0
ATS10	<n>	15
ATV	<value>	1
ATX	<value>	4
AT&C	<value>	1
AT&D	<value>	1
AT+CREG	<n>	0
AT+CGREG	<n>	0
AT+CEREG	<n>	0

## 14.5. Summary of CME ERROR Codes

Final result code **+CME ERROR: <err>** indicates an error related to mobile equipment or network. The operation is similar to **ERROR** result code. None of the following commands in the same command line is executed. Neither **ERROR** nor **OK** result code shall be returned.

**<err>** values are mostly used by common message commands. The following table lists most of general and GRPS related **ERROR** codes. For some GSM protocol failure cause described in GSM specifications, the corresponding **ERROR** codes are not included.

**Table 10: Different Coding Schemes of +CME ERROR: <err>**

Code of <err>	Meaning
0	Phone failure
1	No connection to phone
2	Phone-adaptor link reserved
3	Operation not allowed
4	Operation not supported
5	PH-SIM PIN required
6	PH-FSIM PIN required
7	PH-FSIM PUK required
10	(U)SIM not inserted
11	(U)SIM PIN required
12	(U)SIM PUK required
13	(U)SIM failure
14	(U)SIM busy
15	(U)SIM wrong
16	Incorrect password
17	(U)SIM PIN2 required

18	(U)SIM PUK2 required
20	Memory full
21	Invalid index
22	Not found
23	Memory failure
24	Text string too long
25	Invalid characters in text string
26	Dial string too long
27	Invalid characters in dial string
30	No network service
31	Network timeout
32	Network not allowed - emergency calls only
40	Network personalization PIN required
41	Network personalization PUK required
42	Network subset personalization PIN required
43	Network subset personalization PUK required
44	Service provider personalization PIN required
45	Service provider personalization PUK required
46	Corporate personalization PIN required
47	Corporate personalization PUK required

## 14.6. Summary of CMS ERROR Codes

Final result code **+CMS ERROR: <err>** indicates an error related to mobile equipment or network. The operation is similar to **ERROR** result code. None of the following commands in the same command line is executed. Neither **ERROR** nor **OK** result code shall be returned.

<err> values are mostly used by common message commands:

**Table 11: Different Coding Schemes of +CMS ERROR: <err>**

Code of <err>	Meaning
300	ME failure
301	SMS ME reserved
302	Operation not allowed
303	Operation not supported
304	Invalid PDU mode
305	Invalid text mode
310	(U)SIM not inserted
311	(U)SIM pin necessary
312	PH (U)SIM pin necessary
313	(U)SIM failure
314	(U)SIM busy
315	(U)SIM wrong
316	(U)SIM PUK required
317	(U)SIM PIN2 required
318	(U)SIM PUK2 required
320	Memory failure
321	Invalid memory index
322	Memory full
330	SMSC address unknown
331	No network
332	Network timeout

500	Unknown
512	(U)SIM not ready
513	Message length exceeds
514	Invalid request parameters
515	ME storage failure
517	Invalid service mode
528	More message to send state error
529	MO SMS is not allow
530	GPRS is suspended
531	ME storage full

## 14.7. Summary of URC

Table 12: Summary of URC

Index	URC Display	Meaning	Condition
1	+CREG: <stat>	Indicate registration status of the ME	AT+CREG=1
2	+CREG: <stat>[,<lac>,<ci>[,<Act>]]	After cell neighborhood changing shows whether the network has currently indicated the registration of the ME, with location area code	AT+CREG=2
3	+CGREG: <stat>	Indicate network registration status of the ME	AT+CGREG=1
4	+CGREG: <stat>[,<lac>,<ci>[,<Act>]]	Indicate network registration and location information of the ME	AT+CGREG=2
5	+CTZV: <tz>	Time zone reporting	AT+CTZR=1
6	+CTZE: <tz>,<dst>,<time>	Extended time zone reporting	AT+CTZR=2
7	+CMTI: <mem>,<index>	New message is received, and saved to memory	See AT+CNMI
8	+CMT: [<alpha>],<length><CR><LF>	New short message is received and output directly to TE (PDU mode)	See AT+CNMI

	<pdu>		
9	+CMT: <oa>,[<alpha>],<scts>[,<tooa> ,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length>]<CR><LF><data>	New short message is received and output directly to TE (Text mode)	See AT+CNMI
10	+CBM: <length><CR><LF><pdu>	New CBM is received and output directly (PDU mode)	See AT+CNMI
11	+CBM: <sn>,<mid>,<dcs>,<page>,<pages><CR><LF><data>	New CBM is received and output directly to TE (Text mode)	See AT+CNMI
12	+CDS: <length><CR><LF><pdu>	New CDS is received and output directly (PDU mode)	See AT+CNMI
13	+CDS: <fo>,<mr>,[<ra>],[<tora>],[<scts>,<dt>,<st>	New CDS is received and output directly to TE (Text mode)	See AT+CNMI
14	+CDSI: <mem>,<index>	New message status report is received, and saved to memory	See AT+CNMI
15	+COLP: <number>,<type>,[<subaddr>],[<satype>],[<alpha>]	The presentation of the COL (connected line) at the TE for a mobile originated call	AT+COLP=1
16	+CLIP: <number>,<type>,[subaddr],[satype],[<alpha>],[<CLI validity>	Mobile terminating call indication	AT+CLIP=1
17	+CRING: <type>	An incoming call is indicated to the TE with unsolicited result code instead of the normal RING	AT+CRING=1
18	+CCWA: <number>,<type>,<class>[,<alpha>]	Call waiting indication	AT+CCWA=1,1
19	+CSSI: <code1>	Shows the +CSSI intermediate result code presentation status to the TE	AT+CSSN=1
20	+CSSU: <code2>	Shows the +CSSU unsolicited result code presentation status to the TE	AT+CSSN=<n>,1
21	+CUSD: <status>[,<rspstr>,[<dcs>]]	USSD response from the network, or a network initiated operation	AT+CUSD=1
22	RDY	ME initialization is successful	N/A
23	+CFUN: 1	All function of the ME is available	N/A
24	+CPIN: <state>	SIM card pin state	N/A
25	+QIND: SMS DONE	SMS initialization finished	N/A

26	+QIND: PB DONE	Phonebook initialization finished	N/A
27	POWERED DOWN	Module power down	AT+QPOWD
28	+CGEV: REJECT <PDP_type>, <PDP_addr>	A network request for PDP activation, and was automatically rejected.	AT+CGEREP=2,1
29	+CGEV: NW REACT <PDP_type>, <PDP_addr>, [ <cid> ]	The network request PDP reactivation	AT+CGEREP=2,1
30	+CGEV: NW DEACT <PDP_type>, <PDP_addr>, [ <cid> ]	The network has forced a context deactivation	AT+CGEREP=2,1
31	+CGEV: ME DEACT <PDP_type>, <PDP_addr>, [ <cid> ]	The ME has forced a context deactivation.	AT+CGEREP=2,1
32	+CGEV: NW DETACH	The network has forced a Packet Domain detach.	AT+CGEREP=2,1
33	+CGEV: ME DETACH	The mobile equipment has forced a Packet Domain detach.	AT+CGEREP=2,1
34	+CGEV: NW CLASS <class>	The network has forced a change of MS class.	AT+CGEREP=2,1
35	+CGEV: ME CLASS <class>	The mobile equipment has forced a change of MS class.	AT+CGEREP=2,1

## 14.8. SMS Character Sets Conversions

In 3GPP TS 23.038 DCS (Data Coding Scheme) defined three kinds of alphabets in SMS, GSM 7 bit default alphabet, 8 bit data and UCS2 (16bit). **AT+CSMP** can set the DCS in text mode (**AT+CMGF=1**). In text mode, DCS (Data Coding Scheme) and **AT+CSCS** determine the way of SMS text input or output.

**Table 13: The Way of SMS Text Input or Output**

DCS	AT+CSCS	The Way of SMS Text Input or Output
GSM 7 bit	GSM	Input or output GSM character sets.
GSM 7 bit	IRA	Input or output IRA character sets. Input: UE will convert IRA characters to GSM characters. Output: UE will convert GSM characters to IRA characters.
GSM 7 bit	UCS2	Input or output a hex string similar to PDU mode. So only support characters '0'-'9' and 'A'-'F'.

		Input: UE will convert the UCS2 hex string to GSM characters. Output: UE will convert the GSM characters to UCS2 hex string.
UCS2	-	Ignore the value of AT+CSCS, input or output a hex string similar to PDU mode. So only support characters '0'-'9' and 'A'-'F'.
8 bit	-	Ignore the value of AT+CSCS, input or output a hex string similar to PDU mode. So only support characters '0'-'9' and 'A'-'F'.

When DCS=GSM 7 bit, the input or output needs conversion. The detailed conversion tables are shown as below.

**Table 14: The Input Conversions Table (DCS=GSM 7 bit and AT+CSCS="GSM")**

	0	1	2	3	4	5	6	7
0	00	10	20	30	40	50	60	70
1	01	11	21	31	41	51	61	71
2	02	12	22	32	42	52	62	72
3	03	13	23	33	43	53	63	73
4	04	14	24	34	44	54	64	74
5	05	15	25	35	45	55	65	75
6	06	16	26	36	46	56	66	76
7	07	17	27	37	47	57	67	77
8	08	18	28	38	48	58	68	78
9	09	19	29	39	49	59	69	79
A	0A	Submit	2A	3A	4A	5A	6A	7A
B	0B	Cancel	2B	3B	4B	5B	6B	7B
C	0C	1C	2C	3C	4C	5C	6C	7C
D	0D	1A	2D	3D	4D	5D	6D	7D
E	0E	1E	2E	3E	4E	5E	6E	7E
F	0F	1F	2F	3F	4F	5F	6F	7F

**Table 15: The Output Conversions Table (DCS=GSM 7 bit and AT+CSCS="GSM")**

	0	1	2	3	4	5	6	7
0	00	10	20	30	40	50	60	70
1	01	11	21	31	41	51	61	71
2	02	12	22	32	42	52	62	72
3	03	13	23	33	43	53	63	73
4	04	14	24	34	44	54	64	74
5	05	15	25	35	45	55	65	75
6	06	16	26	36	46	56	66	76
7	07	17	27	37	47	57	67	77
8	08	18	28	38	48	58	68	78
9	09	19	29	39	49	59	69	79
A	0D0A		2A	3A	4A	5A	6A	7A
B	0B		2B	3B	4B	5B	6B	7B
C	0C	1C	2C	3C	4C	5C	6C	7C
D	0D	1A	2D	3D	4D	5D	6D	7D
E	0E	1E	2E	3E	4E	5E	6E	7E
F	0F	1F	2F	3F	4F	5F	6F	7F

**Table 16: GSM Extended Characters**

	0	1	2	3	4	5	6	7
0					1B40			
1								
2								
3								
4		1B14						

5	
6	
7	
8	1B28
9	1B29
A	
B	
C	1B3C
D	1B3D
E	1B3E
F	1B2F

**Table 17: The Input Conversions Table (DCS=GSM 7 bit and AT+CSCS="IRA")**

	0	1	2	3	4	5	6	7
0		20	20	30	00	50	20	70
1	20	20	21	31	41	51	61	71
2	20	20	22	32	42	52	62	72
3	20	20	23	33	43	53	63	73
4	20	20	02	34	44	54	64	74
5	20	20	25	35	45	55	65	75
6	20	20	26	36	46	56	66	76
7	20	20	27	37	47	57	67	77
8	backspace	20	28	38	48	58	68	78
9	20	20	29	39	49	59	69	79
A	0A	Submit	2A	3A	4A	5A	6A	7A
B	20	Cancel	2B	3B	4B	1B3C	6B	1B28

C	20	20	2C	3C	4C	1B2F	6C	1B40
D	0D	20	2D	3D	4D	1B3E	6D	1B29
E	20	20	2E	3E	4E	1B14	6E	1B3D
F	20	20	2F	3F	4F	11	6F	20

**Table 18: IRA Extended Characters**

	A	B	C	D	E	F
0	20	20	20	20	7F	20
1	40	20	20	5D	20	7D
2	20	20	20	20	20	08
3	01	20	20	20	20	20
4	24	20	5B	20	7B	20
5	03	20	0E	20	0F	20
6	20	20	1C	5C	1D	7C
7	5F	20	09	20	20	20
8	20	20	20	0B	04	0C
9	20	20	1F	20	05	06
A	20	20	20	20	20	20
B	20	20	20	20	20	20
C	20	20	20	5E	07	7E
D	20	20	20	20	20	20
E	20	20	20	20	20	20
F	20	60	20	1E	20	20

**Table 19: The Output Conversions Table (DCS=GSM 7 bit and AT+CSCS="IRA")**

	0	1	2	3	4	5	6	7
0	40	20	20	30	A1	50	BF	70
1	A3	5F	21	31	41	51	61	71
2	24	20	22	32	42	52	62	72
3	A5	20	23	33	43	53	63	73
4	E8	20	A4	34	44	54	64	74
5	E9	20	25	35	45	55	65	75
6	F9	20	26	36	46	56	66	76
7	EC	20	27	37	47	57	67	77
8	F2	20	28	38	48	58	68	78
9	C7	20	29	39	49	59	69	79
A	0D0A		2A	3A	4A	5A	6A	7A
B	D8		2B	3B	4B	C4	6B	E4
C	F8	C6	2C	3C	4C	D6	6C	F6
D	0D	E6	2D	3D	4D	D1	6D	F1
E	C5	DF	2E	3E	4E	DC	6E	FC
F	E5	C9	2F	3F	4F	A7	6F	E0

**Table 20: GSM Extended Characters**

	0	1	2	3	4	5	6	7
0					7C			
1								
2								
3								

4	5E	
5		
6		
7		
8	7B	
9	7D	
A		
B		
C		5B
D		7E
E		5D
F	5C	

Because the low 8 bit of UCS2 character is the same as the IRA character:

- The conversion table of DCS=GSM 7 bit and **AT+CSCS="UCS2"** is similar to **AT+CSCS="IRA"**.
- The conversion table of fmt=GSM 7 bit and **AT+CSCS="GSM"** is similar to **AT+CSCS="GSM"**.
- The conversion table of fmt= GSM 7 bit and **AT+CSCS="IRA"** is similar to **AT+CSCS="IRA"**.
- The conversion table of fmt=GSM 7 bit and **AT+CSCS="UCS2"** is similar to **AT+CSCS="IRA"**.
- The difference is the way of SMS text input or output. Please refer to **Table 14** for more details.

## 14.9. Release Cause Text List of AT+CEER

Table 21: Release Cause Text List of AT+CEER

### CS Internal Cause

No cause information available (default)

Phone is offline

No service available

Network release, no reason given

---

Received incoming call

---

Client ended call

---

(U)UIM not present

---

Access attempt already in progress

---

Access failure, unknown source

---

Concur service not supported by network

---

No response received from network

---

GPS call ended for user call

---

SMS call ended for user call

---

Data call ended for emergency call

---

Rejected during redirect or handoff

---

Lower-layer ended call

---

Call origination request failed

---

Client rejected incoming call

---

Client rejected setup indication

---

Network ended call

---

No funds available

---

No service available

---

Full service not available

---

Maximum packet calls exceeded

---

Video connection lost

---

Video protocol closed after setup

---

Video protocol setup failure

---

Internal error

---

**CS Network Cause**

---

Unassigned/unallocated number

---

---

No route to destination

---

Channel unacceptable

---

Operator determined barring

---

Normal call clearing

---

User busy

---

No user responding

---

User alerting, no answer

---

Call rejected

---

Number changed

---

Non selected user clearing

---

Destination out of order

---

Invalid/incomplete number

---

Facility rejected

---

Response to status enquiry

---

Normal, unspecified

---

No circuit/channel available

---

Network out of order

---

Temporary failure

---

Switching equipment congestion

---

Access information discarded

---

Requested circuit/channel not available

---

Resources unavailable, unspecified

---

Quality of service unavailable

---

Requested facility not subscribed

---

Incoming calls barred within the CUG

---

Bearer capability not authorized

---

---

Bearer capability not available

---

Service/option not available

---

Bearer service not implemented

---

ACM  $\geq$  ACM max

---

Requested facility not implemented

---

Only RDI bearer is available

---

Service/option not implemented

---

Invalid transaction identifier value

---

User not member of CUG

---

Incompatible destination

---

Invalid transit network selection

---

Semantically incorrect message

---

Invalid mandatory information

---

Message non-existent/not implemented

---

Message type not compatible with state

---

IE non-existent/not implemented

---

Conditional IE error

---

Message not compatible with state

---

Recovery on timer expiry

---

Protocol error, unspecified

---

Interworking, unspecified

---

### **CS Network Reject**

---

IMSI unknown in HLR

---

Illegal MS

---

IMSI unknown in VLR

---

IMEI not accepted

---

---

Illegal ME

---

GPRS services not allowed

---

GPRS and non GPRS services not allowed

---

MS identity cannot be derived

---

Implicitly detached

---

PLMN not allowed

---

Location area not allowed

---

Roaming not allowed

---

GPRS services not allowed in PLMN

---

No suitable cells in location area

---

MSC temporary not reachable

---

Network failure

---

MAC failure

---

Synch failure

---

Congestion

---

GSM authentication unacceptable

---

Service option not supported

---

Requested service option not subscribed

---

Service option temporary out of order

---

Call cannot be identified

---

No PDP context activated

---

Semantically incorrect message

---

Invalid mandatory information

---

Message type non-existent

---

Message type not compatible with state

---

Information element non-existent

---

---

Message not compatible with state

---

RR release indication

---

RR random access failure

---

RRC release indication

---

RRC close session indication

---

RRC open session failure

---

Low level failure

---

Low level failure no redial allowed

---

Invalid (U)SIM

---

No service

---

Timer T3230 expired

---

No cell available

---

Wrong state

---

Access class blocked

---

Abort message received

---

Other cause

---

Timer T303 expired

---

No resources

---

Release pending

---

Invalid user data

---

**PS Internal Cause**

---

Invalid connection identifier

---

Invalid NSAPI

---

Invalid primary NSAPI

---

PDP establish timeout

---

Invalid field

---

---

SNDCP failure

---

RAB setup failure

---

No GPRS context

---

PDP activate timeout

---

PDP modify timeout

---

PDP inactive max timeout

---

PDP lower layer error

---

PDP duplicate

---

Access technology change

---

PDP unknown reason

---

**CS PS Network Cause**

---

LLC or SNDCP failure

---

Insufficient resources

---

Missing or unknown APN

---

Unknown PDP address or PDP type

---

User authentication failed

---

Activation rejected by GGSN

---

Activation rejected, unspecified

---

Service option not supported

---

Requested service option not subscribed

---

Service option temporary out of order

---

NSAPI already used (not sent)

---

Regular deactivation

---

QoS not accepted

---

Network failure

---

Reactivation required

---

---

Feature not supported

---

Semantic error in the TFT operation

---

Syntactical error in the TFT operation

---

Unknown PDP context

---

PDP context without TFT already activated

---

Semantic errors in packet filter

---

Syntactical errors in packet filter

---

Invalid transaction identifier

---

Semantically incorrect message

---

Invalid mandatory information

---

Message non-existent/not implemented

---

Message type not compatible with state

---

IE non-existent/not implemented

---

Conditional IE error

---

Message not compatible with state

---

Protocol error, unspecified

---