

About Omni:bit wiring:

The left front motor is connected to the M1 interface of the Super:bit expansion board. The black line is on the battery side;

The left rear motor is connected to the M2 interface of the Super:bit expansion board, The black line is on the battery side;

The right front motor is connected to the M3 interface of the Super:bit expansion board, The black line is on the battery side;

The right rear motor is connected to the M4 interface of the Super:bit expansion board, The black line is on the battery side.

